



**User Manual**

**netHOST NHST-T100**

**LAN controlled master devices for Fieldbus and Real-Time Ethernet Systems**



**Hilscher Gesellschaft für Systemautomation mbH**  
**[www.hilscher.com](http://www.hilscher.com)**

DOC130401UM05EN | Revision 5 | English | 2018-05 | Released | Public

# Table of contents

|          |  |           |
|----------|--|-----------|
| <b>1</b> | <b>Introduction</b>                                    | <b>5</b>  |
| 1.1      | About this document                                    | 5         |
| 1.1.1    | Description of the contents                            | 5         |
| 1.1.2    | Obligation to read the manual                          | 6         |
| 1.1.3    | List of revisions                                      | 6         |
| 1.1.4    | Conventions in this document                           | 7         |
| 1.1.5    | Reference to hardware, firmware, software and drivers  | 8         |
| 1.2      | Contents of the product DVD                            | 10        |
| 1.3      | Documentation overview                                 | 12        |
| 1.4      | Legal notes  | 16        |
| 1.5      | Registered Trademarks                                  | 19        |
| <b>2</b> | <b>Safety</b>  | <b>20</b> |
| 2.1      | General note   | 20        |
| 2.2      | Intended use   | 20        |
| 2.3      | Personnel qualification                                | 20        |
| 2.4      | Safety references                                      | 20        |
| 2.5      | Safety instructions to avoid personal injury           | 21        |
| 2.5.1    | Danger of unsafe system operation                      | 21        |
| 2.6      | Safety instructions to avoid property damage           | 21        |
| 2.6.1    | Device destruction by exceeding allowed supply voltage | 21        |
| 2.6.2    | Danger of unsafe system operation                      | 21        |
| 2.7      | Labeling of safety messages                            | 22        |
| <b>3</b> | <b>Description</b>                                     | <b>23</b> |
| 3.1      | Functionality  | 23        |
| 3.2      | Device types   | 25        |
| 3.3      | Interfaces   | 26        |
| <b>4</b> | <b>Requirements</b>                                    | <b>28</b> |
| <b>5</b> | <b>Device drawings and connectors</b>                  | <b>30</b> |
| 5.1      | Dimensioned drawings                                   | 30        |
| 5.2      | Positions of the LEDs, connectors and control elements | 31        |
| 5.2.1    | netHOST for Fieldbus systems                           | 31        |
| 5.2.2    | netHOST for Real-Time Ethernet systems                 | 32        |
| 5.3      | Protocol logo and LED label sticker                    | 33        |
| 5.4      | Device label   | 33        |
| 5.5      | Power supply connector (X1)                            | 33        |
| 5.6      | Ethernet connectors                                    | 34        |
| 5.7      | Fieldbus interfaces (X3)                               | 35        |
| 5.7.1    | PROFIBUS DP interface (NHST-T100-DP/DPM)               | 35        |
| 5.7.2    | CANopen interface (NHST-T100-CO/COM)                   | 35        |
| 5.7.3    | DeviceNet interface (NHST-T100-DN/DNM)                 | 36        |
| 5.8      | USB interface (Mini-B USB)                             | 36        |
| 5.9      | Schematic diagram of Galvanic isolation                | 36        |

|           |  |           |
|-----------|--|-----------|
| 5.9.1     | netHOST for Fieldbus systems .....   | 37        |
| 5.9.2     | netHOST for RTE systems .....  | 38        |
| <b>6</b>  | <b>Mounting and dismounting of netHOST device .....</b>                      | <b>39</b> |
| 6.1       | Safety messages .....  | 39        |
| 6.2       | Mounting netHOST device onto Top Hat Rail .....                              | 40        |
| 6.3       | Removing netHOST device from the Top Hat Rail .....                          | 41        |
| <b>7</b>  | <b>Commissioning .....</b>   | <b>42</b> |
| 7.1       | Firmware .....   | 42        |
| 7.2       | Configuring the netHOST .....  | 42        |
| 7.3       | Start-up behavior .....  | 44        |
| 7.3.1     | Start-up without SD memory card .....  | 44        |
| 7.3.2     | Start-up with inserted SD memory card .....                                  | 44        |
| <b>8</b>  | <b>Firmware recovery .....</b>   | <b>45</b> |
| 8.1       | Overview .....   | 45        |
| 8.2       | Using an SD memory card to reset the netHOST to its “factory settings” ..... | 45        |
| 8.3       | Using USB to recover firmware .....  | 47        |
| <b>9</b>  | <b>Troubleshooting .....</b>   | <b>51</b> |
| <b>10</b> | <b>LEDs .....</b>  | <b>52</b> |
| 10.1      | SYS LED .....  | 52        |
| 10.2      | APL LED .....  | 53        |
| 10.3      | LEDs of the Fieldbus and Real-Time Ethernet systems .....                    | 54        |
| 10.3.1    | LED PROFIBUS DP Master (NHST-T100-DP/DPM) .....                              | 54        |
| 10.3.2    | LED CANopen Master (NHST-T100-CO/COM) .....                                  | 55        |
| 10.3.3    | LED DeviceNet Master (NHST-T100-DN/DNM) .....                                | 56        |
| 10.3.4    | LEDs PROFINET IO Controller .....  | 57        |
| 10.3.5    | LEDs EtherCAT Master .....   | 58        |
| 10.3.6    | LEDs EtherNet/IP Scanner .....   | 60        |
| <b>11</b> | <b>Technical data .....</b>  | <b>62</b> |
| 11.1      | Technical data of the netHOST devices .....                                  | 62        |
| 11.1.1    | netHOST for Fieldbus systems .....   | 62        |
| 11.1.2    | netHOST for Real-Time Ethernet systems .....                                 | 64        |
| 11.2      | Technical data of the protocols .....  | 65        |
| 11.2.1    | PROFIBUS DP Master (NHST-T100-DP/DPM) .....                                  | 65        |
| 11.2.2    | CANopen Master (NHST-T100-CO/COM) .....                                      | 66        |
| 11.2.3    | DeviceNet Master (NHST-T100-DN/DNM) .....                                    | 67        |
| 11.2.4    | PROFINET IO Controller .....   | 68        |
| 11.2.5    | EtherCAT Master .....  | 69        |
| 11.2.6    | EtherNet/IP Scanner .....  | 70        |
| <b>12</b> | <b>Decommissioning/Disposal .....</b>  | <b>71</b> |
| 12.1      | Putting the device out of operation .....                                    | 71        |
| 12.2      | Disposal of waste electronic equipment .....                                 | 71        |
|           | <b>List of figures .....</b>   | <b>72</b> |
|           | <b>List of tables .....</b>  | <b>73</b> |

---

**Contacts..... 75**

# 1 Introduction

## 1.1 About this document

### 1.1.1 Description of the contents

This user manual describes hardware, installation and commissioning of the LAN controlled Hilscher **netHOST** master devices for fieldbus and Real-Time Ethernet networks:

**NHST-T100-DP/DPM** for PROFIBUS DP (order no.: 1890.410/DPM)

**NHST-T100-CO/COM** for CANopen (order no.: 1890.500/COM)

**NHST-T100-DN/DNM** for DeviceNet (order no.: 1890.510/DNM)

**NHST-T100-EN/PNM** for PROFINET IO (order no.: 1890.840/PNM)

**NHST-T100-EN/ECM** for EtherCAT (order no.: 1890.110/ECM)

**NHST-T100-EN/EIM** for EtherNet/IP (order no.: 1890.820/EIM)

**NHST-T100-EN** for PROFINET IO, EtherCAT or EtherNet/IP (order no.: 1890.800, hardware and performance are identical to the **NHST-T100-EN/PNM/ECM/EIM** devices, but firmware has to be loaded into the device by the customer)

This document also features the technical data of the devices and of the supported network protocols. Instructions for resetting a netHOST device to its “factory settings” (firmware recovery) are also provided here.

The installation of the configuration software and the configuration of the netHOST devices are not subject of this document.

The installation of the software is described in the user manual *Software Installation netHOST Devices*. Instructions on how to configure, diagnose or test a netHOST device, or how update its firmware are provided in the operating instruction manual *Configuration of LAN controlled master devices – netHOST*.

All devices are delivered with their firmware already installed, except for the **NHST-T100-EN** netHOST device. If you are using the **NHST-T100-EN**, you will find instructions on how to install the firmware in the operating instruction manual *Configuration of LAN controlled master devices – netHOST*.

See also section *Documentation overview* [▶ page 12].

## 1.1.2 Obligation to read the manual



### Important:

- To avoid personal injury or property damage to your system or to your device, you must read and understand all instructions in this manual and in the documents accompanying your device before installing and operating your device.
- First read the **Safety Instructions** in the chapter *Safety* [▶ page 20].
- Observe all **Safety Messages** in this manual.
- Keep the product DVD providing the product manuals.

## 1.1.3 List of revisions

| Index | Date       | Revision  |
|-------|------------|---|
| 1     | 2013-08-05 | Created   |
| 2     | 2014-12-05 | Devices for Real-Time Ethernet added, document completely revised. Subtitle of document changed from “ <i>Remote Fieldbus Device for Field Installation</i> ” to „ <i>LAN controlled master devices for Fieldbus and Real-Time Ethernet networks</i> “.   |
| 3     | 2015-07-10 | Device <b>NHST-T100-EN</b> for loadable firmware added.   |
| 4     | 2015-07-22 | Firmware version in section <i>Hardware and firmware</i> [▶ page 8] updated to version ≥ 1.7<br>Section <i>LEDs of the Fieldbus and Real-Time Ethernet systems</i> [▶ page 54] updated.<br>Layout of document updated.<br>Layout of safety messages updated.  |
| 5     | 2018-05-16 | Software versions in section <i>Software</i> [▶ page 9] updated.<br>Section <i>Legal notes</i> [▶ page 16] updated.<br>Section <i>LEDs EtherCAT Master</i> [▶ page 58] updated.<br>Section <i>LEDs EtherNet/IP Scanner</i> [▶ page 60] updated.<br>Reference to stack version (2.7.) in section <i>Technical data PROFINET IO RT Controller</i> [▶ page 68] updated.<br>Section <i>Technical data EtherCAT Master protocol</i> [▶ page 69] updated (stack version 4.4.)<br>Reference to stack version (2.10.) in section <i>Technical data EtherNet/IP Scanner (master) protocol</i> [▶ page 70] updated. |

Table 1: List of revisions

## 1.1.4 Conventions in this document

Notes, operation instructions and results of operation steps are marked as follows:

### Notes



---

**Note:**  
<important note>

---



---

**Note:**  
<simple note>

---



---

<note, where to find further information>

---

### Operation instructions

1. <operational step>
  - <instruction>
2. <operational step>
  - <instruction>

### Results

- ↻ <intermediate result>
- ⇒ <final result>

For a description of the labeling of **Safety Messages**, see section *Labeling of safety messages* [➤ page 22].

## 1.1.5 Reference to hardware, firmware, software and drivers

### 1.1.5.1 Hardware and firmware

This document relates to the following versions of hardware and firmware:

#### Devices with preloaded firmware

| netHOST device preloaded with firmware | Order no.    | Hardware revision | Protocol               | Firmware file | Firmware (starting from this version and higher) |
|--|--------------|-------------------|------------------------|---------------|--|
| NHST-T100-DP/DPM                       | 1890.410/DPM | 4                 | PROFIBUS DP Master     | FT20V010.NXF  | 1.7.x.x  |
| NHST-T100-CO/COM                       | 1890.500/COM | 4                 | CANopen Master         | FT20V040.NXF  | 1.7.x.x  |
| NHST-T100-DN/DNM                       | 1890.510/DNM | 4                 | DeviceNet Master       | FT20V060.NXF  | 1.7.x.x  |
| NHST-T100-EN/PNM                       | 1890.840/PNM | 2                 | PROFINET IO Controller | FT20C0V0.NXF  | 1.7.x.x  |
| NHST-T100-EN/ECM                       | 1890.110/ECM | 2                 | EtherCAT Master        | FT20E0V0.NXF  | 1.7.x.x  |
| NHST-T100-EN/EIM                       | 1890.820/EIM | 2                 | EtherNet/IP Scanner    | FT20G0V0.NXF  | 1.7.x.x  |

Table 2: Reference to devices with preloaded firmware

#### Device for loadable firmware

(Firmware not loaded in state of delivery of device):

| netHOST device for loadable firmware | Order no. | Hardware revision | Supported protocols    | Loadable firmware file | Firmware (starting from this version and higher) |
|--------------------------------------|-----------|-------------------|------------------------|------------------------|--|
| NHST-T100-EN                         | 1890.800  | 2                 | PROFINET IO Controller | FT20C0V0.NXF           | 1.7.x.x  |
|                                      |           |                   | EtherCAT Master        | FT20E0V0.NXF           | 1.7.x.x  |
|                                      |           |                   | EtherNet/IP Scanner    | FT20G0V0.NXF           | 1.7.x.x  |

Table 3: Reference to devices for loadable firmware



#### Note:

For acting as master device, the **NHST-T100-EN** requires the **NXLIC-Master** license (order no.: **8211.000**). Make sure to order the **NHST-T100-EN** device together with the master license, so that it can be delivered with the license already loaded.

If necessary, a master license can also be ordered and installed belatedly; instructions for this are provided in the operating instruction manual *Configuration of LAN controlled master devices – netHOST*.

### 1.1.5.2 Software

This document relates to the following software versions:

| Software                           | Version   | File name               | Path on netHOST Solutions DVD                                   |
|------------------------------------|-----------|-------------------------|---|
| SYCON.net                          | 1.400.x.x | SYCONnet netX setup.exe | Setups & Drivers\SYCON.net                                      |
| Ethernet Device Configuration Tool | 1.900.x.x | EnDevConfigTool.msi     | Setups & Drivers\Ethernet Device Setup Utility                  |
| netHOST Device Test Application    | 1.2.x.x   | netHOST.exe             | Setups & Drivers\netHOST Test                                   |
| ComProX                            | 1.0.x.x   | comproX.exe             | Supplements & Examples\netHOST Device Recovery\Recovery via USB |

Table 4: Reference to software

### 1.1.5.3 Drivers

This document relates to the following driver versions:

| Driver   | Version | File name | Path on netHOST Solutions DVD |
|--|---------|-----------|-------------------------------|
| Installation program for Windows USB drivers, <i>contains:</i> | -       | setup.exe | Setups & Drivers\USB Driver   |
| • Windows Driver Package hilusbser                             | 6.0.x.x | -         | -                             |
| • Windows Driver Package hilusbser                             | 6.0.x.x | -         | -                             |

Table 5: Reference to drivers

## 1.2 Contents of the product DVD

The **netHOST Solutions** product DVD contains:

- PDF documentation for users and developers
- SYCON.net configuration and diagnostic program for Windows
- Ethernet Device Configuration Tool for Windows
- netHOST Device Test Application for Windows
- Communication DLLs for immediate usage in customer-engineered Windows applications
- source code of the DLLs
- XML templates and examples for configuring the netHOST device without SYCON.net
- Converter DLL for converting XML text files into netHOST-readable NXD binary files
- C-Toolkit (source code for developers of Non-Windows target platforms and embedded systems)
- USB drivers for Windows (only needed for resetting the device to its factory settings)
- Firmware:  
If you are using devices with preloaded firmware, these firmware files are needed only for resetting the device to its factory settings or for firmware recovery in case of a device defect.  
If you are using an NHST-T100-EN device (netHOST for loadable firmware), you have to load the corresponding firmware file of the desired protocol into the device during commissioning with SYCON.net.
- Software for resetting the device to its factory settings and for loading firmware
- Video-audio tutorials

### Directory of the DVD:

| Folder   | Contents   |  |
|--|--|--|
| <b>Documentation</b>                               |  |  |
| 1. Software  | Software documentation for standard users (PDF)  |  |
| Ethernet Device Setup Utility                      |  |  |
| SYCON.net  |  |  |
| 2. Hardware  | User Manual of the netHOST NHST-T100 device (PDF)  |  |
| 3. For Programmers                                 |  |  |
| 0. Understanding the Remote Access Principle       | Documentation for developers (PDF)   |  |
| 1. Communication Interface DLL API                 |  |  |
| 2. C-Toolkit Programming Reference Guide           |  |  |
| 3. Shared Memory Interface                         |  |  |
| 4. Communication Protocol specific APIs            |  |  |
| 5. Configuration without SYCON.net, XML file based |  | Documentation for developers (PDF) and XML files |
| 6. Ethernet Device Scanning UDP Protocol           |  | Documentation for developers (PDF)               |
| 7. Error Codes                                     |  |  |
| 4. Installation Instructions                       | Wiring and software installation instructions for standard users (PDF)   |  |
| <b>Firmware</b>                                    |  |  |
|  | Loadable device firmware<br><b>Note:</b> If you are using devices with preloaded firmware, these firmware files are needed only for resetting the device to its factory settings or for firmware recovery in case of a device defect. If you are using an NHST-T100-EN device (netHOST for loadable firmware), you have to load the corresponding firmware file of the desired protocol into the device during commissioning with SYCON.net. |  |
| <b>fscommand</b>                                   |  |  |
|  | Files needed for displaying the installation menu of the netHOST Solutions DVD   |  |
| <b>Programming &amp; Development</b>               |  |  |
| Configuration without SYCON.net, XML file based    | XML files  |  |
| Generic XML Configuration Schema                   |  |  |
| Protocol Specific XML Templates                    |  |  |
| XML2NXD Converter DLL                              |  |  |
| Developing own remote accessing Applications       |  |  |
| Header Files                                       | Header files for compilation   |  |
| netXTransport Protocol C-Toolkit                   | C source code of the netHOST transport protocol for target platform adaptation   |  |
| netXTransport Protocol DLL                         | C++ source codes of the DLLs and the netHOST Device Test Application for usage under Windows and precompiled Windows DLLs  |  |
| Wireshark netXTransport Protocol Interpreter-DLL   | DLL files for Wireshark  |  |
| <b>Setups &amp; Drivers</b>                        |  |  |
|  | Installation programs for the SYCON.net configuration and diagnostic software, for the netHOST Device Test Application, for the Ethernet Device Configuration Tool (Ethernet Device Setup Utility) and for the USB drivers   |  |
| <b>Supplements &amp; Examples</b>                  |  |  |
| netHOST Device Recovery                            |  |  |
| Recovery via Memory Card                           | Images for recovering the factory settings of the device by memory card  |  |

| Folder   | Contents   |
|--|--|
| Recovery via USB   | Software for recovering the factory settings of the device via USB |
| netXTransport Protocol C-Toolkit - Linux, Win32 Test Applications with Source Code | netXTransport Protocol C-Toolkit - Test Applications.sfx.exe       |
| netXTransport Protocol DLL - Win32 Test Application with Source Code               | netHOST test application for Windows                               |
| SYCON.net Sample Projects  | SYCON.net example projects   |
| XML2NXD Converter - Test Application (WPF) with Source Code                        | XML2NXD Converter - Test Application.sfx.exe                       |
| <b>Training &amp; Podcasts</b>   | Video presentations in avi format                                  |

Table 6: Directory of netHOST Solutions DVD

## 1.3 Documentation overview

This section lists documents that are relevant to the user of the netHOST device.

### Basic documents

| Title  | Contents   | Document ID     | Path on the netHOST Solutions DVD   |
|--|--|-----------------|---|
| User Manual netHOST NHST-T100 – LAN controlled master devices for Fieldbus and Real-Time Ethernet Systems <b>(this document)</b> | Installation, commissioning and hardware description of the netHOST devices and other technical data | DOC130401UMxxEN | Documentation\english\2.Hardware\netHOST, Model NHST-T100-xx\netHOST NHST-T100 – LAN controlled master devices UM xx EN.pdf |
| Operating Instruction Manual Configuration of LAN controlled master devices – netHOST  | Configuring, testing, diagnosing and updating firmware of the netHOST devices                        | DOC130402OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Configuration of netHOST-Devices OI xx EN.pdf             |
| User Manual Software Installation netHOST Devices  | Instructions for installing the netHOST software   | DOC130501UMxxEN | Documentation\english\4.Installation Instructions \netHOST - Software Installation UM XX EN.pdf                             |
| Operating Instruction Manual Ethernet Device Configuration   | Instructions on how to assign an IP address to Hilscher devices                                      | DOC050402OIxxEN | Documentation\english\1.Software\Ethernet Device Setup Utility \Ethernet Device Configuration OI XX EN.pdf                  |
| User Manual Wiring Instructions  | Wiring instructions (cable characteristics) for fieldbus networks                                    | DOC120208UMxxEN | Documentation\english\4.Installation Instructions \Wiring Instructions UM XX EN.pdf   |

Table 7: Basic documentation for netHOST

### netHOST as PROFIBUS DP Master

You also need the following documents if you are using an **NHST-T100-DP/DPM** netHOST device:

| Title  | Contents   | Document ID     | Path on the netHOST Solutions DVD  |
|--|--|-----------------|--|
| Operating Instruction Manual DTM for Hilscher-PROFIBUS DP Master Devices     | Description of the device type manager for PROFIBUS DP master devices        | DOC070401OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \PROFIBUS DP Master\PROFIBUS DP Master DTM OI xx EN.pdf                             |
| Operating Instruction Manual Generic Slave DTM for PROFIBUS DP Slave Devices | Description of the device type manager for generic PROFIBUS DP slave devices | DOC031001OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \PROFIBUS DP Master\Slave Configuration \PROFIBUS DP Generic Slave DTM OI xx EN.pdf |

Table 8: Additional documentation for netHOST as PROFIBUS DP Master

### netHOST as CANopen Master

You also need the following documents if you are using an **NHST-T100-CO/COM** netHOST device:

| Title  | Contents   | Document ID     | Path on the netHOST Solutions DVD   |
|--|--|-----------------|---|
| Operating Instruction Manual DTM for Hilscher-CANopen Master Devices     | Description of the device type manager for CANopen master devices        | DOC070402OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \CANopen Master\CANopen Master DTM OI xx EN.pdf                            |
| Operating Instruction Manual Generic Slave DTM for CANopen Slave Devices | Description of the device type manager for generic CANopen slave devices | DOC060203OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \CANopen Master\Slave Configuration\CANopen Generic Slave DTM OI xx EN.pdf |

Table 9: Additional documentation for netHOST as CANopen Master

### netHOST as DeviceNet Master

You also need the following documents, if you are using an **NHST-T100-DN/DNM** netHOST device:

| Title  | Contents   | Document ID     | Path on the netHOST Solutions DVD   |
|--|--|-----------------|---|
| Operating Instruction Manual DTM for Hilscher-DeviceNet Master Devices     | Description of the device type manager for DeviceNet master devices        | DOC070403OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \DeviceNet Master\DeviceNet Master DTM OI xx EN.pdf                            |
| Operating Instruction Manual Generic Slave DTM for DeviceNet Slave Devices | Description of the device type manager for generic DeviceNet slave devices | DOC041201OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \DeviceNet Master\Slave Configuration\DeviceNet Generic Slave DTM OI xx EN.pdf |

Table 10: Additional documentation for netHOST as DeviceNet Master

### netHOST as PROFINET IO Controller

You also need the following documents if you are using an **NHST-T100-EN/PNM**, respectively **NHST-T100-EN** device with loaded PROFINET IO Controller firmware:

| Title  | Contents  | Document ID     | Path on the netHOST Solutions DVD  |
|--|---|-----------------|--|
| Operating Instruction Manual DTM for Hilscher-PROFINET IO-Controller Devices | Description of the device type manager for PROFINET IO Controller devices | DOC060302OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \PROFINET IO Controller\PROFINET IO Controller DTM OI xx EN.pdf                               |
| Operating Instruction Manual Generic DTM for PROFINET IO Devices             | Description of the device type manager for generic PROFINET IO devices    | DOC060305OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \PROFINET IO Controller \IO Device Configuration \PROFINET IO Generic Device DTM OI xx EN.pdf |

Table 11: Additional documentation for netHOST as PROFINET IO Controller

### netHOST as EtherCAT Master

You also need the following documents if you are using an **NHST-T100-EN/ECM**, respectively **NHST-T100-EN** device with loaded EtherCAT Master firmware:

| Title   | Contents  | Document ID     | Path on the netHOST Solutions DVD   |
|---|---|-----------------|---|
| Operating Instruction Manual DTM for Hilscher EtherCAT Master Device      | Description of the device type manager for EtherCAT Master devices        | DOC080404OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \EtherCAT Master\EtherCAT Master DTM OI xx EN.pdf                            |
| Operating Instruction Manual Generic Slave DTM for EtherCAT Slave Devices | Description of the device type manager for generic EtherCAT slave devices | DOC071202OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \EtherCAT Master\Slave Configuration\EtherCAT Generic Slave DTM OI xx EN.pdf |
| User Manual Wiring Instructions EtherCAT                                  | Wiring instructions for EtherCAT networks                                 | DOC121104UMxxEN | Documentation\english\4.Installation Instructions\Wiring Instructions UM xx EN.pdf  |

Table 12: Additional documentation for netHOST as EtherCAT Master

### netHOST as EtherNet/IP Scanner

You also need the following documents if you are using an **NHST-T100-EN/EIM**, respectively **NHST-T100-EN** device with loaded EtherNet/IP Scanner firmware:

| Title  | Contents  | Document ID     | Path on the netHOST Solutions DVD   |
|--|---|-----------------|---|
| Operating Instruction Manual DTM for EtherNet/IP Scanner Devices   | Description of the device type manager for EtherNet/IP Scanner devices  | DOC061201OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \EtherNetIP Scanner\EtherNetIP Scanner DTM OI xx EN.pdf                                    |
| Operating Instruction Manual Generic, Modular Generic DTM from EDS File for non-modular and modular EtherNet/IP Adapter Devices          | Description of the generic, modular generic device type manager from EDS file for non-modular EtherNet/IP Adapter devices and modular EtherNet/IP Adapter devices | DOC100221OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \EtherNetIP Scanner\Adapter Configuration \EtherNetIP Generic Adapter DTM EDS OI xx EN.pdf |
| Operating Instruction Manual Generic DTM for EtherNet/IP Adapter Devices and Modular Generic DTM for modular EtherNet/IP Adapter Devices | Description of the generic device type manager for EtherNet/IP Adapter devices and modular EtherNet/IP Adapter devices  | DOC070203OIxxEN | Documentation\english\1.Software\SYCON.net Configuration Software\Master Configuration \EtherNetIP Scanner\Adapter Configuration \EtherNetIP Generic Adapter DTM OI xx EN.pdf     |

*Table 13: Additional documentation for netHOST as EtherNet/IP Scanner*

## 1.4 Legal notes

### Copyright

© Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying materials (in the form of a user's manual, operator's manual, Statement of Work document and all other document types, support texts, documentation, etc.) are protected by German and international copyright and by international trade and protective provisions. Without the prior written consent, you do not have permission to duplicate them either in full or in part using technical or mechanical methods (print, photocopy or any other method), to edit them using electronic systems or to transfer them. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. Illustrations are provided without taking the patent situation into account. Any company names and product designations provided in this document may be brands or trademarks by the corresponding owner and may be protected under trademark, brand or patent law. Any form of further use shall require the express consent from the relevant owner of the rights.

### Important notes

Utmost care was/is given in the preparation of the documentation at hand consisting of a user's manual, operating manual and any other document type and accompanying texts. However, errors cannot be ruled out. Therefore, we cannot assume any guarantee or legal responsibility for erroneous information or liability of any kind. You are hereby made aware that descriptions found in the user's manual, the accompanying texts and the documentation neither represent a guarantee nor any indication on proper use as stipulated in the agreement or a promised attribute. It cannot be ruled out that the user's manual, the accompanying texts and the documentation do not completely match the described attributes, standards or any other data for the delivered product. A warranty or guarantee with respect to the correctness or accuracy of the information is not assumed.

We reserve the right to modify our products and the specifications for such as well as the corresponding documentation in the form of a user's manual, operating manual and/or any other document types and accompanying texts at any time and without notice without being required to notify of said modification. Changes shall be taken into account in future manuals and do not represent an obligation of any kind, in particular there shall be no right to have delivered documents revised. The manual delivered with the product shall apply.

Under no circumstances shall Hilscher Gesellschaft für Systemautomation mbH be liable for direct, indirect, ancillary or subsequent damage, or for any loss of income, which may arise after use of the information contained herein.

### Liability disclaimer

The hardware and/or software was created and tested by Hilscher Gesellschaft für Systemautomation mbH with utmost care and is made available as is. No warranty can be assumed for the performance or flawlessness of the hardware and/or software under all application conditions and scenarios and the work results achieved by the user when using the hardware and/or software. Liability for any damage that may have occurred as a result of using the hardware and/or software or the corresponding documents shall be limited to an event involving willful intent or a grossly negligent violation of a fundamental contractual obligation. However, the right to assert damages due to a violation of a fundamental contractual obligation shall be limited to contract-typical foreseeable damage.

It is hereby expressly agreed upon in particular that any use or utilization of the hardware and/or software in connection with

- Flight control systems in aviation and aerospace;
- Nuclear fusion processes in nuclear power plants;
- Medical devices used for life support and
- Vehicle control systems used in passenger transport

shall be excluded. Use of the hardware and/or software in any of the following areas is strictly prohibited:

- For military purposes or in weaponry;
- For designing, engineering, maintaining or operating nuclear systems;
- In flight safety systems, aviation and flight telecommunications systems;
- In life-support systems;
- In systems in which any malfunction in the hardware and/or software may result in physical injuries or fatalities.

You are hereby made aware that the hardware and/or software was not created for use in hazardous environments, which require fail-safe control mechanisms. Use of the hardware and/or software in this kind of environment shall be at your own risk; any liability for damage or loss due to impermissible use shall be excluded.

### Warranty

Hilscher Gesellschaft für Systemautomation mbH hereby guarantees that the software shall run without errors in accordance with the requirements listed in the specifications and that there were no defects on the date of acceptance. The warranty period shall be 12 months commencing as of the date of acceptance or purchase (with express declaration or implied, by customer's conclusive behavior, e.g. putting into operation permanently).

The warranty obligation for equipment (hardware) we produce is 36 months, calculated as of the date of delivery ex works. The aforementioned provisions shall not apply if longer warranty periods are mandatory by law pursuant to Section 438 (1.2) BGB, Section 479 (1) BGB and Section 634a (1) BGB [Bürgerliches Gesetzbuch; German Civil Code] If, despite of all due care taken, the delivered product should have a defect, which already

existed at the time of the transfer of risk, it shall be at our discretion to either repair the product or to deliver a replacement product, subject to timely notification of defect.

The warranty obligation shall not apply if the notification of defect is not asserted promptly, if the purchaser or third party has tampered with the products, if the defect is the result of natural wear, was caused by unfavorable operating conditions or is due to violations against our operating regulations or against rules of good electrical engineering practice, or if our request to return the defective object is not promptly complied with.

### **Costs of support, maintenance, customization and product care**

Please be advised that any subsequent improvement shall only be free of charge if a defect is found. Any form of technical support, maintenance and customization is not a warranty service, but instead shall be charged extra.

### **Additional guarantees**

Although the hardware and software was developed and tested in-depth with greatest care, Hilscher Gesellschaft für Systemautomation mbH shall not assume any guarantee for the suitability thereof for any purpose that was not confirmed in writing. No guarantee can be granted whereby the hardware and software satisfies your requirements, or the use of the hardware and/or software is uninterrupted or the hardware and/or software is fault-free.

It cannot be guaranteed that patents and/or ownership privileges have not been infringed upon or violated or that the products are free from third-party influence. No additional guarantees or promises shall be made as to whether the product is market current, free from deficiency in title, or can be integrated or is usable for specific purposes, unless such guarantees or promises are required under existing law and cannot be restricted.

### **Confidentiality**

The customer hereby expressly acknowledges that this document contains trade secrets, information protected by copyright and other patent and ownership privileges as well as any related rights of Hilscher Gesellschaft für Systemautomation mbH. The customer agrees to treat as confidential all of the information made available to customer by Hilscher Gesellschaft für Systemautomation mbH and rights, which were disclosed by Hilscher Gesellschaft für Systemautomation mbH and that were made accessible as well as the terms and conditions of this agreement itself.

The parties hereby agree to one another that the information that each party receives from the other party respectively is and shall remain the intellectual property of said other party, unless provided for otherwise in a contractual agreement.

The customer must not allow any third party to become knowledgeable of this expertise and shall only provide knowledge thereof to authorized users as appropriate and necessary. Companies associated with the customer shall not be deemed third parties. The customer must obligate authorized

users to confidentiality. The customer should only use the confidential information in connection with the performances specified in this agreement.

The customer must not use this confidential information to his own advantage or for his own purposes or rather to the advantage or for the purpose of a third party, nor must it be used for commercial purposes and this confidential information must only be used to the extent provided for in this agreement or otherwise to the extent as expressly authorized by the disclosing party in written form. The customer has the right, subject to the obligation to confidentiality, to disclose the terms and conditions of this agreement directly to his legal and financial consultants as would be required for the customer's normal business operation.

### **Export provisions**

The delivered product (including technical data) is subject to the legal export and/or import laws as well as any associated regulations of various countries, especially such laws applicable in Germany and in the United States. The products / hardware / software must not be exported into such countries for which export is prohibited under US American export control laws and its supplementary provisions. You hereby agree to strictly follow the regulations and to yourself be responsible for observing them. You are hereby made aware that you may be required to obtain governmental approval to export, reexport or import the product.

### **Terms and conditions**

Please read the notes about additional legal aspects on our netIOT web site under <http://www.netiot.com/netiot/netiot-edge/terms-and-conditions/>.

## **1.5 Registered Trademarks**

Adobe Reader® is a registered trademark of the Adobe Systems Incorporated.

CANopen® is a registered trademark of CAN in AUTOMATION - International Users and Manufacturers Group e.V (CiA), Nürnberg.

DeviceNet™ and EtherNet/IP™ are trademarks of ODVA (Open DeviceNet Vendor Association, Inc).

EtherCAT® is a registered trademark and a patented technology of Beckhoff Automation GmbH, Verl, Federal Republic of Germany, formerly Elektro Beckhoff GmbH.

PROFIBUS® and PROFINET® are registered trademarks of PROFIBUS & PROFINET International (PI), Karlsruhe.

Windows® XP, Windows® Vista, Windows® 7 and Windows® 8 are registered trademarks of Microsoft Corporation.

All other mentioned trademarks are property of their respective legal owners.

## 2 Safety

### 2.1 General note

The user manual, the accompanying texts and the documentation are written for the use of the products by educated personnel. When using the products, all safety instructions and all valid legal regulations have to be obeyed. Technical knowledge is presumed. The user has to assure that all legal regulations are obeyed.

### 2.2 Intended use

The netHOST devices described in this manual are communication devices which connect a TCP/IP network to a fieldbus or Real-Time Ethernet network. The netHOST devices thus serve as “gateways” between the two networks.

The netHOST devices are in a compact housing and suitable for DIN rail mounting according to DIN EN 60715.

### 2.3 Personnel qualification

The netHOST devices must only be installed, configured and removed by qualified personnel. Job-specific technical skills for people professionally working with electricity must be present concerning the following topics:

- Safety and health at work
- Mounting and attaching of electrical equipment
- Measurement and analysis of electrical functions and systems
- Evaluation of the safety of electrical systems and equipment
- Installing and configuring IT

### 2.4 Safety references

|      |  |
|------|--|
| [S1] | ANSI Z535.6-2011 American National Standard for Product Safety Information in Product Manuals, Instructions, and Other Collateral Materials  |
| [S2] | DIN EN 62368-1: 2016-05, Audio/video, information and communication technology equipment - Part 1: Safety requirements (IEC 62368-1: 2014, modified + Cor.:2015); German version EN 62368-1: 2014 + AC: 2015 |
| [S3] | EN 61340-5-1 and EN 61340-5-2 as well as IEC 61340-5-1 and IEC 61340-5-2   |

## 2.5 Safety instructions to avoid personal injury

To ensure your own personal safety and to avoid personal injury, you must read, understand and follow the safety instructions and all safety messages in this manual about danger that might cause personal injury, before you install and operate your netHOST device.

### 2.5.1 Danger of unsafe system operation

To prevent personal injury, make sure that the removal of the device from your plant during operation will not affect the safe operation of the plant.

## 2.6 Safety instructions to avoid property damage

To avoid property damage to your system or to the netHOST device, you must read, understand and follow the safety instructions and all safety messages in this manual about danger that might cause property damage, before you install and operate your netHOST device.

### 2.6.1 Device destruction by exceeding allowed supply voltage

Observe the following notes concerning the supply voltage:

- The netHOST may only be operated with the specified supply voltage. Make sure that the limits of the allowed range for the supply voltage are not exceeded.
- A supply voltage above the upper limit can cause severe damage to the netHOST!
- A supply voltage below the lower limit can cause malfunction of the netHOST.

The allowed range for the supply voltage is specified in the section *Technical data of the netHOST devices* [▶ page 62].

### 2.6.2 Danger of unsafe system operation

To prevent property damage, make sure that the removal of the device from your plant during operation will not affect safe operation of the plant.

## 2.7 Labeling of safety messages

In this document the safety instructions and property damage messages are designed according both to the internationally used safety conventions as well as to the **ANSI Z535** standard.

- The **Section Safety Messages** at the beginning of a chapter are pinpointed particularly and highlighted by a signal word according to the degree of endangerment. The kind of danger is specified exactly by the safety message text and optionally by a specific safety sign.
- The **Integrated Safety Messages** embedded in operating instructions are highlighted by a signal word according to the degree of endangerment. In the safety message, the nature of the hazard is indicated.

### Signal words and safety signs in safety messages on personal injury

| Signal word  | Meaning  |
|--|--|
|  <b>DANGER</b>  | Indicates a direct hazard with high risk, which will have as consequence death or grievous bodily harm if it is not avoided.       |
|  <b>WARNING</b> | Indicates a possible hazard with medium risk, which will have as consequence death or (grievous) bodily harm if it is not avoided. |
|  <b>CAUTION</b> | Indicates a minor hazard with medium risk, which could have as consequence personal injury if it is not avoided.                   |

Table 14: Signal words in safety messages on personal injury

| Safety sign   | Sort of warning or principle         |
|---|--------------------------------------|
|  | Warning of lethal electrical shock   |
|  | Principle: Disconnect the power plug |

Table 15: Safety signs in messages on personal injury

### Signal words and safety signs in safety messages on property damage

| Signal word   | Meaning                             |
|---------------|-------------------------------------|
| <b>NOTICE</b> | Indicates a property damage message |

Table 16: Signal words in safety messages on property damage

| Safety sign   | Sort of warning or principle                          |
|---|---|
|  | Warning of property damage by electrostatic discharge |

Table 17: Safety signs in safety messages on property damage

## 3 Description

### 3.1 Functionality

The Hilscher netHOST is a communication device that connects a TCP/IP network to a fieldbus or Real-Time Ethernet (RTE) network. The netHOST device has a compact housing and is suited for DIN rail mounting according to DIN EN 60715.

The netHOST device allows you to access data of a fieldbus or Real-Time Ethernet network from your PC, terminal or other host system via TCP/IP. Thus, the device serves as a gateway, respectively programming interface between your PC/terminal/host system and the fieldbus or RTE network. Once configured, the netHOST device controls the secondary network on its own.

An appropriate application program establishes the TCP/IP connection to the device and accesses the data of the fieldbus/RTE network.

Access to the netHOST device takes place according to the "Ethernet Marshalling" procedures, by which locally generated service requests of an initiator (i. e. the host application) are being transmitted to a receiver (i. e. the netHOST device) by an appropriate method (i. e. coded/decoded in Ethernet telegrams). The service requests are then called and executed "remotely" on the netHOST device.

The host system can be based on a Windows operating system, but is, however, not restricted to Windows only. For Windows developers, the netHOST Solutions DVD provides the code with the Ethernet Marshalling function both as C++ source code and as Windows DLL (netXTransport.dll). For developers of embedded systems, the DVD provides a C source code which is independent from any specific type of operating system.

**Important:**

The Ethernet LAN connection to the netHOST device is not protected by password or encryption. Protection against unauthorized access by external networks has to be ensured by using adequate measures !

---

The following figure illustrates the data flow of “Ethernet Marshalling” with the netHOST:




Figure 1: Data flow of LAN controlled netHOST device

## 3.2 Device types

### Devices with preloaded firmware

LAN controlled netHOSTs are currently available as **master devices** for the following protocols:

- PROFIBUS DP (**NHST-T100-DP/DPM**),
- CANopen (**NHST-T100-CO/COM**),
- DeviceNet (**NHST-T100-DN/DNM**),
- PROFINET IO (**NHST-T100-EN/PNM**),
- EtherCAT (**NHST-T100-EN/ECM**),
- EtherNet/IP (**NHST-T100-EN/EIM**)

netHOSTs acting as **slave devices** in the secondary network are not yet available.

All devices listed above are delivered with their firmware and master license already loaded.

### Device for loadable firmware

To allow users of Real-Time Ethernet system more flexibility, Hilscher also offers the device

- **NHST-T100-EN**

which has the same hardware and performance as the other netHOST devices for Real-Time Ethernet listed above (**NHST-T100-EN/PNM/ECMEIM**), but it is not delivered with preloaded firmware. For this device, the product DVD provides firmware files for the

- PROFINET IO Controller,
- EtherCAT Master and
- EtherNet/IP Scanner

protocols, which can be chosen and downloaded to the **NHST-T100-EN** by the user himself, the device supporting each of these three protocols. To act as a master, the **NHST-T100-EN** also needs the **NXLIC-Master** license. If you order the **NHST-T100-EN** together with the **NXLIC-Master** license (order no. **8211.000**), the device will be delivered with an already installed and activated master license – you will thus only have to download the chosen firmware file.

A belated ordering and downloading of a master license after device delivery is also possible, information on this can be found in the operating instruction manual *Configuration of LAN controlled master devices – netHOST*.

### 3.3 Interfaces

All interfaces are easily accessible at the front of the netHOST device. In addition to the necessary network interfaces, every device is also equipped with a USB interface (protected by a cover) and an SD memory card slot. The USB and SD memory card interfaces can be used to perform a firmware recovery or to reset the device to its “factory settings” (see chapter *Firmware-Recovery* [▶ page 45]).

#### netHOST for Fieldbus systems

The netHOST devices **NHST-T100-DP/DPM**, **NHST-T100-CO/COM** and **NHST-T100-DN/DNM** are equipped with two RJ45 sockets on the left side (**X2**), in order to connect the device to the LAN network by which the netHOST is controlled/marshalled. The interface for the Fieldbus (i. e. the secondary network), which is to be controlled by the netHOST, is located on the right side of the device (**X3**) and consists of a PROFIBUS DP, CANopen or DeviceNet interface and the appropriate fieldbus connector hardware (according to the device type).

The following figure shows the NHST-T100-DP/DPM netHOST device:




Figure 2: netHOST for Fieldbus: NHST-T100-DP/DPM (example)

### netHOST for Real-Time Ethernet systems

The netHOST devices **NHST-T100-EN**, **NHST-T100-EN/PNM**, **NHST-T100-EN/ECM** and **NHST-T100-EN/EIM** are equipped with three RJ45 sockets. The two RJ45 sockets for the Real-Time Ethernet system, which is to be controlled by the netHOST, are located on the left side of the device (**X2**). A single RJ45 socket for the LAN network, by which the netHOST is controlled/marshalled, is located on the right side of the device (**X3**).




Figure 3: netHOST for RTE systems

## 4 Requirements

### Technical requirements

- The netHOST device is to be mounted on a DIN rail according to DIN EN 60715.
- A suitable external power supply is required.
- The voltage to be applied must be in the allowed range  $24\text{ V} \pm 6\text{ V DC}$ .
- The power supply must be able to deliver at least a current of 130 mA at 24 V.
- Power supply is to be connected at the X1 connector located on the upper side of the device (see section *Positions of the LEDs, connectors and control elements* [▶ page 31]).

---

### NOTICE

#### Device Destruction by Exceeding Allowed Supply Voltage!

The voltage must not exceed 30 V, otherwise the device may be destroyed or damaged.

---

In order to avoid damage caused by overheating or freezing, it is necessary that the temperature of the device does not exceed the limits of the allowed temperature range. For the allowed temperature, see section *Technical data of the netHOST devices* [▶ page 62].

### General requirements

Additionally, the following preconditions must be met in order to operate the netHOST device successfully:

- If you are using an **NHST-T100-EN** netHOST device (order no. 1890.800) you must download the firmware to the device before commissioning/configuring the netHOST.
- An IP address must be assigned to the netHOST device (by default/factory setting, the IP address of the netHOST is 0.0.0.0).
- The netHOST device must be properly configured with the SYCON.net configuration software. The configuration needs to be downloaded to the device. As an alternative, the netHOST can also be configured by the accessing host system.



For detailed information on how download firmware to the **NHST-T100-EN** device and how to configure all netHOST devices with SYCON.net, see Operating Instruction Manual *Configuration of LAN controlled master devices – netHOST*, DOC130402OIxxEN, stored on the netHOST Solutions DVD in the Documentation\english \1.Software\SYCON.net directory.

---

### Requirements for using the SYCON.net configuration software

For installing and operating the SYCON.net configuration software, you need the following:

- PC with 1 GHz processor or higher
- Windows® XP SP3, Windows® Vista (32 bit) SP2, Windows® 7 (32 bit) SP1, Windows® 7 (64 bit) SP1, Windows® 8 (32 bit) or Windows® 8 (64 bit)
- Administrator privilege required for installation
- Internet Explorer 5.5 or higher
- Free disk space: min. 400 MByte
- DVD ROM drive
- RAM: min. 512 MByte, recommended 1024 MByte
- Graphic resolution: min. 1024 x 768 pixel
- Keyboard and Mouse
- Ethernet interface

**Note:**

If the project file is saved and opened again or it is used on another PC, the system requirements need to match. Particularly the DTMs need to be installed on the used PC.

---

### Restrictions


Touch screen is not supported.

## 5 Device drawings and connectors


### 5.1 Dimensioned drawings

The outer dimensions are identical for all types of netHOST devices.

Side view:



Front view:



Power supply plug:




Table 18: Dimensioned drawing, example NHST-T100-DP




**Important:**

When planning the installation of the netHOST device, take into account that there must be enough head room above the device to allow for convenient plugging and unplugging of the power supply.

## 5.2 Positions of the LEDs, connectors and control elements


### 5.2.1 netHOST for Fieldbus systems

The following figure depicts LEDs, connectors and control elements of the netHOST for Fieldbus systems. The left part of each netHOST is identical for all device types, the right part differs according to fieldbus type.



- (1) Connector for supply voltage (X1)
- (2) Slot for SD memory card (part number 1719.003)
- (3) Address switch (factor 10), can be monitored in the system information block.
- (4) Address switch (factor 1), can be monitored in the system information block.
- (5) SYS LED (system status)
- (6) APL LED (application status)
- (7) Mini USB service interface (protected by a cover)
- (8) LINK LED for LAN channel 0
- (9) LAN interface channel 0 (X2, RJ45 socket)
- (10) ACT LED for LAN channel 0 (activity)
- (11) LINK LED for LAN channel 1
- (12) LAN interface channel 1 (X2, RJ45 socket)
- (13) ACT LED for LAN channel 1 (activity)
- (14) **LED communication status of fieldbus**  
 PROFIBUS DP Master (NHST-T100-DP):  
**COM**  
 CANopen Master (NHST-T100-CO):  
**CAN**  
 DeviceNet Master (NHST-T100-DN):  
**MNS**
- (15) **Fieldbus interface (X3)**  
 PROFIBUS DP Master (NHST-T100-DP):  
 Dsub 9-pole female  
 CANopen Master (NHST-T100-CO):  
 Dsub 9-pole male  
 DeviceNet Master (NHST-T100-DN):  
 COMBICON 5-pole

NHST-T100-DP




NHST-T100-CO

NHST-T100-DN

Table 19: LEDs, connectors and operating elements of netHOST for Fieldbus systems

### 5.2.2 netHOST for Real-Time Ethernet systems

The following figure depicts LEDs, connectors and control elements of the netHOST for Real-Time Ethernet systems.



NHST-T100-EN

- (1) Connector for supply voltage (X1)
- (2) Slot for SD memory card (part number 1719.003)
- (3) Push button without function
- (4) SYS LED (system status)
- (5) APL LED (application status)
- (6) Mini USB service interface (protected by a cover)
- (7) Protocol specific LED  
for PROFINET IO Controller: **SF**  
for EtherCAT Master: **RUN**  
for EtherNet/IP Scanner: **MS**
- (8) Protocol specific LED  
for PROFINET IO Controller: **BF**  
for EtherCAT Master: **ERR**  
for EtherNet/IP Scanner: **NS**
- (9) LINK LED for Real-Time Ethernet channel 0
- (10) Real-Time Ethernet interface channel 0 (X2, RJ45 socket)
- (11) ACT LED for Real-Time Ethernet channel 0 (activity)
- (12) LINK LED for Real-Time Ethernet channel 1
- (13) Real-Time Ethernet interface channel 1 (X2, RJ45 socket)
- (14) ACT LED for Real-Time Ethernet channel 1 (activity)
- (15) LINK LED for LAN interface
- (16) LAN interface (X3, RJ45 socket)
- (17) ACT LED for LAN interface (activity)

Table 20: LEDs, connectors and operating elements of netHOST for RTE systems

### 5.3 Protocol logo and LED label sticker

Each netHOST with preloaded firmware is delivered with the appropriate protocol logo and LED labels already attached to the device. In case of the **NHST-T100-EN** device (for which the appropriate firmware has to be loaded into the device by the customer) label stickers for the supported master protocols for PROFINET IO, EtherCAT and EtherNet/IP are included in the delivery package, and can be attached to the device by the customer:


| PROFINET IO   | EtherCAT  | EtherNet/IP  |
|---|---|--|
|  |  |  |

Table 21: Sticker for NHST-T100-EN

### 5.4 Device label




Table 22: Device label (NHST-T100-DP example)

### 5.5 Power supply connector (X1)

For identification, see position (1) in section *Positions of the LEDs, connectors and control elements* [▶ page 31].

The power supply of the netHOST has to be connected to connector X1. The power supply voltage must be in the range between 18 V and 30 V DC.


| Supply voltage  | Pin | Signal    | Description              |
|---|-----|-----------|--------------------------|
|  | 1   | 0 V / GND | Ground of supply voltage |
|   | 2   | 24 V      | +24 V supply voltage     |
| Mini Combicon   |     |           |                          |

Table 23: Pin assignment Mini Combicon socket 2-pole



**Note:**

The power supply plug is included in the delivery. If needed as a spare part, the plug can be obtained from RIA CONNECT GmbH in Blumberg, Germany, part number: 31369102-001792.

## 5.6 Ethernet connectors

This section describes the technical details of the LAN and Real-Time Ethernet connectors of the netHOST devices. The details are valid for the LAN interface featured by all netHOST types and for the RTE interface featured only by the netHOST devices for Real-Time Ethernet systems.

For identification of the LAN connector of the **netHOST for Fieldbus systems**, see positions (9) and (12) in section *netHOST for Fieldbus systems* [▶ page 31].

For identification of the LAN connector of the netHOST for Real-Time Ethernet systems, see position (16), for identification of the RTE connectors, see positions (10) and (13) in section *netHOST for Real-Time Ethernet systems* [▶ page 32].

The Ethernet interfaces (LAN and RTE) use RJ45 sockets, with twisted pair cables of category 5 (CAT5) or higher, consisting of four twisted pairs. The maximum baud rate is 100 MBit/s (CAT5).



### Note:

The device supports Auto Crossover function. Due to this fact, RX and TX can be switched. The following figure shows the RJ45 standard pinning.

| Ethernet | Pin | Signal | Description  |
|----------|-----|--------|--|
|          | 1   | TX+    | Transmit data positive                             |
|          | 2   | TX-    | Transmit data negative                             |
|          | 3   | RX+    | Receive data positive                              |
|          | 4   | Term 1 | Connected and terminated to PE via RC combination* |
|          | 5   | Term 1 |  |
|          | 6   | RX-    | Receive data negative                              |
|          | 7   | Term 2 | Connected and terminated to PE via RC combination* |
|          | 8   | Term 2 |  |
|          |     |        | * Bob Smith Termination                            |

Table 24: Ethernet RJ45 pin assignment



If you are using the NHST-T100-EN/ECM for EtherCAT, please note also the user manual *Wiring Instructions EtherCAT*, DOC121104UMxxEN, stored on the netHOST Solutions DVD in the Documentation\english\4.Installation Instructions directory.

## 5.7 Fieldbus interfaces (X3)

For identification, see position (15) in section *netHOST for Fieldbus systems* [▶ page 31].



Information on fieldbus cabling can be found in the user manual *Wiring Instructions*, DOC120208UMxxEN, stored on the netHOST Solutions DVD in the Documentation\english\4.Installation Instructions directory.

### 5.7.1 PROFIBUS DP interface (NHST-T100-DP/DPM)

The PROFIBUS DP interface at X3 is a RS-485 interface according to PROFIBUS standard EN 50170.

| PROFIBUS                           | Pin    | Signal  | Description  |
|------------------------------------|--------|---------|--|
| <p>9-pole sub-D socket, female</p> | 3      | Rx/Tx + | Receive- / Transmit data positive  |
|                                    | 4      | CNTR-P  | Control signal for repeater (direction control)                            |
|                                    | 5      | ISO GND | Data ground  |
|                                    | 6      | VP      | Power supply positive 5V for terminating resistor. Maximum current 100 mA. |
|                                    | 8      | Rx/Tx - | Receive- / Transmit data negative  |
|                                    | Shield | PE      | Metal shell on PE  |
|                                    |        |         |  |

Table 25: PROFIBUS RS-485 pin assignment

A pull up resistor of 100 kΩ is connected inside the device at “Rx / Tx +”.

A pull down resistor of 100 kΩ is connected inside the device at “Rx / Tx -”.

### 5.7.2 CANopen interface (NHST-T100-CO/COM)

The CANopen interface at X3 is an ISO 11898 interface according to the CANopen CiA DS 102 standard.

| CANopen                  | Pin              | Signal  | Description  |
|--------------------------|------------------|---------|--|
| <p>9-pole sub-D male</p> | 2                | CAN L   | CAN Low bus line   |
|                          | 3                | ISO GND | CAN ground   |
|                          | 7                | CAN H   | CAN High bus line  |
|                          | 1, 4, 5, 6, 8, 9 |         | <b>Important note and strongly recommended:</b> Leave these pins unconnected! Otherwise there is a high risk of a device damage. |
|                          | Shield           | PE      | Metal shell on PE  |

Table 26: CANopen pin assignment

### 5.7.3 DeviceNet interface (NHST-T100-DN/DNM)

The pin assignment of the DeviceNet interface at X3 complies with the DeviceNet standard.


| DeviceNet   | Pin | Signal  | Description                              |
|---|-----|---------|--|
| <br>COMBICON<br>socket, female | 1   | ISO GND | Common ground<br>DeviceNet-power supply. |
|   | 2   | CAN L   | CAN Low signal                           |
|   | 3   | Drain   | Shield                                   |
|   | 4   | CAN H   | CAN High signal                          |
|   | 5   | V+      | +24 V DeviceNet-power supply             |

Table 27: DeviceNet pin assignment

### 5.8 USB interface (Mini-B USB)

For identification, see section *Positions of the LEDs, connectors and control elements* [▶ page 31].

The USB interface can be used to perform a firmware download/firmware recovery to the netHOST device to its “factory settings” (see section *Using USB to recover firmware* [▶ page 47]).


| USB Buchse  | Pin    | Signal  | Description                                  |
|---|--------|---------|--|
|  | 1      | USB_EXT | Power supply USB Bus (+5 V, from externally) |
|   | 2      | D-      | Data -                                       |
|   | 3      | D+      | Data +                                       |
|   | 4      | ID      |  |
|   | 5      | GND     | Ground                                       |
|   | Shield | PE      | Metal shell to PE                            |

Table 28: Pin assignment Mini-B USB connector (5-pin)

### 5.9 Schematic diagram of Galvanic isolation

The following schematic diagram illustrates the internal connections between the different connectors X1, X2 and X3 of the netHOST device. This gives you the chance to properly install the device in accordance with the “potential equalization concept” of your plant.



**Note:**

The PE connection (potential equalization) of the device is done via the DIN rail.

### 5.9.1 netHOST for Fieldbus systems

Galvanic isolation of the netHOST devices **NHST-T100-DP/DPM**, **NHST-T100-CO/COM** and **NHST-T100-DN/DNM**.




Figure 4: Galvanic isolation of netHOST for Fieldbus systems

The device has three galvanically isolated areas. The isolation to the network connections is indicated by the red arrow **(A)**.

- (1) System area, galvanically coupled with the power supply connection at X1.
- (2) LAN connecting area, 2 \* RJ45.  
(The figure above shows only one RJ45 socket. The second RJ45 socket is built up identically and connected to the logic at netX X2.)
- (3) Fieldbus connecting area with DSub male / female or Combicon-connector.

The following table shows the characteristics of the galvanic isolation of the different areas and coupling against potential equalization:

| Area Connection | Interface                | galv. Isolation | Coupling | Coupling against PE potential | Functional earthing to PE                          |
|-----------------|--------------------------|-----------------|----------|-------------------------------|--|
| (1)<br>X1       | -                        | no              | Cx1 (1)  | 4 * 10 nF 500V                |  |
|                 |                          |                 | HF (1)   | Cf = 10 nF, Lf = 47 µH        |  |
| (2)<br>X2       | Ethernet                 | inductive       | Cx2 (2)  | 4 * 75 Ω, 1 nF 2000 V         | Directly via the metal connection of RJ 45 sockets |
| (3)<br>X3       | CANopen (NHST-T100-CO)   | optically       | Cx3 (3)  | 1 MΩ // 15 nF 1000V           | directly   |
|                 | PROFIBUS (NHST-T100-DP)  | inductive       | Cx3 (3)  | 1 MΩ // 2.2 nF 1000 V         | directly   |
|                 | DeviceNet (NHST-T100-DN) | optically       | Cx3 (3)  | 1 MΩ // 15 nF 1000V           | 1 MΩ // 15 nF 1000V                                |

Table 29: Coupling of netHOST for Fieldbus systems

### 5.9.2 netHOST for RTE systems

Galvanic isolation of the netHOST devices **NHST-T100-EN**, **NHST-T100-EN/PNM**, **NHST-T100-EN/ECM** and **NHST-T100-EN/EIM**.




Figure 5: Galvanic isolation of netHOST for RTE systems

The device has three galvanically isolated areas. The isolation to the network connections is indicated by the red arrow **(A)**.

- (1) System area, galvanically coupled with the power supply connection at X1.
- (2) LAN connection area, 2 \* RJ45.  
(The figure above shows only one RJ45 socket. The second RJ45 socket is built up identically and connected to the logic at netX X2.)
- (3) LAN connection area 1 \* RJ45

The following table shows the characteristics of the galvanic isolation of the different areas and coupling against potential equalization:

| Area Connection | Interface          | galv. Isolation | Coupling | Coupling against PE potential | Functional earthing to PE                          |
|-----------------|--------------------|-----------------|----------|-------------------------------|--|
| (1)<br>X1       | -                  | no              | Cx1 (1)  | 4 * 10 nF 500V                |  |
|                 |                    |                 | HF (1)   | Cf = 10 nF, Lf = 47 μH        |  |
| (2)<br>X2       | Real-Time Ethernet | inductive       | Cx2 (2)  | 4 * 75 Ω, 1 nF 2000 V         | Directly via the metal connection of RJ 45 sockets |
| (3)<br>X3       | Ethernet           | inductive       | Cx3 (3)  | 4 * 75 Ω, 1 nF 2000 V         | Directly via the metal connection of RJ 45 socket  |

Table 30: Coupling of netHOST for RTE systems

## 6 Mounting and dismounting of netHOST device

### 6.1 Safety messages

Please observe the following safety messages:

---

**NOTICE****Device Destruction Due to Compensating Currents !**

Please pay attention to the grounding and shielding concept of your plant. The concept should prevent the flowing of compensating currents via signal and power supply lines between the used devices. Otherwise device destruction of the netHOST is possible.

---

---

**NOTICE****Device Destruction Due to Overheating !**

The air ventilation slots of the netHOST device must not be covered by any objects. Otherwise the device might overheat.

---


**Important:**

On the top side, the devices should have a minimum distance of 20 mm to the next device.

---

## 6.2 Mounting netHOST device onto Top Hat Rail

- The netHOST device is to be mounted onto a horizontally attached top hat rail according to DIN EN 60715.
- The rail has to be connected with the potential equalization conductor (PE).
- The devices can be mounted onto the top hat rail side-by-side without any gap.



- (1) ➤ Push the device onto the top hat rail from above.
- (2) ➤ Then press the device against the mounting surface.

Table 31: Mounting the netHOST device onto Top Hat Rail

- After mounting, connect the 24 V supply voltage to the device.

---

### NOTICE

#### Device Destruction by Exceeding the Allowed Supply Voltage!

The supply voltage must not exceed 30 V, otherwise the netHOST device will be damaged.

---




#### Note:

Grounding is done via a grounding contact located at the backside of the device, connecting it electrically to the DIN top hat rail.

---

## 6.3 Removing netHOST device from the Top Hat Rail

In order to remove the netHOST from the top hat rail, first remove the power supply cable and all data cables from the device.



- (1) ➤ To release the device from the top hat rail, put a screw driver to the clip located on the bottom in the middle of the device.
- (2) ➤ To disengage the lock from the top hat rail, press the screw driver upwards.
- (3) ➤ You can then easily pull the device off the top hat rail.

Table 32: Removing the netHOST device from Top Hat Rail

## 7 Commissioning

### 7.1 Firmware

With the exception of the **NHST-T100-EN** device (order no.: 1890.800), all netHOST devices are delivered with their firmware already loaded. Thus, you can instantly install, configure and commission the netHOST after delivery. You will find a short summarizing description about configuration in the following section, for detailed instructions and examples see the operating instruction manual *Configuration of LAN controlled master devices – netHOST*.

If you are using the **NHST-T100-EN** device, you first have to download the firmware featuring the Real-Time Ethernet master protocol (PROFINET IO, EtherCAT or EtherNet/IP) to the device with the **SYCON.net** configuration software. Detailed instructions on this can be found in the operating instruction manual *Configuration of LAN controlled master devices – netHOST*. Once you have downloaded the firmware to the **NHST-T100-EN** device, all following configurational steps are same as for the devices with preloaded firmware as described in the operating instruction manual.

### 7.2 Configuring the netHOST

#### **Assigning IP address with Ethernet Device Configuration Tool**

A netHOST device is delivered without its Fieldbus or Real-Time Ethernet configuration and answers at its LAN interface with the default IP address 0.0.0.0.

Before the netHOST device can be configured (in case of the **NHST-T100-EN**, before the firmware can be downloaded to the device), a valid IP address has to be assigned to the netHOST. Use the **Ethernet Device Configuration Tool** for this. The IP address of the device must be in the same sub net as the IP address of the configuration PC, so that it can later be reached for configuration.

Note, that the IP address assigned by the **Ethernet Device Configuration Tool** is kept by the netHOST device only until next power-on cycle or device reset, respectively until a permanent IP address has been configured and downloaded to the device with SYCON.net.

### Configuration with SYCON.net

The netHOST device is configured with the Windows configuration software SYCON.net. The configuration is transferred to the netHOST device via LAN connection and TCP/IP protocol (primary network, in case of netHOST devices for Fieldbus systems connected to the X2 interface, in case of netHOST devices for RTE systems to the X3 interface).

SYCON.net allows you to create a configuration “offline”, without any immediate connection to the target device (i. e. the netHOST). Only for the subsequent download of the configuration into the device, you need a physical LAN connection.

The SYCON.net configuration consists of the IP address and the fieldbus or Real-Time Ethernet configuration. The device stores this data remanently, i. e. the data is being kept after power off or device reset.

After updating the firmware of the netHOST device with SYCON.net, the device loses its configuration and its IP address. The device then answers with its default IP address 0.0.0.0 again.



Detailed information about configuration, diagnosis, testing and firmware update can be found in the operating instruction manual *Configuration of LAN controlled master devices – netHOST*, DOC1304020lxxEN, stored on the netHOST Solutions DVD in the `Documentation\english\1.Software\SYCON.net` directory.

---

## 7.3 Start-up behavior

After a return of power or device reset, the start-up behavior of the netHOST device depends on whether at the time of power return an SD memory card is inserted in the device or not.

### 7.3.1 Start-up without SD memory card

If no card is inserted at the time of power return or reset, the firmware and configuration data (if available) stored permanently in the internal load memory is loaded and started. This can take approximately four seconds, depending on the size of the configuration data.

### 7.3.2 Start-up with inserted SD memory card

If an SD memory card containing a valid configuration is inserted in the netHOST device at the time of power on, all data stored on the card is copied to the internal load memory of the device.

This data can be:

- firmware
- configuration files
- IP address

All old data stored in the load memory will be erased by this.

With this procedure, you can reset the device to its factory settings or load the desired configuration without having to establish a LAN connection to the SYCON.net configuration software. With the SD card, you can easily “clone” a configuration and transfer it into another device, e. g. into a spare device in case of a defective primary device.

With the SYCON.net configuration software, the data of the internal load memory of the netHOST device can be copied to an empty SD memory card. Note that the SD card must be FAT16 formatted, otherwise it will not be recognized by the device.



Detailed instructions on how to transfer configuration data into another netHOST device by SD memory card can be found in chapter *Using SD Memory Card to Copy Configuration Data to Spare netHOST Devices* in the operating instruction manual *Configuration of LAN controlled master devices – netHOST*, DOC1304020IxxEN.

---

Resetting the netHOST device to its factory settings by using an SD memory card (e. g. in case of a defective firmware) is described in the subsequent chapter.

## 8 Firmware recovery

### 8.1 Overview

If after power-on the SYS LED (for the position of the SYS LED see section *Positions of the LEDs, connectors and control elements* [▶ page 31]) is flashing yellow and green at a rate of 1 Hz, the device is in boot mode. The firmware file of the netHOST device is missing or defective. In this state the device cannot be operated and a new firmware file needs to be loaded into the device either via SD memory card or via USB. When using the SD memory card, all existing configuration or IP address files inside the device will be deleted. The device will thus be reset to its “factory settings”. On the other hand, when using the firmware download function via USB, you can overwrite only the old defective firmware file and keep the configuration files inside the device, thus performing only a “firmware recovery” instead of a “factory reset”. When using USB, you can decide for yourself, whether you also want to delete the configuration files in order to perform a full “factory reset”.

### 8.2 Using an SD memory card to reset the netHOST to its “factory settings”

The netHOST device can be reset to its factory settings by using the load memory image on an SD memory card. You will find the load memory image on the netHOST Solutions DVD in the `Supplements & Examples \netHOST Device Recovery\Recovery via Memory Card` directory in the folder of your device type (e. g. `NHST-T100-DP_DPM` folder for the NHST-T100-DP/DPM device). From there, you can copy the image to the SD memory card, and then use the card to copy it to the netHOST device.

All existing old data (including configuration and IP address) in the internal load memory of the device will thereby be deleted. After recovery by SD card, the device therefore needs a new IP address and a new configuration.



---

**Note:**

The SD memory card is not included in the delivery of the netHOST device, but can be obtained from Hilscher. The part number of the card is 1719.003.

---

**Prerequisites**

- Empty SD memory card (FAT16 formatted)
- PC with SD card reader device
- netHOST Solutions DVD
- the netHOST device is supplied with voltage

**Step-by-step instructions**

1. Copy load memory image from DVD to SD card.
  - Insert an empty SD memory card into the SD card reader device of your PC.

- On the netHOST Solutions DVD, open `Supplements & Examples \netHOST Device Recovery\Recovery via Memory Card` directory.
  - In the directory, open the folder for your type of device, e. g. `NHST-T100-DP_DPM`, then copy the `STARTUP.INI` file and the `BACKUP` folder (with all its subfolders) to the root directory of the SD memory card.
  - Remove the SD memory card from the SD card reader device.
2. Copy load memory image to netHOST device.
- Disconnect the voltage supply from your netHOST device.
  - Insert the SD card into the card slot of the netHOST device until it engages (see position (2) in section *Positions of the LEDs, connectors and control elements* [▶ page 31]).
  - Reconnect the voltage supply of your netHOST device.
  - ⇒ The device then loads the memory image. While loading the image, the SYS LED quickly alternates between green and yellow for approximately eight seconds, then shows steady yellow for approximately ten seconds, then is switched off for a short while before it finally shows steady green light. The device automatically starts the loaded firmware.
  - Remove the SD memory card from device.
  - ⇒ The netHOST device has been reset to its factory settings. The device now needs an IP address and a configuration.

## 8.3 Using USB to recover firmware

Via USB, you can reset the netHOST device to its factory settings or, as an alternative, perform a so-called “firmware recovery”, by downloading a new firmware file to the device without thereby deleting any existing configuration files within the device.

For this, you need a USB cable with a Mini USB connector and the Hilscher **ComProX** tool, which is stored on the netHOST Solutions DVD in the `Supplements & Examples\netHOST Device Recovery\Recovery via USB` directory. **ComProX** can be executed directly from DVD, it does not need to be installed on your configuration PC.

Note that for recovery via USB, you need to install the USB driver for the Hilscher netHOST on your configuration PC. This driver allows you to communicate with the netHOST via USB, even if the old firmware within the device is defective or missing altogether.

It is recommended to install the USB driver *before* you connect the netHOST device via USB cable. Use the **setup.exe** driver installation program for this, which is stored on the netHOST Solutions DVD in the `Setups & Drivers\USB Driver` directory.



---

The installation of the USB driver is described in the user manual *Software Installation netHOST Devices*, DOC130501UMxxEN, which is stored on the netHOST Solutions DVD in the `Documentation\english\4.Installation Instructions` directory.

---

Note the following concerning recovery via USB:

Although any old firmware file that may have existed in the netHOST device will be overwritten by downloading the new firmware file (recognizable by the `.NXF` file name extension), all other files stored in the internal load memory of the device remain untouched. This means that any existing configuration (`CONFIG.NXD`) or IP address (`NWID.NXD`) file in the device can be preserved for further use, if needed. However, if you want a complete reset of your device via USB (a complete reset to “factory setting” means that only “fresh” firmware is present in the device), you can delete the configuration and the address files separately in the **Explorer** of the **ComProX** tool.

### Prerequisites

- The USB driver for Hilscher netHOST has been installed on the configuration PC (the driver is included in the USB driver installation program stored on the netHOST Solutions DVD).
- The configuration PC has been connected to the netHOST device via USB cable.
- You have access to the netHOST Solutions DVD.
- The netHOST device is supplied with voltage.

## Step-by-step instructions

1. Open ComProX.
  - On the netHOST Solutions DVD, open Supplements & Examples \netHOST Device Recovery\Recovery via USB directory.
  - Double-click **comproX.exe** file.
  - The **ComProX** tool opens:




Figure 6: ComProX start screen

2. Connect to netHOST device.
  - In the menu, choose **Connection > Open**.
  - After the Windows USB/COM ports have been scanned, the connection selection dialog opens:




Figure 7: ComProX Connection dialog

- Select **Hilscher netHOST** entry, then click **OK**.
  - The connection dialog closes and you are back in start screen of ComProX.
3. Download firmware file.
    - In the menu, choose **Connection > File Explorer**.

➤ The **Explorer** window opens:




Figure 8: ComProX File Explorer

- Under **Filesystem**, select **PORT\_0**.
- The content of PORT\_0 is displayed. This, most likely, will be the old firmware file, which you want to overwrite. If you have already downloaded a configuration to the netHOST, the IP address configuration file (**NWID.NXD**) is also displayed here.
- In the right part of the **Explorer** window, right-click to open the context menu, then choose **Download**.




Figure 9: ComProX Download

➤ The **Choose a file** dialog opens:




Figure 10: Choose a file dialog in ComProX

- Open the folder for your device and select the firmware file you want to download to your device (firmware files can be recognized by the file name extension .NXF).
  - Click **Open**.
  - ⇒ The firmware file is being downloaded to the netHOST device. The old firmware file is being overwritten. This can take a few seconds.
4. Check download.
- In the right part of the **Explorer** window, right-click to open the context menu, then choose **Refresh**.
  - Wait for a few seconds.
  - ⇒ If the download has been successful, the downloaded firmware file is displayed in **Port 0**:



Figure 11: Downloaded firmware in Explorer



**Note:**

If there is an IP address file (**NWID.NXD**) present in **Port\_0** and configuration files (**CONFIG.NXD**) in **Port\_1**, and you do not want to use these configuration files any longer, you can delete them in order to completely reset the device to its “factory settings”. For this, select the configuration file in the **Explorer**, then choose **Delete** command from the context menu.

5. Exit ComProX.
- Close the **Explorer** window.
  - In the menu of ComProX, choose **Connection > Close** to close the connection to the device.
  - Close **ComProX**.
6. Restart netHOST device.
- Disconnect the voltage supply from the netHOST device, then reconnect it.
  - ⇒ After restart, the SYS LED shows steady green light. The state of the APL LED depends on whether a valid configuration is still present in the device. If this is not the case, the APL LED is blinking red.

## 9 Troubleshooting

There are two steps of error diagnosis:

- the initial approximate diagnosis by checking the LEDs of the device,
- the comprehensive diagnosis with the SYCON.net configuration and diagnosis software via LAN connection.

The following overview describes the error conditions that may be detected by checking the LEDs (for identification of the LEDs, please refer to section *Positions of the LEDs, connectors and control elements* [▶ page 31]).



For information on how to diagnose the netHOST device with SYCON.net, see Operating Instruction Manual *Configuration of LAN controlled master devices – netHOST*, DOC130402OixxEN, stored on the netHOST Solutions DVD in the `Documentation\english\1.Software\SYCON.net` directory.

| LED  | LED state  | Cause/remedy  |
|--|--|---|
| All  | No LED is on   | The device is not powered or the device is defective and needs replacement.   |
| <b>SYS</b><br>RTE devices: position (4)<br>Fieldbus devices: position (5)  | <b>SYS</b> LED flashes  yellow/green at 1 Hz  | After a power cycle the device has not found a valid firmware and remains in boot loader mode. The firmware of the device has to be “recovered”. See chapter <i>Firmware-Recovery</i> [▶ page 45]. If recovery fails, the load memory of the device might be defective. |
| <b>SYS</b><br>RTE devices: position (4)<br>Fieldbus devices: position (5)  | <b>SYS</b> LED flashes  yellow  | The device could not be initialized. No boot loader was found in the load memory. The load memory of the device might be defective or a USB cable, which has pin 4 connected with ground, might be attached to the device. This prevents the device from starting.      |
| <b>SYS</b><br>RTE devices: position (4)<br>Fieldbus devices: position (5)  | <b>SYS</b> LED shows static  yellow   | The hardware of the device is defective and needs replacement.  |
| <b>SYS</b><br>RTE devices: position (4)<br>Fieldbus devices: position (5)<br><b>APL</b><br>RTE devices: position (5)<br>Fieldbus devices: position (6) | <b>SYS</b> LED shows static  green and<br><b>APL</b> LED flashes  red or shows static  red. | The device is well initialized. Further diagnosis is possible with the <b>APL</b> LED. See section <i>LED APL</i> [▶ page 53].  |
| <b>APL</b><br>RTE devices: position (5)<br>Fieldbus devices: position (6)  | <b>APL</b> LED flashes  green.  | The communication at port X2 or/and port X3 is not in data exchange mode. See also section <i>LED APL</i> [▶ page 53].  |

Table 33: netHOST troubleshooting by LED

For protocol-specific error diagnostics by LED, see section *LEDs of the Fieldbus and Real-Time Ethernet systems* [▶ page 54].

## 10 LEDs

This chapter describes the meaning of the LEDs of the netHOST device. For identification of the LEDs on the device, please refer to section *Positions of the LEDs, connectors and control elements* [▶ page 31].

### 10.1 SYS LED

This LED indicates basic operating states which are independent of the configuration of the device.

| LED   | Color  | State                          | Meaning  |
|---|--|--------------------------------|--|
| <b>SYS</b><br>RTE devices:<br>position (4)<br>Fieldbus devices:<br>position (5) | <b>Duo LED yellow/green</b>  |                                |  |
|   |  (green)          | On                             | Operating System running. For further diagnosis, see <b>APL</b> LED.   |
|   |  (yellow)         | On                             | The hardware of the device is defective and needs replacement.   |
|   |  (yellow)         | Flashing                       | The device could not be initialized. No boot loader was found in the load memory. The load memory of the device might be defective or a USB cable, which has pin 4 connected with ground, might be attached to the device. This prevents the device from starting. |
|   |  (yellow/green)   | Flashing yellow/green<br>1 Hz  | <b>Error state!</b> Boot loader active. Firmware file is missing or defective. The device needs to be recovered by SD memory card or via USB. See chapter <i>Firmware recovery</i> [▶ page 45].  |
|   |  (yellow/green) | Flashing yellow/green<br>16 Hz | Data is being copied from the SD memory card into the internal load memory.  |
|   |  (off)          | Off                            | Power supply for the device is missing or hardware is defective.   |

Table 34: System LED

## 10.2 APL LED

This LED indicates the communication state of the primary network (Ethernet LAN) and the secondary network (Fieldbus or Real-Time Ethernet), as well as the state of the configuration of the netHOST device.

| LED   | Color   | State  | Meaning  |
|---|---|--|--|
| <b>APL</b><br>RTE devices:<br>position (5)<br>Fieldbus devices:<br>position (6)           | Duo LED red/green   |  |  |
|   |  (green) | On   | The Ethernet cable of the primary network is plugged in at the LAN interface. The netHOST device communicates via secondary network (Fieldbus or Real-Time Ethernet) and exchanges payload data. The netHOST function is executed without error.<br><b>Note:</b> This does not indicate a connection to a host application.  |
|   |  (green) | Blinking with<br>2 s off,<br>0.5 s on  | netHOST is initialized, a valid configuration is present in the device. The netHOST communicates via secondary network, but the LAN interface at the primary network shows no activity.<br>The Ethernet cable has been removed from the LAN interface. Reconnect the cable.  |
|   |  (green) | Blinking with<br>2 s off,<br>0.5 s on,<br>0.5 s off,<br>0.5 s on   | netHOST is initialized, a valid configuration is present in the device. Communication at the secondary network (Fieldbus or Real-Time Ethernet) is not in payload data exchange. <ul style="list-style-type: none"> <li>In the netHOST configuration, the starting mode for communication at the interface of the secondary network is set to “controlled by the host application”, which is the default setting. Please check this setting in the configuration software. Check also, whether or not the start command from the host application has already been issued.</li> <li>netHOST as Fieldbus or Real-Time Ethernet master after start command: The netHOST has no payload data connection to any of the configured slaves.<br/>The configuration of the netHOST might not match the configuration of the slaves or the fieldbus or RTE cable is not connected. Use the SYCON.net configuration software for diagnosis.</li> </ul> |
|  (red) | Blinking with<br>2 s off,<br>0.5 s on   | netHOST is initialized, but the configuration of the primary network (LAN) does not allow communication. <ul style="list-style-type: none"> <li>DHCP mode was configured for the LAN network, but the device has not yet received an IP address from the DHCP server. Check the DHCP server and your configuration.</li> <li>An IP address has been configured, but it conflicts with another IP address already used in the LAN network.</li> <li>Configuration is missing in the netHOST device. Use the SYCON.net configuration software to download the configuration.</li> <li>LAN configuration has an error.</li> </ul> |  |

| LED   | Color   | State  | Meaning  |
|---|---|--|--|
| <b>APL</b><br>RTE devices:<br>position (5)<br>Fieldbus devices:<br>position (6) |  (red) | Blinking with<br>2 s off,<br>0.5 s on,<br>0.5 s off,<br>0.5 s on | netHOST is initialized, but the configuration of the secondary network protocol (Fieldbus or Real-Time Ethernet) does not allow communication. Use the SYCON.net configuration software to download the configuration again. <ul style="list-style-type: none"> <li>• A watchdog timeout error has occurred while the watchdog for host application was active. The Fieldbus or RTE network has been set to operating mode “stop”. Check the LAN connection to the host application. The connection to the host application has to be re-established.</li> <li>• The configuration of the Fieldbus/RTE network has an error.</li> <li>• The configuration of the Fieldbus/RTE network is not complete.</li> <li>• The configuration of the Fieldbus/RTE network is missing.</li> </ul> |
|   |  (red) | On   | netHOST has detected one of the following errors during the initialization: <ul style="list-style-type: none"> <li>• Missing configuration</li> <li>• Error in configuration</li> <li>• Internal sequence error</li> </ul>   |

Table 35: APL LED

## 10.3 LEDs of the Fieldbus and Real-Time Ethernet systems

### 10.3.1 LED PROFIBUS DP Master (NHST-T100-DP/DPM)

The subsequent table describes the meaning of the COM LED of the NHST-T100-DP/DPM netHOST device.

| LED   | Color   | State   | Meaning  |
|---|---|---|--|
| <b>COM</b><br>Position in the<br>device drawing:<br>(14)                                  | <b>Duo LED red/green</b>  |   |  |
|   |  (green) | On  | Communication to all Slaves is established.  |
|   |  (green) | Blinking (5 Hz)   | PROFIBUS is configured, but the bus communication is not yet released from the application.  |
|   |  (green) | Flashing,<br>acyclic                                    | No configuration or faulty configuration   |
|   |  (red)   | Blinking (5 Hz)   | Communication to at least one Slave is disconnected.   |
|   |  (red)   | On  | Communication to all Slaves is disconnected or another serious error has occurred.<br>Redundant Mode: The active Master was not found. |
|  (off) | Off   | Device is not switched on or supply voltage is missing. |  |

Table 36: LED states for the PROFIBUS DP Master protocol

| LEDs states          | Definition  |
|----------------------|---|
| Blinking (5 Hz)      | The indicator turns on and off with a frequency of 5 Hz: “on” for 100 ms, followed by “off” for 100 ms. |
| Flashing,<br>acyclic | The indicator turns on and off in irregular intervals.  |

Table 37: LED state definitions for the PROFIBUS DP Master protocol

### 10.3.2 LED CANopen Master (NHST-T100-CO/COM)

The subsequent table describes the meaning of the CAN LED of the NHST-T100-CO/COM netHOST device:

| LED   | Color   | State   | Meaning   |
|---|---|---|---|
| <b>CAN</b><br>Position in the device drawing:<br>(14)                                   | <b>Duo LED red/green</b>  |   |   |
|   |  (green) | On  | <b>OPERATIONAL:</b> The device is in the OPERATIONAL state.   |
|   |  (green) | Blinking (2.5 Hz)   | <b>PREOPERATIONAL:</b> The device is in the PREOPERATIONAL state.   |
|   |  (green) | Single flash  | <b>STOPPED:</b> The device is in STOPPED state.   |
|   |  (red)   | Single flash  | <b>Warning limit reached:</b> At least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames). |
|   |  (red)   | Double flash  | <b>Error control event:</b> A guard event (NMT Slave or NMT Master) or a heartbeat event (Heartbeat consumer) has occurred.                               |
|   |  (red)   | On  | <b>Bus off:</b> The CAN controller is in bus OFF state.   |
|  (off) | Off   | <b>RESET:</b> The device is executing a reset or the device has no configuration. |   |

Table 38: LED states for the CANopen Master protocol

| LED states        | Definition   |
|-------------------|--|
| Blinking (2.5 Hz) | The indicator turns on and off with a frequency of 2.5 Hz: "on" for 200 ms, followed by "off" for 200 ms.  |
| Single flash      | The indicator shows one short flash (200 ms) followed by a long "off" phase (1,000 ms).  |
| Double flash      | The indicator shows a sequence of two short flashes (each 200 ms), separated by a short "off" phase (200 ms). The sequence is finished by a long "off" phase (1,000 ms). |

Table 39: LED state definitions for the CANopen Master protocol

### 10.3.3 LED DeviceNet Master (NHST-T100-DN/DNM)

The subsequent table describes the meaning of the MNS LED of the NHST-T100-DN/DNM netHOST device:

| LED  | Color  | State                  | Meaning   |
|--|--|------------------------|---|
| <b>MNS</b><br>Position in the device drawing: (14) | <b>Duo LED red/green</b>   |                        |   |
|  |  (green)  | On                     | <b>Device operational AND on-line, connected</b><br>Device is online and has established all connections with all Slaves.   |
|  |  (green)  | Flashing (1 Hz)        | <b>Device operational AND on-line</b><br>Device is online and has established no connection in the established state.<br>- Configuration missing, incomplete or incorrect.  |
|  |   <br>(green/red/off) | Flashing green/red/off | <b>Self-test:</b> The device is performing its power-up testing. The indicator turns green for approximately 250 ms, turns red for approximately 250 ms, and then turns off.  |
|  |  (red)  | Flashing (1 Hz)        | <b>Minor fault and/or connection time-out</b><br>Device is online and has established one or more connections in the established state. It has data exchange with at least one of the configured slaves.<br><br>Minor or recoverable fault: No data exchange with one of the configured Slaves. One or more Slaves are not connected.<br><br>Connection timeout.<br><br>No network power present. |
|  |  (red)   | On                     | <b>Critical fault or critical link failure</b><br>Critical connection failure; device has detected a network error: duplicate MAC-ID or severe error in CAN network (CAN-bus off).  |
|  |  (off)  | Off                    | <b>Device is not powered</b><br>- The device may not be powered.<br><b>Device is not on-line and/or no network power</b><br>- The device has not yet completed the Dup_MAC_ID test.<br>- The device is powered, but the network power is missing.   |

Table 40: LED states for the DeviceNet Master protocol

| LED state              | Definition  |
|------------------------|---|
| Flashing (1 Hz)        | The indicator turns on and off with a frequency of 1 Hz: "on" for 500 ms, followed by "off" for 500 ms. |
| Flashing green/red/off | The indicator turns on green on for 250 ms, then red on for 250 ms, then off.                           |

Table 41: LED state definitions for the DeviceNet Master protocol

### 10.3.4 LEDs PROFINET IO Controller

The subsequent table describes the meaning of the PROFINET IO Controller LEDs of the NHST-T100-EN/PNM, respectively of the NHST-T100-EN with loaded PROFINET IO Controller firmware.

| LED   | Color                    | State                          | Meaning  |
|---|--------------------------|--------------------------------|--|
| <b>SF</b> (System Failure)<br>Position in the device drawing: (7) | <b>Duo LED red/green</b> |                                |  |
|   | ● (off)                  | Off                            | <b>No error</b>  |
|   | ☀ (red)                  | Flashing (1 Hz, 3 s)           | <b>DCP signal service</b> is initiated via the bus.                          |
|   | ☀ (red)                  | Flashing (2 Hz)                | <b>System error:</b> Invalid configuration, Watchdog error or internal error |
| <b>BF</b> (Bus Failure)<br>Position in the device drawing: (8)    | <b>Duo LED red/green</b> |                                |  |
|   | ● (off)                  | Off                            | <b>No error</b>  |
|   | ☀ (red)                  | Flashing (2 Hz)                | <b>Configuration fault:</b> Not all configured IO-Devices are connected.     |
|   | ● (red)                  | On (together with SF "red ON") | <b>No valid Master license</b>   |
| <b>LINK</b><br>Ch0 (9), Ch1 (12)                                  | <b>LED green</b>         |                                |  |
|   | ● (green)                | On                             | The device is linked to the Ethernet.  |
|   | ● (off)                  | Off                            | The device has no link to the Ethernet.                                      |
| <b>RX/TX</b><br>Ch0 (11), Ch1 (14)                                | <b>LED yellow</b>        |                                |  |
|   | ☀ (yellow)               | Flickering (load dependent)    | The device sends/receives Ethernet frames.                                   |
|   | ● (off)                  | Off                            | The device does not send/receive Ethernet frames.                            |

Table 42: LED states for the PROFINET IO-Controller protocol

| LED state                   | Definition   |
|-----------------------------|--|
| Flashing (1 Hz, 3 s)        | The indicator turns on and off for 3 seconds with a frequency of 1 Hz: "on" for 500 ms, followed by "off" for 500 ms.  |
| Flashing (2 Hz)             | The indicator turns on and off with a frequency of 2 Hz: "on" for 250 ms, followed by "off" for 250 ms.  |
| Flickering (load dependant) | The indicator turns on and off with a frequency of approximately 10 Hz to indicate high Ethernet activity: "on" for approximately 50 ms, followed by "off" for 50 ms. The indicator turns on and off in irregular intervals to indicate low Ethernet activity. |

Table 43: LED state definitions for the PROFINET IO-Controller protocol

### 10.3.5 LEDs EtherCAT Master

The subsequent table describes the meaning of the EtherCAT Master LEDs of the NHST-T100-EN/ECM, respectively of the NHST-T100-EN with loaded EtherCAT Master firmware.

| LED   | Color                    | State                       | Meaning  |
|---|--------------------------|-----------------------------|--|
| <b>RUN</b><br>Position in the device drawing: (7) | <b>Duo LED red/green</b> |                             |  |
|   | ● (off)                  | Off                         | <b>INIT:</b> The device is in INIT state.  |
|   | ☀ (green)                | Blinking (2.5 Hz)           | <b>PRE-OPERATIONAL:</b> The device is in PRE-OPERATIONAL state.                                |
|   | ☀ (green)                | Flickering (10 Hz)          | The device is not configured.  |
|   | ☀ (green)                | Single flash                | <b>SAFE-OPERATIONAL:</b> The device is in SAFE-OPERATIONAL state.                              |
|   | ● (green)                | On                          | <b>OPERATIONAL:</b> The device is in the OPERATIONAL state.                                    |
| <b>ERR</b><br>Position in the device drawing: (8) | <b>Duo LED red/green</b> |                             |  |
|   | ● (off)                  | Off                         | Master has no errors   |
|   | ☀ (red)                  | Single flash                | Bus Sync error threshold   |
|   | ☀ (red)                  | Double flash                | Internal Stop of the bus cycle   |
|   | ☀ (red)                  | Triple Flash                | DPM watchdog has expired.  |
|   | ☀ (red)                  | Quadruple Flash             | No Master license present in the device.   |
|   | ☀ (red)                  | Blinking (2.5 Hz)           | Error in the configuration database.   |
|   | ☀ (red)                  | Single Flickering           | Channel Init was executed at the Master.<br>Transient state that may not be visible.           |
|   | ☀ (red)                  | Double Flickering           | Slave is missing<br>Unconfigured slave<br>No matching mandatory slave list<br>No bus connected |
|   | ☀ (red)                  | Flickering (10 Hz)          | Boot-up was stopped due to an error.   |
| <b>LINK</b><br>Ch0 (9)                            | <b>LED green</b>         |                             |  |
|   | ● (green)                | On                          | <b>Link:</b> The device is linked to the Ethernet, but does not send/receive Ethernet frames.  |
|   | ☀ (green)                | Flickering (load dependent) | <b>Activity:</b> The device is linked to the Ethernet and sends/receives Ethernet frames.      |
|   | ● (off)                  | Off                         | The device has no link to the Ethernet.  |
| <b>ACT</b><br>Ch0 (11)                            | <b>LED yellow</b>        |                             |  |
|   | ● (off)                  | Off                         | This LED is not used.  |

Table 44: LED states for the EtherCAT Master(V4) protocol

| LED state       | Definition   |
|-----------------|--|
| Single flash    | The indicator shows one short flash (200 ms) followed by a long "off" phase (1,000 ms).  |
| Double flash    | The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).   |
| Triple Flash    | The indicator shows a sequence of three short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms). |
| Quadruple Flash | The indicator shows a sequence of four short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).  |

| LED state                         | Definition   |
|-----------------------------------|--|
| Blinking<br>(2.5 Hz)              | The indicator turns on and off with a frequency of 2.5 Hz: "on" for 200 ms, followed by "off" for 200 ms.  |
| Single<br>Flickering              | The indicator is switched on and off once:<br>"on" for 50 ms, followed by "off" for 500 ms.  |
| Double<br>Flickering              | The indicator is switched on and off and on once:<br>"on" / "off" / "on" each for approximately 50 ms, followed by "off" for 500 ms.   |
| Flickering<br>(10 Hz)             | The indicator turns on and off with a frequency of 10 Hz: "on" for 50 ms, followed by "off" for 50 ms.   |
| Flickering<br>(load<br>dependent) | The indicator turns on and off with a frequency of approximately 10 Hz to indicate high Ethernet activity: on for approximately 50 ms, followed by off for 50 ms. The indicator turns on and off in irregular intervals to indicate low Ethernet activity. |

*Table 45: LED state definitions for the EtherCAT Master(V4) protocol*

### 10.3.6 LEDs EtherNet/IP Scanner

The subsequent table describes the meaning of the EtherNet/IP Scanner LEDs of the NHST-T100-EN/EIM, respectively of the NHST-T100-EN with loaded EtherNet/IP Scanner firmware.

| LED                                 | Color   | State                       | Meaning  |
|-------------------------------------|---|-----------------------------|--|
| <b>MS</b> (module status)           | <b>Duo LED red/green</b>  |                             |  |
| Position in the device drawing: (7) |  (green)           | On                          | <b>Device operational:</b> The device is operating correctly.  |
|                                     |  (green)           | Flashing (1 Hz)             | <b>Standby:</b> The device has not been configured.  |
|                                     |  (green/red/green) | Flashing green/red/green    | <b>Self-test:</b><br>The device is performing its power-up testing. The module status indicator test sequence occurs before the network status indicator test sequence, according to the following sequence: <ul style="list-style-type: none"> <li>• Network status LED off.</li> <li>• Module status LED turns green for approximately 250 ms, turns red for approximately 250 ms, and again turns green (and holds that state until the power-up test has completed).</li> <li>• Network status LED turns green for approximately 250 ms, turns red for approximately 250 ms, and then turns off (and holds that state until the power-up test has completed).</li> </ul> |
|                                     |  (red)             | Flashing (1 Hz)             | <b>Major recoverable fault:</b> The device has detected a major recoverable fault. E.g., an incorrect or inconsistent configuration can be considered a major recoverable fault.   |
|                                     |  (red)            | On                          | <b>Major unrecoverable fault:</b> The device has detected a major unrecoverable fault.   |
|                                     |  (off)           | (Off)                       | <b>No power:</b> The device is powered off.  |
| <b>NS</b> (Network status)          | <b>Duo LED red/green</b>  |                             |  |
| Position in the device drawing: (8) |  (green)         | On                          | <b>Connected:</b> An IP address is configured, at least one CIP connection (any transport class) is established, and an Exclusive Owner connection has not timed out.  |
|                                     |  (green)         | Flashing (1 Hz)             | <b>No connections:</b> An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out.   |
|                                     |  (green/red/off) | Flashing green/red/off      | <b>Self-test:</b> The device is performing its power-up testing. Refer to description for module status LED self-test.   |
|                                     |  (red)           | Flashing (1 Hz)             | <b>Connection timeout:</b> An IP address is configured, and an Exclusive Owner connection for which this device is the target has timed out.<br><br>The network status indicator returns to steady green only when all timed out Exclusive Owner connections are reestablished.  |
|                                     |  (red)           | On                          | <b>Duplicate IP:</b> The device has detected that its IP address is already in use.  |
|                                     |  (off)           | Off                         | <b>Not powered, no IP address:</b> The device does not have an IP address (or is powered off).   |
| <b>LINK</b>                         | <b>LED green</b>  |                             |  |
| Ch0: (9), Ch1: (12)                 |  (green)         | On                          | The device is linked to the Ethernet.  |
|                                     |  (off)           | Off                         | The device has no link to the Ethernet.  |
| <b>ACT</b>                          | <b>LED yellow</b>   |                             |  |
| Ch0: (11), Ch1: (14)                |  (yellow)        | Flickering (load dependent) | The device sends/receives Ethernet frames.   |
|                                     |  (off)           | Off                         | The device does not send/receive Ethernet frames.  |

Table 46: LED states for the EtherNet/IP Scanner protocol

| LED state                   | Definition   |
|-----------------------------|--|
| Flashing (1 Hz)             | The indicator turns on and off with a frequency of 1 Hz: "on" for 500 ms, followed by "off" for 500 ms.  |
| Flashing green/red/green    | The MS LED indicator turns on green on for 250 ms, then red on for 250 ms, then green on (until the test is completed).  |
| Flashing green/red/off      | The NS LED indicator turns on green on for 250 ms, then red on for 250 ms, then off (until the test is completed).   |
| Flickering (load dependent) | The indicator turns on and off with a frequency of approximately 10 Hz to indicate high Ethernet activity: on for approximately 50 ms, followed by off for 50 ms. The indicator turns on and off in irregular intervals to indicate low Ethernet activity. |

*Table 47: LED state definitions for the EtherNet/IP Scanner protocol*

# 11 Technical data

## 11.1 Technical data of the netHOST devices

### 11.1.1 netHOST for Fieldbus systems

| NHST-T100-DP/CO/DN       | Parameter                   | Value  |
|--------------------------|-----------------------------|--|
| Communication controller | Type                        | netX 100   |
| Memory                   | RAM                         | 8 MB SDRAM   |
|                          | FLASH                       | 4 MB serial Flash  |
|                          | SD memory card (optional)   | max. 2 GByte<br>Do not use SDHC- or SDXC- card types   |
| USB Interface            | USB Socket                  | Mini-USB, 5-pin  |
| Display                  | LEDs                        | <b>SYS</b> system status netHOST<br><b>APL</b> application status netHOST<br><b>LINK</b> Link (LAN interface)<br><b>ACT</b> Activity (LAN interface)<br>Fieldbus communication status:<br>NHST-T100-DP/DPM: <b>COM</b><br>NHST-T100-CO/COM: <b>CAN</b><br>NHST-T100-DN/DNM: <b>MNS</b> |
| Power supply             | Voltage                     | 24 V ± 6 V DC<br>with reverse voltage protection   |
|                          | Current at 24 V (typically) | 130 mA   |
|                          | Power consumption           | 3.2 W  |
|                          | Connector                   | Mini-COMBICON, 2-pin   |
|                          | Power supply                | For UL compliant usage:<br>Device shall be supplied by an isolated voltage source.   |
| Environmental conditions | Temperature range           | 0 ... + 60 °C  |
|                          | Humidity                    | No condensation permitted  |
|                          | Environment                 | For UL compliant usage:<br>Device must be used in a pollution degree 2 environment.  |
| Device                   | Dimensions (L x W x H)      | 100 x 52 x 70 mm (without connector)   |
|                          | Weight                      | appr. 150 g  |
|                          | Mounting                    | on DIN rail EN 60715   |
|                          | Protection class            | IP 20  |
|                          | RoHS                        | Yes  |
| CE Sign                  | CE Sign                     | Yes  |
|                          | Emission                    | CISPR 11 Class A   |
|                          | Immunity                    | EN 61131-2:2003  |
| Configuration            | Software                    | SYCON.net<br>Ethernet Device Configuration Tool  |

Table 48: Technical data netHOST for Fieldbus systems (Part 1)

| NHST-T100-DP/CO/DN                      | Parameter               | Value  |
|---|-------------------------|--|
| Ethernet Interface (X2)                 | Transmission rate       | 100 MBit/s<br>10 MBit/s  |
|   | Interface type          | 100 BASE-TX, isolated  |
|   | Half duplex/Full duplex | supported (at 100 MBit/s)  |
|   | Auto-Negotiation        | supported  |
|   | Auto-Crossover          | supported  |
|   | Connector               | 2 * RJ45   |
| PROFIBUS DP Interface (X3) NHST-T100-DP | Transmission rate       | 9.6 kBit/s,<br>19.2 kBit/s,<br>31.25 kBit/s,<br>45.45 kBit/s,<br>93.75 kBit/s,<br>187.5 kBit/s,<br>500 kBit/s,<br>1.5 MBit/s,<br>3 MBit/s,<br>6 MBit/s,<br>12 MBit/s |
|   | Interface type          | RS 485, optically isolated   |
|   | Connector               | SubD female, 9-pin   |
| CANopen Interface (X3) NHST-T100-CO     | Transmission rate       | 10 kBit/s,<br>20 kBit/s,<br>50 kBit/s,<br>100 kBit/s,<br>125 kBit/s,<br>250 kBit/s,<br>500 kBit/s,<br>800 kBit/s,<br>1 MBit/s  |
|   | Interface type          | ISO 11898, optically isolated  |
|   | Connector               | SubD male, 9-pin   |
| DeviceNet Interface (X3) NHST-T100-DN   | Transmission rate       | 125 kBit/s,<br>250 kBit/s,<br>500 kBit/s   |
|   | Interface type          | ISO 11898, optically isolated  |
|   | Connector               | COMBICON, 5-pin  |

Table 49: Technical data netHOST for Fieldbus systems (Part 2)

### 11.1.2 netHOST for Real-Time Ethernet systems

| NHST-T100-EN/PNM/ECM/EIM                      | Parameter                   | Value   |
|---|-----------------------------|---|
| Communication controller                      | Type                        | netX 100  |
| Memory  | RAM                         | 8 MB SDRAM  |
|   | FLASH                       | 4 MB serial Flash   |
|   | SD memory card (optional)   | max. 2 GByte<br>Do not use SDHC- or SDXC- card types  |
| USB Interface                                 | USB Socket                  | Mini-USB, 5-pin   |
| Display                                       | LEDs                        | <b>SYS</b> system status netHOST<br><b>APL</b> application status netHOST<br><b>LINK</b> Link (LAN and RTE interface)<br><b>ACT</b> Activity (LAN and RTE interface)<br><br><b>Protocol specific LEDs:</b><br>PROFINET IO Controller: <b>SF, BF</b><br>EtherCAT Master: <b>RUN, ERR</b><br>Ethernet/IP Scanner: <b>MS, NS</b> |
| Power supply                                  | Voltage                     | 24 V ± 6 V DC<br>with reverse voltage protection  |
|   | Current at 24 V (typically) | 130 mA  |
|   | Power consumption           | 3.2 W   |
|   | Connector                   | Mini-COMBICON, 2-pin  |
|   | Power supply                | For UL compliant usage:<br>Device shall be supplied by an isolated voltage source.  |
| Environmental conditions                      | Temperature range           | 0 ... + 60 °C   |
|   | Humidity                    | No condensation permitted   |
|   | Environment                 | For UL compliant usage:<br>Device must be used in a pollution degree 2 environment.   |
| Device  | Dimensions (L x W x H)      | 100 x 52 x 70 mm (without connector)  |
|   | Weight                      | appr. 150 g   |
|   | Mounting                    | on DIN rail EN 60715  |
|   | Protection class            | IP 20   |
|   | RoHS                        | Yes   |
| CE Sign                                       | CE Sign                     | Yes   |
|   | Emission                    | CISPR 11 Class A  |
|   | Immunity                    | EN 61131-2:2003   |
| Configuration                                 | Software                    | SYCON.net<br>Ethernet Device Configuration Tool   |
| Ethernet Interfaces (RTE at X2 and LAN at X3) | Transmission rate           | 100 MBit/s<br>10 MBit/s   |
|   | Interface type              | 100 BASE-TX, isolated   |
|   | Half duplex/Full duplex     | supported (at 100 MBit/s)   |
|   | Auto-Negotiation            | supported   |
|   | Auto-Crossover              | supported   |
|   | Connector                   | X2 (RTE interface): 2 x RJ45<br>X3 (LAN interface): 1 x RJ45  |

Table 50: Technical data netHOST for Real-Time Ethernet systems

## 11.2 Technical data of the protocols

### 11.2.1 PROFIBUS DP Master (NHST-T100-DP/DPM)

| Parameter                                  | Description  |
|--|--|
| Maximum number of PROFIBUS DP slaves       | 125 (DPV0/DPV1)  |
| Maximum number of total cyclic input data  | 5712 bytes   |
| Maximum number of total cyclic output data | 5760 bytes   |
| Maximum number of cyclic input data        | 244 bytes per slave  |
| Maximum number of cyclic output data       | 244 bytes per slave  |
| Configuration data                         | Max. 244 bytes per slave   |
| Parameterization data per slave            | 7 bytes standard parameter per slave<br>Max. 237 bytes application specific parameters per slave   |
| Acyclic communication                      | DPV1 class 1 read, write<br>DPV1 class 1 alarm<br>DPV1 class 2 initiate, read, write, data transport, abort  |
| Maximum number of acyclic read/write       | 240 bytes per slave and telegram   |
| Functions                                  | Configuration in Run (CiR), requires host application program support<br>Timestamp (Master functionality)  |
| Redundancy                                 | Supported, requires host application program support   |
| Baud rate                                  | 9,6 kBits/s,<br>19,2 kBits/s,<br>31,25 kBits/s,<br>45,45 kBits/s,<br>93,75 kBits/s,<br>187,5 kBits/s,<br>500 kBits/s,<br>1, 5 MBits/s,<br>3 MBits/s,<br>6 MBits/s,<br>12 MBit/s<br>Auto baud rate detection is not supported |
| Data transport layer                       | PROFIBUS FDL   |
| Limitations                                | DPV2 isochronous mode and slave slave communication are not supported.<br>The redundancy function cannot be used, if the master is configured by the host application program by packets.                                    |
| Reference to firmware/stack version        | 2.6.x.x  |

Table 51: Technical data PROFIBUS DP Master protocol

### 11.2.2 CANopen Master (NHST-T100-CO/COM)

| Parameter                            | Description   |
|--------------------------------------|---|
| Maximum number of CANopen nodes      | 126   |
| Maximum number of cyclic input data  | 3584 bytes  |
| Maximum number of cyclic output data | 3584 bytes  |
| Maximum number of receive PDOs       | 512   |
| Maximum number of transmit PDOs      | 512   |
| Exchange of process data             | Via PDO transfer:<br>- synchronized,<br>- remotely requested and<br>- event driven (change of date)   |
| Acyclic communication                | SDO Upload/Download, max. 512 bytes per request   |
| Functions                            | Emergency message (consumer and producer)<br>Node guarding / life guarding, heartbeat<br>PDO mapping<br>NMT Master<br>SYNC protocol (producer)<br>Simple boot-up process, reading object 1000H for identification |
| Baud rates                           | 10 kBits/s,<br>20 kBits/s,<br>50 kBits/s,<br>100 kBits/s,<br>125 kBits/s,<br>250 kBits/s,<br>500 kBits/s,<br>800 kBits/s,<br>1 MBits/s  |
| CAN layer 2 access                   | Send/receive via API supported (11 bit/29 bit)  |
| Data transport layer                 | CAN Frames  |
| CAN Frame type for CANopen           | 11 Bit  |
| Reference to version                 | V2.11.x.x   |

Table 52: Technical data CANopen Master protocol

### 11.2.3 DeviceNet Master (NHST-T100-DN/DNM)

| Parameter                                  | Description   |
|--|---|
| Maximum number of DeviceNet slaves         | 63  |
| Maximum number of total cyclic input data  | 3584 bytes  |
| Maximum number of total cyclic output data | 3584 bytes  |
| Maximum number of cyclic input data        | 255 bytes/connection  |
| Maximum number of cyclic output data       | 255 bytes/connection  |
| Maximum Configuration data                 | 1000 bytes/slave  |
| Acyclic communication                      | Explicit connection<br>All service codes are supported  |
| Connections                                | Bit Strobe<br>Change of State<br>Cyclic<br>Poll<br>Explicit Peer-to-Peer Messaging  |
| Function                                   | Quick Connect   |
| Fragmentation                              | Explicit and I/O  |
| UCMM                                       | Supported   |
| Objects                                    | Identity Object (Class Code 0x01)<br>Message Router Object (Class Code 0x02)<br>DeviceNet Object (Class Code 0x03)<br>Connection Object (Class Code 0x05)<br>Acknowledge Handler Object (Class Code 0x06) |
| Baud rates                                 | 125 kBits/s,<br>250 kBit/s,<br>500 kBit/s<br><br>Auto baudrate detection is not supported   |
| Data transport layer                       | CAN frames  |
| Reference to firmware/stack version        | V2.3.x.x  |

Table 53: Technical data DeviceNet Master protocol

### 11.2.4 PROFINET IO Controller

| Parameter                                  | Description  |
|--|--|
| Maximum number of PROFINET IO Devices      | 128  |
| Maximum number of total cyclic input data  | 5712 bytes (including IOxS status bytes)   |
| Maximum number of total cyclic output data | 5760 bytes (including IOxS status bytes)   |
| Maximum number of cyclic input data        | 1440 bytes per device (= IOCR data length including IOxS status bytes)   |
| Maximum number of cyclic output data       | 1440 bytes per device (= IOCR data length including IOxS status bytes)   |
| Acyclic communication                      | Read/Write Record<br>Limited to 1392 bytes per telegram<br>Limited to 4096 bytes per request   |
| Alarm processing                           | yes, but requires handling in host application program   |
| Diagnostic data                            | One 200 byte buffer per IO device  |
| DCP functions via API                      | Name Assignment IO-Devices (DCP SET NameOfStation)<br>Set IO-Devices IP (DCP SET IP)<br>Signal IO-Device (DCP SET SIGNAL)<br>Reset IO-Device to factory settings (DCP Reset FactorySettings)<br>Bus scan (DCP IDENTIFY ALL)  |
| Supported Protocols                        | RTC – Real Time Cyclic Protocol, Class 1<br>RTA – Real Time Acyclic Protocol<br>DCP – Discovery and configuration Protocol<br>CL-RPC – Connectionless Remote Procedure Call  |
| Context management by CL-RPC               | Supported  |
| Minimum cycle time                         | 1 ms<br>Different IO-Devices can be configured with different cycle times  |
| Functions                                  | Fast Startup of PROFINET IO Devices supported  |
| Baud rate                                  | 100 MBit/s<br>Full-Duplex mode   |
| Data transport layer                       | Ethernet II, IEEE 802.3  |
| Configuration file                         | Maximum 1 MByte  |
| Limitations                                | RT over UDP not supported<br>Multicast communication not supported<br>DHCP is not supported (neither for PROFINET IO-Controller nor for the IO-Devices)<br>Only one IOCR per IO Device<br>NameOfStation of IO Controller CANNOT be set using the DCP SET NameOfStation service but only at start-up while configuring the IO Controller<br>The buffer for IO-Device diagnosis data will be overwritten in case of multiple diagnostic events. Only one (the last) event is stored at the same time. If a single event produces more than 200 bytes of diagnosis data, only the first 200 bytes will be taken care of.<br>The usable (minimum) cycle time depends on the number of used IO Devices, the number of used input and output data. The cycle-time, the number of configured IO Devices and the amount of IO data depend on each other. For example it is not possible due to performance reasons to have 128 IO Devices communication with cycle-time 1ms.<br>The size of the bus configuration file is limited by the size of the RAM Disk (1 MByte)<br>WriteMultiple-Record service is not supported |
| Reference to firmware/stack version        | V2.7.x.x   |

Table 54: Technical data PROFINET IO RT Controller

### 11.2.5 EtherCAT Master

| Parameter                                       | Description  |
|---|--|
| Maximum number of EtherCAT slaves               | Maximum of 388 slaves, if RCX_GET_SLAVE_HANDLES_REQ service is used for determining number of slaves<br><br>The number of usable slaves depends on several parameters: the available memory for the configuration file (see 'configuration file' below), used cycle time, frame propagation time   |
| Maximum number of cyclic input data             | Appr. 4600 bytes, if no LRW command (Logical Read Write) is used for process data  |
| Maximum number of cyclic output data            | Appr. 4600 bytes, if no LRW command (Logical Read Write) is used for process data  |
| Acyclic communication                           | CoE (CANopen over EtherCAT): SDO, SDOINFO, Emergency<br>FoE (File Access over EtherCAT)<br>Configurable with SYCON.net: CoE<br><br>If the file ETHERCAT.XML contains the appropriate configuration information (e.g. created with "EtherCAT Configurator"), the CoE function can be used   |
| Mailbox protocols                               | CoE, FoE   |
| Functions                                       | Distributed Clocks<br>Redundancy<br>Slave diagnostics<br>Bus scan  |
| Minimum bus cycle time                          | 250 µs, depending on the used number of slaves and the used number of cyclic input data and output data.   |
| Topology  | Line or ring   |
| Slave station address range                     | 1 – 14335  |
| Data transport layer                            | Ethernet II, IEEE 802.3, 100 MBit/s, full-duplex   |
| Configuration file (ETHERCAT.XML or CONFIG.NXD) | NHST-T100-EN: Maximum 2 MByte  |
| Synchronization via ExtSync                     | Supported (not configurable with SYCON.net)  |
| ENI Slave-to-Slave copy infos                   | Supported (not configurable with SYCON.net)  |
| Hot Connect                                     | Supported (not configurable with SYCON.net)  |
| Limitations                                     | The size of the bus configuration file is limited by the size of the Flash disk (2 MByte)<br><br>Store-and-forward switches cannot be used within network topology due to hard receive timing model<br><br>RCX_GET_SLAVE_HANDLES_REQ can only communicate up to 388 slaves<br><br>Process data is restricted by the dual-port memory to 5760 bytes |
| Reference to firmware / stack version           | V4.4   |

Table 55: Technical data EtherCAT Master protocol

### 11.2.6 EtherNet/IP Scanner

| Parameter                                     | Description   |
|---|---|
| Maximum number of EtherNet/IP connections     | 64 connections for implicit and explicit  |
| Maximum number of total cyclic input data     | 5712 bytes  |
| Maximum number of total cyclic output data    | 5760 bytes  |
| Maximum number of cyclic input data           | 504 bytes per slave per telegram  |
| Maximum number of cyclic output data          | 504 bytes per slave per telegram  |
| IO Connection type                            | Cyclic, minimum 1 ms (depending on used number of connections and used number of input and output data)   |
| Maximum number of unscheduled data            | 1400 bytes per telegram   |
| UCMM, Class 3                                 | Supported   |
| Explicit Messages, Client and Server Services | Get_Attribute_Single/All<br>Set_Attribute_Single/All  |
| Quick connect                                 | Supported   |
| Predefined standard objects                   | Identity Object<br>Message Route Object<br>Assembly Object<br>Connection Manager<br>Ethernet Link Object<br>TCP/IP Object<br>DLR Object<br>QoS Object |
| Maximal number of user specific objects       | 20  |
| Topology                                      | Tree, Line, Ring  |
| DLR (Device Level Ring)                       | Beacon based 'Ring Node'  |
| ACD (Address Conflict Detection)              | Supported   |
| DHCP  | Supported   |
| BOOTP   | Supported   |
| Baud rates                                    | 10 and 100 MBit/s   |
| Data transport layer                          | Ethernet II, IEEE 802.3   |
| Switch function                               | Integrated  |
| Limitations                                   | CIP Sync Services are not implemented<br>TAGs are not supported   |
| Reference to firmware/stack version           | V2.10.x.x   |

Table 56: Technical data EtherNet/IP Scanner (master) protocol

## 12 Decommissioning/Disposal

### 12.1 Putting the device out of operation

---

**NOTICE****Danger of Unsafe System Operation !**

To prevent personal injury or property damage, make sure that the removal of the device from your plant during operation will not affect the safe operation of the plant.

---

- Disconnect all communication cables from the device.
- Disconnect the power supply plug.
- Remove the device from the DIN rail as described in section *Removing netHOST device from the Top Hat Rail* [▶ page 41].

### 12.2 Disposal of waste electronic equipment

According to the European Directive 2002/96/EG “Waste Electrical and Electronic Equipment (WEEE)”, waste electronic equipment may not be disposed of as household waste. As a consumer, you are legally obliged to dispose of all waste electronic equipment according to national and local regulations.



---

**Waste electronic equipment****Waste Electronic Equipment**

This product must not be treated as household waste.

This product must be disposed of at a designated waste electronic equipment collecting point.

---

## List of figures

|            |  |    |
|------------|--|----|
| Figure 1:  | Data flow of LAN controlled netHOST device.....          | 24 |
| Figure 2:  | netHOST for Fieldbus: NHST-T100-DP/DPM (example) .....   | 26 |
| Figure 3:  | netHOST for RTE systems .....                            | 27 |
| Figure 4:  | Galvanic isolation of netHOST for Fieldbus systems ..... | 37 |
| Figure 5:  | Galvanic isolation of netHOST for RTE systems .....      | 38 |
| Figure 6:  | ComProX start screen .....                               | 48 |
| Figure 7:  | ComProX Connection dialog .....                          | 48 |
| Figure 8:  | ComProX File Explorer .....                              | 49 |
| Figure 9:  | ComProX Download .....                                   | 49 |
| Figure 10: | Choose a file dialog in ComProX.....                     | 49 |
| Figure 11: | Downloaded firmware in Explorer.....                     | 50 |

## List of tables

|           |   |    |
|-----------|---|----|
| Table 1:  | List of revisions .....   | 6  |
| Table 2:  | Reference to devices with preloaded firmware .....                            | 8  |
| Table 3:  | Reference to devices for loadable firmware .....                              | 8  |
| Table 4:  | Reference to software .....   | 9  |
| Table 5:  | Reference to drivers .....  | 9  |
| Table 6:  | Directory of netHOST Solutions DVD .....                                      | 11 |
| Table 7:  | Basic documentation for netHOST .....   | 12 |
| Table 8:  | Additional documentation for netHOST as PROFIBUS DP Master .....              | 13 |
| Table 9:  | Additional documentation for netHOST as CANopen Master .....                  | 13 |
| Table 10: | Additional documentation for netHOST as DeviceNet Master .....                | 13 |
| Table 11: | Additional documentation for netHOST as PROFINET IO Controller .....          | 14 |
| Table 12: | Additional documentation for netHOST as EtherCAT Master .....                 | 14 |
| Table 13: | Additional documentation for netHOST as EtherNet/IP Scanner .....             | 15 |
| Table 14: | Signal words in safety messages on personal injury .....                      | 22 |
| Table 15: | Safety signs in messages on personal injury .....                             | 22 |
| Table 16: | Signal words in safety messages on property damage .....                      | 22 |
| Table 17: | Safety signs in safety messages on property damage .....                      | 22 |
| Table 18: | Dimensioned drawing, example NHST-T100-DP .....                               | 30 |
| Table 19: | LEDs, connectors and operating elements of netHOST for Fieldbus systems ..... | 31 |
| Table 20: | LEDs, connectors and operating elements of netHOST for RTE systems .....      | 32 |
| Table 21: | Sticker for NHST-T100-EN .....  | 33 |
| Table 22: | Device label (NHST-T100-DP example) .....                                     | 33 |
| Table 23: | Pin assignment Mini Combicon socket 2-pole .....                              | 33 |
| Table 24: | Ethernet RJ45 pin assignment .....  | 34 |
| Table 25: | PROFIBUS RS-485 pin assignment .....  | 35 |
| Table 26: | CANopen pin assignment .....  | 35 |
| Table 27: | DeviceNet pin assignment .....  | 36 |
| Table 28: | Pin assignment Mini-B USB connector (5-pin) .....                             | 36 |
| Table 29: | Coupling of netHOST for Fieldbus systems .....                                | 37 |
| Table 30: | Coupling of netHOST for RTE systems .....                                     | 38 |
| Table 31: | Mounting the netHOST device onto Top Hat Rail .....                           | 40 |
| Table 32: | Removing the netHOST device from Top Hat Rail .....                           | 41 |
| Table 33: | netHOST troubleshooting by LED .....  | 51 |
| Table 34: | System LED .....  | 52 |
| Table 35: | APL LED .....   | 53 |
| Table 36: | LED states for the PROFIBUS DP Master protocol .....                          | 54 |
| Table 37: | LED state definitions for the PROFIBUS DP Master protocol .....               | 54 |
| Table 38: | LED states for the CANopen Master protocol .....                              | 55 |
| Table 39: | LED state definitions for the CANopen Master protocol .....                   | 55 |
| Table 40: | LED states for the DeviceNet Master protocol .....                            | 56 |

---

|           |   |    |
|-----------|---|----|
| Table 41: | LED state definitions for the DeviceNet Master protocol .....       | 56 |
| Table 42: | LED states for the PROFINET IO-Controller protocol .....            | 57 |
| Table 43: | LED state definitions for the PROFINET IO-Controller protocol ..... | 57 |
| Table 44: | LED states for the EtherCAT Master(V4) protocol.....                | 58 |
| Table 45: | LED state definitions for the EtherCAT Master(V4) protocol .....    | 58 |
| Table 46: | LED states for the EtherNet/IP Scanner protocol .....               | 60 |
| Table 47: | LED state definitions for the EtherNet/IP Scanner protocol.....     | 61 |
| Table 48: | Technical data netHOST for Fieldbus systems (Part 1) .....          | 62 |
| Table 49: | Technical data netHOST for Fieldbus systems (Part 2) .....          | 63 |
| Table 50: | Technical data netHOST for Real-Time Ethernet systems.....          | 64 |
| Table 51: | Technical data PROFIBUS DP Master protocol .....                    | 65 |
| Table 52: | Technical data CANopen Master protocol .....                        | 66 |
| Table 53: | Technical data DeviceNet Master protocol .....                      | 67 |
| Table 54: | Technical data PROFINET IO RT Controller .....                      | 68 |
| Table 55: | Technical data EtherCAT Master protocol.....                        | 69 |
| Table 56: | Technical data EtherNet/IP Scanner (master) protocol .....          | 70 |

# Contacts

## HEADQUARTERS

### Germany

Hilscher Gesellschaft für  
Systemautomation mbH  
Rheinstrasse 15  
65795 Hattersheim  
Phone: +49 (0) 6190 9907-0  
Fax: +49 (0) 6190 9907-50  
E-mail: [info@hilscher.com](mailto:info@hilscher.com)

### Support

Phone: +49 (0) 6190 9907-99  
E-mail: [de.support@hilscher.com](mailto:de.support@hilscher.com)

## SUBSIDIARIES

### China

Hilscher Systemautomation (Shanghai) Co. Ltd.  
200010 Shanghai  
Phone: +86 (0) 21-6355-5161  
E-mail: [info@hilscher.cn](mailto:info@hilscher.cn)

### Support

Phone: +86 (0) 21-6355-5161  
E-mail: [cn.support@hilscher.com](mailto:cn.support@hilscher.com)

### France

Hilscher France S.a.r.l.  
69500 Bron  
Phone: +33 (0) 4 72 37 98 40  
E-mail: [info@hilscher.fr](mailto:info@hilscher.fr)

### Support

Phone: +33 (0) 4 72 37 98 40  
E-mail: [fr.support@hilscher.com](mailto:fr.support@hilscher.com)

### India

Hilscher India Pvt. Ltd.  
Pune, Delhi, Mumbai  
Phone: +91 8888 750 777  
E-mail: [info@hilscher.in](mailto:info@hilscher.in)

### Italy

Hilscher Italia S.r.l.  
20090 Vimodrone (MI)  
Phone: +39 02 25007068  
E-mail: [info@hilscher.it](mailto:info@hilscher.it)

### Support

Phone: +39 02 25007068  
E-mail: [it.support@hilscher.com](mailto:it.support@hilscher.com)

### Japan

Hilscher Japan KK  
Tokyo, 160-0022  
Phone: +81 (0) 3-5362-0521  
E-mail: [info@hilscher.jp](mailto:info@hilscher.jp)

### Support

Phone: +81 (0) 3-5362-0521  
E-mail: [jp.support@hilscher.com](mailto:jp.support@hilscher.com)

### Korea

Hilscher Korea Inc.  
Seongnam, Gyeonggi, 463-400  
Phone: +82 (0) 31-789-3715  
E-mail: [info@hilscher.kr](mailto:info@hilscher.kr)

### Switzerland

Hilscher Swiss GmbH  
4500 Solothurn  
Phone: +41 (0) 32 623 6633  
E-mail: [info@hilscher.ch](mailto:info@hilscher.ch)

### Support

Phone: +49 (0) 6190 9907-99  
E-mail: [ch.support@hilscher.com](mailto:ch.support@hilscher.com)

### USA

Hilscher North America, Inc.  
Lisle, IL 60532  
Phone: +1 630-505-5301  
E-mail: [info@hilscher.us](mailto:info@hilscher.us)

### Support

Phone: +1 630-505-5301  
E-mail: [us.support@hilscher.com](mailto:us.support@hilscher.com)