

User manual

NFD-3090-EIS-IOLM\W

netFIELD IO-Link Wireless Master EtherNet/IP Adapter



Hilscher Gesellschaft für Systemautomation mbH
www.hilscher.com

DOC200701UM02EN | Revision 2 | English | 2021-08 | Released | Public

Table of contents

1	Introduction	5
1.1	About this document	5
1.2	List of revisions	5
2	Device description	6
2.1	Functional description	6
2.2	Device overview	7
2.3	Product software	9
2.4	Revisions and versions	9
2.5	Identification	10
2.6	Connectors and interfaces	11
2.6.1	Power supply	11
2.6.2	Ethernet	11
2.6.3	IO-Link, SMA antenna.....	12
2.7	Derating.....	12
3	Safety	13
3.1	General note	13
3.2	Intended use	13
3.3	Personnel qualification	13
3.4	Power drop during write and delete accesses in the file system.....	14
3.5	Exceeding the maximum number of permitted write and delete accesses	14
3.6	Information and data security.....	14
4	Getting started	15
5	Requirements	16
5.1	Hardware and system requirements	16
5.2	Software requirements	16
6	Mounting and demounting.....	17
6.1	Mounting	17
6.1.1	Grounding	19
6.2	Demounting.....	19
6.3	Disposal of waste electronic equipment.....	20
7	Connections	21
7.1	Connection example	22
8	Configuration	23
8.1	Configuration tools	23
8.2	Configuring EtherNet/IP	26
8.2.1	Selecting a connection.....	27
8.2.2	Setting parameters.....	28
8.3	Configuration with netFIELD Wireless Web Server	31
8.3.1	Functional overview	31
8.3.2	Open netFIELD Wireless Web Server	32

8.3.3	Dashboard	33
8.3.4	Licenses	34
8.3.5	IO-Link Wireless Master settings	34
8.3.6	Device or port information	42
8.3.7	Device settings	51
9	Commissioning	71
9.1	Getting an IP address from a DHCP server	71
9.2	Configuration with netFIELD Wireless Web Server	72
9.2.1	Configuring the IO-Link Wireless Master	73
9.2.2	Port settings	75
9.3	Testing	79
9.4	Master reset	81
9.5	Indexed Service Data Units	82
9.6	Wireless	84
9.7	Setting date and time	84
9.8	Using OPC UA Client	85
9.8.1	Connecting with device	85
9.8.2	Setting date and time of the device via OPC UA	87
10	Communication	89
10.1	Process data	89
10.1.1	Connections 1 to 4	90
10.1.2	Connections 5 to 7	93
10.1.3	Connections 8 to 10	97
10.1.4	Input process data status	101
10.2	OPC UA	102
10.2.1	Device identification	103
10.2.2	Identification of connected IO-Link Devices	103
10.2.3	NTP Client configuration	104
10.3	MQTT topics	105
10.3.1	General parts of a topic	105
10.3.2	Gateway topics	105
10.3.3	Master topics	107
10.3.4	Device topics	112
10.3.5	MQTT topics	116
11	Diagnosis	117
11.1	Diagnosis via LEDs	117
11.1.1	System LED	117
11.1.2	APL LED	118
11.1.3	Supply voltage status	118
11.1.4	EtherNet/IP Adapter status	119
11.1.5	Wireless track status	121
11.1.6	Wireless port status	121
11.2	Diagnosis via EtherNet/IP	122
11.2.1	Event Log Object 65 (0x41)	122
11.2.2	CIP status	124
11.3	Diagnosis over IO-Link	127
11.3.1	Event Qualifier	127
11.3.2	IO-Link Wireless Master Event Codes	127
11.3.3	IO-Link Device Event Codes (common)	128

12	Technical data	130
12.1	Technical data device	130
12.2	Technical data IO-Link Wireless Master	132
12.3	Technical data protocol	133
12.4	Technical data netFIELD Wireless Web Server	134
12.5	OPC UA Server	134
12.6	MQTT Client	134
13	Dimensions	135
13.1	Dimensions netFIELD IO-Link Wireless Master device	135
14	Approvals	136
14.1	FCC/ISED	136
15	Appendix	138
15.1	References	138
15.2	Conventions in this document	139
15.3	Directives and standards	140
15.4	Legal notes	141
15.5	Registered trademarks	145
	Glossary	151
	Contacts	154

1 Introduction

1.1 About this document

This document describes the netFIELD IO-Link Wireless Master EtherNet/IP Adapter **NFD-3090-EIS-IOLMW** device.

The device and the firmware are under development and changes of the functionality can appear. The information provided in this document is preliminary, may not be complete and may not be error free.



Important:

The device must not be used in a productive environment.

1.2 List of revisions

Index	Date	Revision
1	2020-11-25	Document created.
2	2021-08-31	<p><i>Description:</i> Section <i>Device description</i> [▶ page 6] updated, sections <i>Product software</i> [▶ page 9] and <i>Derating</i> [▶ page 12] added.</p> <p><i>Configuration:</i> Section <i>Configuration tools</i> [▶ page 23] updated. Section <i>Selecting a connection</i> [▶ page 27] revised, section <i>Setting parameters</i> [▶ page 28] updated.</p> <p>Section <i>Configuration with netFIELD Wireless Web Server</i> [▶ page 31] description updated (subsections <i>Device ISDU</i> [▶ page 46] and <i>Port settings</i> [▶ page 52], and further updates).</p> <p><i>Commissioning:</i> Section <i>Port settings</i> [▶ page 75] updated, sections <i>Setting date and time</i> [▶ page 84], and <i>Using OPC UA Client</i> [▶ page 85] added.</p> <p><i>Communication:</i> Section <i>Process data</i> [▶ page 89] revised, section <i>Input process data status</i> [▶ page 101] added.</p> <p>Section <i>NTP Client configuration</i> [▶ page 104] added, and sections <i>MQTT topics</i> [▶ page 105] with <i>General parts of a topic</i> [▶ page 105] added.</p> <p><i>Diagnosis:</i> Section <i>EtherNet/IP Adapter status</i> [▶ page 119] updated, section <i>Wireless port status</i> [▶ page 121] updated. Section <i>Event Log Object 65 (0x41)</i> [▶ page 122] updated and section <i>CIP status</i> [▶ page 124] added.</p> <p><i>Technical data:</i> Section <i>Technical data device</i> [▶ page 130] updated. Sections <i>Technical data IO-Link Wireless Master</i> [▶ page 132], <i>Technical data netFIELD Wireless Web Server</i> [▶ page 134], <i>OPC UA Server</i> [▶ page 134] and <i>MQTT Client</i> [▶ page 134] added. Section <i>Technical data protocol</i> [▶ page 133] revised.</p> <p><i>Approvals:</i> Chapter <i>Approvals</i> [▶ page 136] added. <i>Appendix:</i> Section <i>Directives and standards</i> [▶ page 140] added.</p>

Table 1: List of revisions

2 Device description

2.1 Functional description

The IO-Link Wireless Master **NFD-3090-EIS-IOLMW** device is intended for use within an EtherNet/IP network.

The device enables the operation of up to 16 IO-Link Devices via a wireless connection. An IO-Link Device could be an IO-Link sensor/actuator.

Parameterization, configuration

- The device is parameterized via EtherNet/IP. The device stores the parameters.
- Alternatively, the IO-Link Wireless Master and the wireless IO-Link ports of the device can be configured using the integrated netFIELD Wireless Web Server. The netFIELD Wireless Web Server enables you to parameterize the IO-Link Devices connected via a wireless connection to the IO-Link Wireless Master device.
- Or, you can use the IO-Link engineering tool “IO-Link E.T.” to configure the IO-Link Wireless Master and the wireless IO-Link ports of the device, as well as IO-Link Devices parameters based on IODD file.
- OPC UA Server is also integrated and offers identification, and status.
- The device provides MQTT topics for device identification, device capabilities, configuration status, address data, process data, event logs or device parameters.



For further information see section *Configuration tools* [► page 23].

2.2 Device overview




Figure 1: Device overview, NFD-3090-EIS-IOLMW

Manufacturer, product identification, and technical data can be found on the device housing as laser engravings.

Function	Pos.	Name	Description	For details, see section
Ethernet	(32)	X31	Ethernet interface, M12, D-coded, EtherNet/IP port 1 (CH0)	Ethernet [▶ page 11]
	(10)	X32	Ethernet interface, M12, D-coded, EtherNet/IP port 2 (CH1)	
	(30)	LINK (X31)	Link LED for connector X31	EtherNet/IP Adapter status [▶ page 119]
	(31)	ACT (X31)	Activity LED for connector X31	
	(28)	ACT (X32)	Activity LED for connector X32	
	(29)	LINK (X32)	Link LED for connector X32	
	(9)	-	Labeling fields Ethernet interfaces X31 and X32	-
LEDs	(34)	SYS	System status LED	System LED [▶ page 117]
	(33)	APL	Application status LED	APL LED [▶ page 118]
	(7)	MS	Module status LED	EtherNet/IP Adapter status [▶ page 119]
	(8)	NS	Network status LED	
Power supply	(25)	X21	Power supply input (PWR IN), M12, L-coded	Power supply [▶ page 11]
	(13)	X22	Power supply output (PWR OUT), M12, L-coded	
	(12)	1L (X21)	1L supply voltage status LED (DC 24 V)	Supply voltage status [▶ page 118]
	(14)	2L (X21)	2L supply voltage status LED (DC 24 V)	
	(11)	-	Labeling fields power supply input X21 and output X22	-
Antenna connectors and LEDs for IO-Link wireless radio module	(23)	X1	Connector for SMA antenna for IO-Link wireless connection to the IO-Link Devices 1 to 8	IO-Link, SMA antenna [▶ page 12]
	(16)	X2	Connector for SMA antenna for IO-Link wireless connection to the IO-Link Devices 9 to 16	
	(21)	X3	Connector for SMA antenna	
	(22), (20)	-	Labeling fields SMA antennas X1, X2, and X3	-
	(24)	WT1 ... WT3	IO-Link wireless track status LEDs	Wireless track status [▶ page 121]
	(15)	WP01 ... WP08	Port status LEDs for wireless IO-Link ports WP01 ... WP08	Wireless port status [▶ page 121]
	(17)	WP09 ... WP16	Port status LEDs for wireless IO-Link ports WP09 ... WP16	
Device identification	(26)	-	QR code	Identification [▶ page 10]
	(27)	-	Product group and model	
	(35)	-	Logo communication field bus	
	(36)	-	Part number, model, serial number, MAC address	
	(19)	-	Device labeling field	-
Manufacturer	(37)	-	Manufacturer address	Contacts [▶ page 154]
Technical data	(1), (5)	-	Space for certification signs and IDs	Technical data [▶ page 130]
	(4)	-	Power supply (SELV / PELV), fuse protection, temperature range, protection class	
Safety and disposal	(2), (3)	-	Signs on safety and environment (disposal)	Mounting and demounting [▶ page 17]
Mounting	(6)	-	Mounting hole and grounding	Mounting and demounting [▶ page 17]
	(18)	-	Mounting hole	

Table 2: Legend to the device overview, NFD-3090-EIS-IOLMW

2.3 Product software

All the information and software you need for your product can be downloaded free of charge at the web-link

<https://kb.hilscher.com/display/NFDIOLWM>

- Select the link for the current release for the product software.

After the download, you can start commissioning and configuring your device immediately.

- Check our website regularly for software updates for your product.

2.4 Revisions and versions

The hardware revision listed below, as well as the software and firmware versions belong together functionally. If a hardware installation is available, for the firmware update these specifications are relevant.

Model	Description	Part number	Hardware revision
NFD-3090-EIS-IOLM\W	netFIELD IO-Link Wireless Master EtherNet/IP Adapter	1912.122	3

Table 3: Hardware

Software	Version
netFIELD Wireless Web Server	1.1

Table 4: Software

Protocol	File name	Note	Version
EtherNet/IP Adapter	U197H001.nxi, U197H001.nxe, U197H001.nai	nxi for COM CPU, with nxe for extension. nai for APP CPU.	2.1

Table 5: Firmware

Description	Version
IO-Link Wireless Master stack	8.3
Radio module revision	2.3

Table 6: IO-Link Wireless Master

2.5 Identification

On the front side of the NFD-3090-EIS-IOLM\W device housing a QR code is provided for device identification.



Figure 2: QR code (example)

The QR code includes (example data):

- Part number: 1912.112,
- Hardware revision number: R2
- Serial number: 020000
- MAC ID: 00-02-A2-02-20-E3

To find the QR code in the device overview, see position (26) in section *Device overview* [▶ page 7].

2.6 Connectors and interfaces

2.6.1 Power supply

Connectors X21 and X22

The device is supplied via connector X21 (PWR IN). You can connect two supply lines to the connector:

- Supply line 1: 1L+ (U_{1L}) and the reference potential 1L-
- Supply line 2: 2L+ (U_{2L}) and the reference potential 2L-

Both supply lines are electrically isolated.

Each pin of connector X21 (PWR IN) is connected to the same pin of socket X22 (PWR OUT) and is used to forward the supply to the next device.

For identifying the connector X21 of the NFD-3090-EIS-IOLMW device, see position (25), and connector X22, see position (13) in section *Device overview* [► page 7].



Supply voltage input	Supply voltage output	Pin	Signal	Description
 M12, L-coded, plug, 5-pin (4 + FE)	 M12, L-coded, socket, 5-pin (4 + FE)	1	1L+	24 V DC supply voltage U_{1L} for system and sensor/actuator
		2	2L-	Reference potential for 2L
		3	1L-	Reference potential for 1L
		4	2L+	24 V DC auxiliary/control voltage U_{2L}
		FE	FE	Functional earth

Table 7: Supply voltage

2.6.2 Ethernet

- Connector X31 for Ethernet interface port 1 (CH0)
- Connector X32 for Ethernet interface port 2 (CH1)

For identifying the connector X31 of the NFD-3090-EIS-IOLMW device, see position (32), and connector X32, see position (10) in section *Device overview* [► page 7].

Connectors X31 and X32


Ethernet	Pin	Signal	Description
 M12, D-coded, socket, 4-pin	1	TX+	Transmit data positive
	2	RX+	Receive data positive
	3	TX-	Transmit data negative
	4	RX-	Receive data negative

Table 8: Ethernet

2.6.3 IO-Link, SMA antenna

With the NFD-3090-EIS-IOLMW device, two tracks with each up to 8 and together up to 16 IO-Link Devices simultaneously can be supported.

IO-Link Devices

The type of data transferred (length and data type, etc.) depends on the connected IO-Link Devices.

SMA antenna


Antenna SMA	Type	Manufacturer
	Wifi Antenna 2.4G rubber antenna, Model: TLW2.5A-SMA-Male Bandwidth: 1000 MHz Impedance: 50 Ohms	Silram Technologies Ltd., Kfar Saba, Israel

Table 9: SMA antenna type



Important:

The use of an SMA antenna other than the SMA antenna supplied with the product is not permitted. This could result in losing the approval for your device.

For proper device operation, all three SMA antennas X1, X2, and X3 must be mounted.

2.7 Derating

Note the derating when using the netFIELD IO-Link Wireless Master device, when you connect a device to Power Out at the device and thus a larger current is passed through the device. The ambient temperature and the current have influence on the heating of the device.

The derating curve was created with the operating conditions "without air flow or with air flow 0.5 m/s" as well as "mounting on poorly heat conducting wall". The real operating conditions can lead to a better heat dissipation of the device for example by a higher air flow or a better heat dissipation to the mounting wall.

The following figure shows the maximum permissible current (I) that may flow into the device as a function of the ambient temperature (T).




Figure 3: Derating netFIELD IO-Link Wireless Master device

3 Safety

3.1 General note

The documentation in the form of a user manual, an operating instruction manual or other manual types, as well as the accompanying texts have been created for the use of the products by qualified personnel. When using the products, all Safety Messages, Integrated Safety Messages, Property Damage Messages and all valid legal regulations must be obeyed. Technical knowledge is presumed. The user has to assure that all legal regulations are obeyed.

3.2 Intended use

The device netFIELD IO-Link Wireless Master EtherNet/IP Adapter NFD-3090-EIS-IOLMW is used to receive or send process data via IO-Link:

- The IO-Link Wireless Master device receives process data from the connected IO-Link Device (sensor) and sends this data to a higher-level control system.
- The IO-Link Wireless Master device sends process data received from the higher-level control system to the connected IO-Link Device (actuator).

3.3 Personnel qualification

The device may only be mounted, configured, operated or demounted by qualified personnel. Job-specific technical skills for people professionally working with electricity must be present concerning the following topics:

- Safety and health at work
- Mounting and connecting of electrical equipment
- Measurement and analysis of electrical functions and systems
- Evaluation of the safety of electrical systems and equipment
- Installing and configuring IT systems

3.4 Power drop during write and delete accesses in the file system

The FAT file system in the netX firmware is subject to certain limitations in its operation. Write and delete accesses in the file system (firmware update, configuration download etc.) can destroy the FAT (File Allocation Table) if the accesses cannot be completed if the power drops. Without a proper FAT, a firmware may not be found and cannot be started.

- Make sure that the power supply of the device does not drop during write and delete accesses in the file system (firmware update, configuration download etc.).

3.5 Exceeding the maximum number of permitted write and delete accesses

This device uses a serial flash chip to store remanent data such as firmware storage, configuration storage, etc. This device allows a maximum of 100,000 write/delete accesses that are sufficient for standard operation of the device. However, writing/deleting the chip excessively (e.g. changing the configuration or changing the name of station) leads to the maximum number of permitted write/delete accesses being exceeded and to device damage. For example, if the configuration is changed once an hour, the maximum number is reached after 11.5 years. If the configuration is changed even more frequently, for example once a minute, the maximum number is reached after approx. 69 days.

Avoid exceeding the maximum permitted write/delete accesses by writing too often.

3.6 Information and data security

Take all usual measures for information and data security, in particular, for devices with Ethernet technology. Hilscher explicitly points out that a device with access to a public network (Internet) must be installed behind a firewall or only be accessible via a secure connection such as an encrypted VPN connection. Otherwise, the integrity of the device, its data, the application or system section is not safeguarded.

Hilscher cannot assume any warranty or liability for damage due to neglected security measures or incorrect installation.

4 Getting started

Below you will find an overview of the steps required for installation and commissioning of your IO-Link Wireless Master device:

Step	Description	Refer to section
Requirements and preparation	<ul style="list-style-type: none"> • Prepare the device installation and commissioning according to the requirements on hardware, system, and software. • Prepare the required mounting tools. 	<i>Requirements</i> [► page 16] <i>Mounting</i> [► page 17]
Safety	<ul style="list-style-type: none"> • Read the mounting instructions and the safety instructions on connecting and commissioning the device. • Disconnect the system to which the device will be mounted from the power supply. 	<i>Mounting</i> [► page 17]
Mounting	<ul style="list-style-type: none"> • Mark the positions to fasten the device with screws and cut the M4 holes. • Fasten the device with the screws. • Ground the device. • Mount all three SMA antennas. 	<i>Mounting</i> [► page 17] <i>Grounding</i> [► page 19]
Connecting and booting	<ul style="list-style-type: none"> • Connect the Ethernet M12 cable to the NFD-3090-EIS-IOLM\W device and to the PLC (EtherNet/IP Scanner). • Connect the +24 V DC SELV or PELV power supply to the NFD-3090-EIS-IOLM\W device. • Connect the +24 V DC SELV or PELV power supply to the IO-Link Device. • Switch on the power supply units of the device and of the IO-Link Device. 	<i>Connections</i> [► page 21]
Commissioning	<ul style="list-style-type: none"> • For the first commissioning, the NFD-3090-EIS-IOLM\W device requires a DHCP server. <p>In the configuration software of the EtherNet/IP Scanner:</p> <ul style="list-style-type: none"> • Configure the EtherNet/IP Scanner: Import the EDS file HILSCHER-NETFIELD-WIRELESS-Vx.y.EDS, • Create the configuration project with EtherNet/IP Scanner and EtherNet/IP Adapter, select the connection and set the parameters. <p>For the subsequent steps the following configuration tools can be used:</p> <ul style="list-style-type: none"> • Configure the IO-Link Wireless Master NFD-3090-EIS-IOLM\W using the netFIELD Wireless Web Server. • Configure the wireless IO-Link port parameters via the configuration software of the EtherNet/IP Scanner or using the netFIELD Wireless Web Server. • Configure the IO-Link Device. 	<i>Configuration tools</i> [► page 23] <i>Configuring EtherNet/IP</i> [► page 26] <i>Commissioning</i> [► page 71]

Table 10: Overview for installation and commissioning

5 Requirements

5.1 Hardware and system requirements

To install your IO-Link Wireless Master you need the following hardware elements:

- Power supply: 24 V DC SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) power supply
- Power supply cable with L-coded M12 connector
- Ethernet cable with D-coded M12 connector
- EtherNet/IP Scanner (PLC)
- At least one
IO-Link Wireless Device or
a Wireless Bridge and a wired IO-Link Device
- 3 x SMA antenna: Use type Wifi Antenna 2.4G rubber antenna, model "TLW25A-SMA-Male" only (see section *IO-Link, SMA antenna* [► page 12]).

Additional components

- Ethernet network switch

For commissioning

- PC or notebook with at least one additional Ethernet port and Internet access

5.2 Software requirements

For commissioning and configuring your IO-Link Wireless Master, the following requirements must comply:

- Web browser if integrated netFIELD Wireless Web Server is to be used for configuration.
- DHCP server (at least required for first commissioning)



For further information see section *Configuration tools* [► page 23].

6 Mounting and demounting

6.1 Mounting

Required tools for mounting the device

You will need the following tools for mounting:

- Allen key for the M4 mounting screws with hexagon socket

Only additionally required for mounting without existing mounting holes:

- M4 thread tap (ready-made or set of taps)
- Drilling machine (to pre-drill the mounting holes as M4 threads for mounting the device to the system)

You will also need two M4 hexagon cylinder head screws according to DIN 912 / ISO 4762 of suitable length.

Before mounting the device

Always observe the following instructions:

- The device may only be mounted and commissioned by qualified electricians in accordance with EN 50110-1/-2 and IEC 60364.
- Refer to the safety instructions in the *Safety* [► page 13] chapter.
- Before mounting the device, check for damage, e.g. transport damage! Damaged devices must not be put into operation.

Mounting instructions

Observe the following points when selecting the mounting location:

- When mounting outside buildings: Mount the device in such a way that it is protected from weathering, especially from direct sunlight and the effects of UV light, salt water or salt spray, e.g. in a switch box.
- Only screw the device on flat contact surfaces to protect it from mechanical tension.
- Do not bridge any gaps with the device to protect it from any tensile forces that may occur.
- To prevent damage to the device, do not mount it in shearing areas of moving system parts. Also, lay the cables in such a way that they cannot be caught in the shear zones of moving system parts.
- Leave sufficient space for easy replacement of the device and for connecting the plug connections.
- Ensure that the requirements of the device for vibration and shock resistance are met at the mounting site.
- Mount the device so that the diagnostic LEDs of the device remain visible.

Observe the following instructions for the mounting procedure:

- Disconnect the system from the power supply before you start mounting.
- Ensure sufficient equipotential bonding in your system.
- During mounting, make sure that you do not soil the connections. Dirt will damage the contacts, resulting in reduced contact reliability.

Notes on protection against the heat generated by the device

The device can get hot during operation! Therefore, always observe the following instructions:

- The cooling of the device must not be impaired.
- Ensure an unobstructed air supply!
- Do not install the device near strong heat sources!
- Do not mount the device on or near highly inflammable materials.

Mounting of the device

You can attach the device directly to your system or in the control cabinet with screws. Fasten the device to a flat, solid base with two M4 screws, each of which is screwed into a mounting hole. Section *Technical data* [► page 130] contains the specification of the tightening torque.



Note:

Note that the device requires a connection to FE (functional earth) plate at the plastic housing via the screws.

The procedure for this is as follows:

- Hold the device in the desired position and mark the two points where the M4 threads are to be cut. Make sure that there is enough space around the device so that you can connect all cables without any problems.
- Cut an M4 thread at each of the two marked points with the M4 thread cutter, if necessary pre-drill with the drill first.
- Screw the device into the mounting holes with the Allen key using two M4 cylinder head screws of suitable length at the upper and lower ends. Observe the tightening torque.

After mounting

Observe the notes on *Grounding* [► page 19].

Mounting of the SMA antennas



Important:

For proper device operation, all three SMA antennas X1, X2, and X3 must be mounted.

6.1.1 Grounding

Functional earth

The L-coded M12 connectors of the power supply of the NFD-3090-EIS-IOLM\W device have a pin FE (functional earth). You can ground the device via FE of the power supply connection or via the screws to the FE plate at the plastic housing. Grounding the device is recommended.

6.2 Demounting

Required tools for demounting

For demounting, you need an Allen key to loosen the M4 hexagon socket head screws according to DIN 912 or ISO 4762.

Before demounting

Prepare for demounting:



⚠ CAUTION

Device is hot!

During operation, high surface temperatures can occur on the housing and at the metal connections, especially at the M12 connector sleeve. If the device was in operation, let it cool down before touching it or use gloves.

-
- Disconnect the part of the plant to which you have mounted the device from the power supply.
 - If the device is dirty, clean it first. It is particularly important to clean dirty screw connections.
 - Before demounting, loosen all screw connections at the terminals and disconnect the cables.

Demounting

To disassemble the device, e.g. when replacing the device, proceed as follows:

- Make sure that the part of the plant on which you have mounted the device is zero-potential.
- Use the Allen key to loosen the two M4 cylinder head screws.
- Remove the device.

After demounting

If the demounted device is defective, mark it as defective to prevent the device from being used again.

6.3 Disposal of waste electronic equipment

Important notes from the European Directive 2012/19/EU “Waste Electrical and Electronic Equipment (WEEE)”



Waste electronic equipment

This product must not be treated as household waste.

This product must be disposed of at a designated waste electronic equipment collecting point.

Waste electronic equipment may not be disposed of as household waste. As a consumer, you are legally obliged to dispose of all waste electronic equipment according to national and local regulations.

7 Connections

Warnings

- Adhere to the warnings hereafter before you connect the network cable and the power supply cable to the IO-Link Wireless Master NFD-3090-EIS-IOLMW device.



⚠ WARNING

Danger from electrical shock, SELV or PELV power supply required

Operate the device exclusively with 24 V DC SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) power supply. In case of ignoring this, there is a risk of electrical shock.

Always use two separate supply lines/power supplies for 1L and 2L to supply the devices. Pay attention to a central grounding (FE) if two separate power supplies are used.

NOTICE

Device destruction, fuse protection

The maximum supply current must not be exceeded and must be fused with an external fuse (16 A). Otherwise, the risk of device destruction cannot be excluded, damage to the printed circuit board and the connecting plug. For further details, refer to *Technical data* [► page 130].

Connection example with W-Bridge

The connection example described hereafter shows a typical installation that uses a W-Bridge to connect a wired IO-Link Device via a wireless connection to the IO-Link Wireless Master NFD-3090-EIS-IOLMW device. Section *Connection example with W-Bridge* [► page 22] shows a typical installation.

Requirements

- Use the cables described in section *Hardware and system requirements* [► page 16].

IO-Link Wireless Master

- Connect the Ethernet cable to the M12 connector Ethernet **X31** of the NFD-3090-EIS-IOLMW device, see position (32) in section *Device overview* [► page 7] and to the PLC.
- Connect the power cable (+24 V DC SELV or PELV) to the M12 connector PWR IN **X21** of the NFD-3090-EIS-IOLMW device, see position (25) in section *Device overview* [► page 7].

W-Bridge

- Connect the wired IO-Link Device with the cable to the W-Bridge.
- Connect the power cable (+24 V DC SELV or PELV) to the power connector of the W-Bridge.

7.1 Connection example




Figure 4: Connection example with W-Bridge

8 Configuration

8.1 Configuration tools

For operation, the NFD-3090-EIS-IOLM\W device requires configuration settings or parameters. The required settings or parameters can be grouped to several areas.

NFD-3090-EIS-IOLM\W device:

- EtherNet/IP connection,
- parameters for the IO-Link Wireless Master (e.g. track mode),
- parameters for the wireless port (e.g. wireless slot number).
- If the MQTT communication is used, then the MQTT Client in the NFD-3090-PNS-IOLM\W device requires MQTT Client parameters.

Connected IO-Link-Device:

- IO-Link-Device parameters.

To configure the device and to set parameters, you can use the following tools:

- **Configuration software of the EtherNet/IP Scanner:** The EtherNet/IP Scanner must be configured to exchange process data with the NFD-3090-EIS-IOLM\W device. The configuration software of the EtherNet/IP Scanner requires an EDS file to configure the device. The configuration software of the EtherNet/IP Scanner imports the EDS file, and the user can make the configuration settings and parameterizations for the device. The user loads the configuration to the EtherNet/IP Scanner. The EtherNet/IP Scanner performs the configuration and parameterization of the NFD-3090-EIS-IOLM\W device.
- **netFIELD Wireless Web Server:** A web browser can be used, to display the pages of the integrated web server. This user interface serves to set parameters during commissioning more easily. If the MQTT communication is to be used, the MQTT Client parameters are set via the netFIELD Wireless Web Server only.
- **IO-Link E.T.:** The IO-Link engineering tool serves also for device configuration, and can import IODD files of the used IO-Link Devices.

For the NFD-3090-EIS-IOLM\W device, the EDS file `HILSCHER-NETFIELD-WIRELESS-Vx.y.EDS` is available to be used in the configuration software for the EtherNet/IP Scanner for easy parameterization.

The possible tool chains for configuration are outlined below:

Configuration software for the EtherNet/IP Scanner + netFIELD Wireless Web Server (Tool chain 1)

- Configuration software for the EtherNet/IP Scanner: Configuration of the EtherNet/IP connection. If connection 1 is used, then the EtherNet/IP Scanner sends the wireless port parameters to the device. For all other connections, the EtherNet/IP Scanner sends no wireless port parameters to the device.
- netFIELD Wireless Web Server: Settings of the IO-Link Wireless Master parameters, the wireless port parameters, and if MQTT is used, settings of the MQTT Client parameters.



Note:

Each time the EtherNet/IP communication starts, the EtherNet/IP Scanner transmits the configuration and parameters to the NFD-3090-EIS-IOLM\W device. If using connection 1, then the wireless port parameters, which have been set by using the netFIELD Wireless Web Server, will be overwritten. The parameters set via EtherNet/IP Scanner have priority.

If connection 1 is used, and you want to change parameters for the wireless ports permanently, set them with the configuration software of the EtherNet/IP Scanner.

Configuration software for the EtherNet/IP Scanner + IO-Link E.T. (Tool chain 2)

- Configuration software for the EtherNet/IP Scanner: Configuration of the EtherNet/IP connection. If connection 1 is used, then the EtherNet/IP Scanner sends the wireless port parameters to the device. For all other connections, the EtherNet/IP Scanner sends no wireless port parameters to the device.
- IO-Link E.T.: Settings of the IO-Link Wireless Master parameters, the wireless port, and the IO-Link-Device parameters based on IODD file.
- If MQTT communication is used, netFIELD Wireless Web Server: Settings of the MQTT Client parameters.



Note:

Each time the EtherNet/IP communication starts, the EtherNet/IP Scanner transmits the configuration and parameters to the NFD-3090-EIS-IOLM\W device. If using connection 1, then the wireless port parameters, which have been set by using the IO-Link E.T., will be overwritten. The parameters set via EtherNet/IP Scanner have priority.

If connection 1 is used, and you want to change parameters for the wireless ports permanently, set them with the configuration software of the EtherNet/IP Scanner.

Overview Tool chains 1 and 2

	EtherNet/IP connection	Parameters for the IO-Link Wireless Master	Parameters for the wireless ports	IO-Link Device parameters	MQTT Client parameters (if the MQTT communication is used)
Tool chain 1					
Configuration software for the EtherNet/IP Scanner	Yes	-	Connection 1: yes Connection 2-10: -	-	-
netFIELD Wireless Web Server	-	Yes	Yes If connection 1 is used, then set the wireless port parameters in the configuration software for the EtherNet/IP Scanner.	(experts)	Yes
Tool chain 2					
Configuration software for the EtherNet/IP Scanner	Yes	-	Connection 1: yes Connection 2-10: -	-	-
IO-Link E.T.	-	Yes	Yes If connection 1 is used, then set the wireless port parameters in the configuration software for the EtherNet/IP Scanner.	Yes IODD	-
netFIELD Wireless Web Server to configure MQTT only	-	Use IO-Link E.T. only.	Use IO-Link E.T. only.	(experts)	Yes

Table 11: Overview Tool chains 1 and 2



For more details, refer to sections *Configuration with netFIELD Wireless Web Server* [► page 31], and *Configuring EtherNet/IP* [► page 26].

8.2 Configuring EtherNet/IP

In order that the EtherNet/IP Scanner and the EtherNet/IP Adapter exchanges process data, the EtherNet/IP Scanner has to be configured. Therefore, you need the device description file (EDS file) of the NFD-3090-EIS-IOLMW device:

```
HILSCHER-NETFIELD-WIRELESS-Vx.y.EDS
```

Perform the following steps:

- Import the EDS file into the configuration software of the EtherNet/IP Scanner.
- Select the **netFIELD** device from the device catalog and add it to the configuration project.
- For configuration of the netFIELD device, select a connection.
- Set the parameters.

8.2.1 Selecting a connection

The netFIELD Device offers several types of connections:

- Exclusive owner: The Scanner can read input process data and write output process data.
- Input only: The Scanner can read input process data only.
- Listen only: The Scanner can read input process data only. This connection requires that another Scanner has established an Exclusive Owner or an Input Only connection with the netFIELD device.

The max. number of usable IO-Link Devices (for wireless connection) depends on the number of IO-Link bytes the used IO-Link Device requires to transfer. In case, one or more IO-Link Devices require to transfer 17 or more IO-Link bytes, then max. 8 IO-Link Devices can be used. In case all IO-Link Devices requires 16 IO-Link bytes or less, then up to 16 IO-Link Devices can be used.

Connection	Name	Description
Connection 1	Exclusive Owner – 8 ports x 32 bytes	Up to 8 IO-Link Devices with up to 32 IO-Link bytes and one wireless track can be used. The EtherNet/IP Scanner sends the wireless IO-Link port parameters to the netFIELD Wireless IO-Link Master device.
Connection 2	Exclusive Owner – 8 ports x 32 bytes w/o Config	Up to 8 IO-Link Devices with up to 32 IO-Link bytes and one wireless track can be used. The wireless IO-Link port parameters have to be set using the netFIELD Wireless Web Server.
Connection 3	Listen Only – 8 ports x 32 bytes	Up to 8 IO-Link Devices with up to 32 IO-Link bytes and one wireless track can be used.
Connection 4	Input Only – 8 ports x 32 bytes	Up to 8 IO-Link Devices with up to 32 IO-Link bytes and one wireless track can be used.
Connection 5	Exclusive Owner - 16 ports x 16 bytes w/o Config	Up to 16 IO-Link Devices with up to 16 IO-Link bytes and two wireless tracks can be used. The wireless IO-Link port parameters have to be set using the netFIELD Web Wireless Server.
Connection 6	Listen Only - 16 ports x 16 bytes	Up to 16 IO-Link Devices with up to 16 IO-Link bytes and two wireless tracks can be used.
Connection 7	Input Only - 16 ports x 16 bytes	Up to 16 IO-Link Devices with up to 16 IO-Link bytes and two wireless tracks can be used.
Connection 8	Exclusive Owner - 16 ports x 4 bytes w/o Config	Up to 16 IO-Link Devices with up to 4 IO-Link bytes and two wireless tracks can be used. The wireless IO-Link port parameters have to be set using the netFIELD Web Wireless Server.
Connection 9	Listen Only - 16 ports x 4 bytes	Up to 16 IO-Link Devices with up to 4 IO-Link bytes and two wireless tracks can be used.
Connection 10	Input Only - 16 ports x 4 bytes	Up to 16 IO-Link Devices with up to 4 IO-Link bytes and two wireless tracks can be used.

Table 12: Connections

8.2.2 Setting parameters

In the configuration software of the EtherNet/IP Scanner you can set the parameters for the device netFIELD IO-Link Wireless Master EtherNet/IP Adapter NFD-3090-EIS-IOLMW. The existing parameters contain the basic settings for the device, which you adapt for your application. Set the device and port parameters in the start-up parameters of the configuration software of the EtherNet/IP Scanner. The EtherNet/IP Scanner sends these parameters to the NFD-3090-EIS-IOLMW device when starting the communication.

If using connection 1 the following parameters have to be set.

No.	Parameter name	Value range	Default	Description
10, 20, ...	Port mode	Deactivated	Deactivated	The W-port is inactive. Input and Output Process Data is 0.
		Cyclic		The W-port operates in cyclic mode.
		Roaming		The W-port operates in roaming mode.
11, 21, ...	Validation and backup	No Device check	No Device check	There is no device check for validation or backup of wireless connected IO-Link Devices (default).
		Type compare*, no Backup/Restore		A device check is performed for validation of wireless connected IO-Link Devices to the specified device type, without backup/restore.
		Type compare*, Restore only		A device check is performed for validation or restore of wireless connected IO-Link Devices to the specified device type, without backup. <i>Setting is not supported / reserved for future use.</i>
		Type compare*, Backup and Restore		A device check is performed for validation or backup/restore of the wireless connected IO-Link Devices to the specified device type. <i>Setting is not supported / reserved for future use.</i>
13, 23, ...	Port cycle time	0 ... 255	0	See table <i>Calculation of the port cycle time of the IO-Link Wireless Master</i> [► page 29].
14, 24, ...	Vendor ID	0 ... 65535	0	See ioddfinder.io-link.com , or the documentation of the manufacturer of the IO-Link Device used.
15, 25, ...	Device ID	1 ... 16777215	16777215	

Table 13: Parameters 10 to 85

No.	Parameter name	Value range	Default	Description
410, 430 ...	Slot number	0 ... 7	0	Wireless slot number to be used for the port
	Track number	0 ... 2	0	Wireless track number to be used for the port
	Device TX power	1 ... 31	31	This parameter contains the transmit power level of the W-Device
	Max retry	2 ... 31	8	Maximum number of retries for a transmission in OPERATE mode
	IMA time	1.664 ms ... 10 min	3 s	Requested I-Am-Alive time for the OPERATE mode See table <i>Calculation of I-Am-Alive time</i> [▶ page 30].
	Slot type	Single slot	Single slot	Slot type is "single slot"
		Double slot		Slot type is "double slot"
	Low power device	Not Low Power	Not Low Power	Is the connected W-Device low power or not
		Low Power		
	Max PD segment length	1 ... 32	2	This parameter contains the maximum segment length of the PDOOut data to the Message handler to distribute PDOOut Data within multiple W-Cycles.
	Unique ID – Byte 0	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 1	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 2	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 3	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 4	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 5	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 6	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 7	0 ... 255	0	UniqueID of the W-Device
	Unique ID – Byte 8	0 ... 255	0	UniqueID of the W-Device

Table 14: Parameters 410 to 566

Port cycle time

The parameter "Port cycle time" sets up the cycle time of a W-Port of the W-Master. The cycle time is encoded using "Time base" (bits 6+7) and "Multiplier" (bits 0-5) values, as shown in the following table:

Range of values	Time base (Bits 7+6)	Multiplier (Bits 5-0)	Resulting Cycle time
0	00	0	free-running mode
1 ... 64	00	1 ... 63	Note: If the free-running mode is chosen with a time base of 0, the W-Master stack will automatically configure the Master cycle time to be the Minimum Master cycle time based on the PD Segmentation length, Slot Type, and Max Retry configurations.
65 ... 127	01: 5ms	1 ... 63 as multiplier	5 ... 315 ms (Time Base * Multiplier) Note: For W-Devices and W-Bridges the minimum possible transmission time is 5 ms.
128 ... 255	10 ... 11: reserved	1 ... 63	reserved, do not use

Table 15: Calculation of the port cycle time of the IO-Link Wireless Master

I-Am-Alive time

The parameter "I-Am-Alive time" serves for W-Master and W-Device communication control if no other messages are transmitted. The W-Device has to send an "I-Am-Alive" messages to the W-Master before timeout, otherwise an error is reported, e.g. to start failsafe functionalities in the application.

The "I-Am-Alive time" is a 16-bit value. Bits 7–0 contain the "Time base" and bits 15–8 contain the "Multiplier".

The "I-Am-Alive time" is calculated by multiplying the "Time base" with the "Multiplier".

The following table shows the coding of the Time base.

Value	Time base	Description
0	Reserved	reserved, do not use
1	1.664 ms	Time base is 1.664 ms
2	5 ms	Time base is 10 ms
3	1 sec	Time base is 1 sec
4	1 min	Time base is 1 min
5 ... 255	Reserved	reserved, do not use

Table 16: Time base of I-Am-Alive time

The Multiplier has the value range of 1 ... 255.

The "I-Am-Alive time" is calculated by multiplying the "Time base" with the "Multiplier", as shown in the following table:

Multiplier (Bits 15-8)	Time base (Bits 7-0)	Calculated I-Am-Alive time	Value
1	1: 1.664 ms	1.664 ms	257
	2: 5 ms	5 ms	258
	3: 1 sec	1 sec	259
	4: 1 min	1 min	260
2	1: 1.664 ms	3.328 ms	513
	2: 5 ms	10 ms	514
	3: 1 sec	2 sec	515
	4: 1 min	2 min	516
3	1: 1.664 ms	4.992 ms	769
	2: 5 ms	15 ms	770
	3: 1 sec	3 sec	771
	4: 1 min	3 min	772
4 ... 254	1 ... 4	Multiplier * Time base	Value of Multiplier * 256 + value of Time base
255	1: 1.664 ms	424.32 ms	65281
	2: 5 ms	1275 ms	65282
	3: 1 sec	255 s	65283
	4: 1 min	255 min (10 min is used)	65284

Table 17: Calculation of I-Am-Alive time

The Wireless Master verifies the calculated "I-Am-Alive time" with the following limits:

- "Minimum I-Am-Alive time" = W-Sub-cycle duration [ms] * (MaxRetry + 1)
If the calculated "I-Am-Alive time" is less than the "Minimum I-Am-Alive time", the Wireless Master uses the "Minimum I-Am-Alive time" as resulting "I-Am-Alive time".
- Maximum I-Am-Alive time = 10 minutes
If the calculated "I-Am-Alive time" is greater than the "Maximum I-Am-Alive time", the error message `Port configuration failed HTTP Error 500: NetProxy returned with an error: C0000124` appears.

8.3 Configuration with netFIELD Wireless Web Server

This chapter describes how you can use the integrated netFIELD Wireless Web Server to access detailed information about the current operating status of the IO-Link Wireless Master device and the connected IO-Link Devices. You also can make settings for device parameterization to influence the device behavior.

8.3.1 Functional overview

The following overview shows you which functions are provided by the netFIELD Wireless Web Server integrated in the device and via which menu items or tabs of the user interface these functions can be accessed:

Menu	Tab	Description	Section
Dashboard	-	Display of device-specific information	<i>Dashboard</i> [▶ page 33]
Licenses	-	Display of the used software components	<i>Licenses</i> [▶ page 34]
IO-Link Wireless Master settings	Channel Selection	WLAN channel list	<i>Channel Selection</i> [▶ page 35]
	Configuration	Configure parameters of the IO-Link Wireless Master	<i>Configuration</i> [▶ page 38]
	Scan	Scan for unconnected IO-Link Devices	<i>Scan and pairing</i> [▶ page 40]
Wireless port WP01, WP02, WP03 ...	(all)	Port-specific information and settings for the wireless IO-Link ports WP01, WP02, WP03 ...	<i>Device or port information</i> [▶ page 42]
	Information	Displays device information on the connected IO-Link Device	<i>Device information</i> [▶ page 43]
	Status	Displays port status information	<i>Port status</i> [▶ page 44]
	Settings	Display (and setting) of port parameters.	<i>Port settings</i> [▶ page 52]
	ISDU	Display of device Index Service Data Units	<i>Device ISDU</i> [▶ page 46]
		Display of master Index Service Data Units	<i>Master ISDU</i> [▶ page 48]
Settings	Process data	Displays the process data (input/output)	<i>Process data</i> [▶ page 51]
	(all)	Device settings	<i>Device settings</i> [▶ page 51]
	Settings	Setting of port parameters (such as port mode, Unique ID, IMA Time, etc.)	<i>Port settings</i> [▶ page 52]
	Device configuration	Configure parameters for IP connection	<i>IP parameters</i> [▶ page 57]
	Maintenance information	Store maintenance information	<i>Maintenance information</i> [▶ page 58]
	Firmware update	Update the firmware of the device	<i>Firmware update</i> [▶ page 59]
	Factory reset	Reset the device to factory settings	<i>Factory settings</i> [▶ page 62]
	MQTT	Client and connection configuration	<i>MQTT configuration</i> [▶ page 63]
User administration	-	Set up and manage users	<i>Log in or User administration</i> [▶ page 68]
Sign-in, Sign-out	-	User login and logout	

Table 18: Functional overview of the netFIELD Wireless Web Server for IO-Link Devices

8.3.2 Open netFIELD Wireless Web Server

Prerequisite: To open the user interface of the netFIELD Wireless Web Server, the IP address of the device must be configured and known.



Note:

Make sure that the PC on which you want to access the website of the netFIELD Wireless Web Server and the device you want to connect to are both on the same Ethernet subnet.

Proceed as follows:

- Enter the following text in the address line of your web browser to address the device: `http://<Configured IP Address>` e.g.
`http://192.168.10.2`
- ⇒ The page Dashboard of the netFIELD Wireless Web Server appears. You can now use the functions described below.

8.3.3 Dashboard




Figure 5: Dashboard page (example)

When opening the user interface, the Dashboard page appears first. On the Dashboard page, the following device-specific information is displayed:

Area	Information displayed
Top left corner	Shows the current user role and device connection state.
Left column	Navigation area; icons on errors or operating states may appear here.
Vendor information	Contact details of the device manufacturer
Device information	The name, part and version number, MAC address of the hardware
IO-Link Wireless technology	Specification of the radio connection
Device version	The name and version number of the device, the Master and the radio module, the web page version.
Maintenance information	Maintenance information in text form

Table 19: Data on "Dashboard" page

Maintenance information

Maintenance information includes textual information that the user can specify, such as device name, installation location and date, contact information, description, date of last and next service of the device. These texts can be edited using the **Maintenance information** tab of the **Settings** menu (see *Maintenance information* [▶ page 58]).

8.3.4 Licenses

The **Licenses** menu item allows you to display the page of the same name. This shows you:

- a list of the licensed software components contained in the product,
- for each licensed software component, a link to the associated license conditions.

8.3.5 IO-Link Wireless Master settings

The netFIELD Wireless Web Server provides the IO-Link Wireless Master settings with the tabs Channel Selection, Configuration and Scan.

- Select **Master**, to display the tabs.
- The **Channel Selection** tab allows you to select the WLAN channels required for device operation.
- On the **Configuration** tab, you can make the IO-Link Wireless Master configuration settings. This includes the specific master settings parameters, the activating or deactivating of wireless tracks WT1 ... WT3, as well as specification of the track transmission power.
- On the **Scan** tab, you can scan for unconnected IO-Link Devices. A scan result then shows the found devices. Each of them must be paired to one of the 16 wireless IO-Link ports (WP01, Wp02, WP03, ...).

8.3.5.1 Channel Selection

- Select **Master** in the left column of the netFIELD Wireless Web Server.
- The **Channel Selection** tab appears.




Figure 6: Channel selection tab

Use the Channel Selection tab to select the WLAN channels required for operation.



Parameter	Description	Value, Value range
WLAN Channel 01 ... WLAN Channel 13	<div>List of WLAN channels 01 to 13 on the 2.4 GHz frequency band.</div> <div>The radio symbols indicate whether a channel is activated and if fully or partly.</div> <div>Use mouse over to indicate the help text.</div> <div> WLAN Channel <input checked="" type="checkbox"/> fully activated</div> <div> WLAN Channel <input type="checkbox"/> partly activated</div>	"checked", "unchecked" (default)

Table 20: IO-Link Wireless Master settings - Channel selection

- Select the operating channels required for device operation.
- Click **Apply**.
- The selected WLAN channels are configured.

Expert settings

The expert mode allows a refinement of the transmission frequencies to be used. Here, each individual operating channel can be activated or deactivated. Since the list of operating channels is based on the WLAN channels, there are overlaps. When activating/deactivating the operating channels, these overlaps are automatically taken into consideration.

The complete range of wireless operating channels comprises 80 bitwise coded 1 MHz frequency channels.

- The wireless channels 1 (2401 MHz), 2 (2402 MHz), 79 (2479 MHz) and 80 (2480 MHz) are used for network configurations and cannot be configured.
- The wireless channels 3-78 (2403 ... 2478 MHz) can be configured to be used or not for IO-Link wireless communication within a Wireless Master. Frequency Hopping is used for transmission on different frequency channels on the 2.4 GHz Band frequency.



Note:

The ranges of wireless operating channels assigned to each of the WLAN channels 01 to 13 overlap each other. In consequence, if an 1 MHz frequency channel option is configured for one WLAN channel, this will have effect on the corresponding 1 MHz frequency channel that is also assigned to a WLAN channel in the neighborhood.



Important:

The use of this mode is for experts only!

- Check **Expert settings**.
- 🔗 The following view appears with configuration options of each single MHz frequency.

Figure 7: Channel selection tab, Expert settings (example)

8.3.5.2 Configuration

- Select **Master** in the left column of the netFIELD Wireless Web Server.
- Then select the **Configuration** tab.

Figure 8: Master > Configuration tab

Use the Master > Configuration tab to view or adapt the IO-Link Wireless Master settings:


Parameter	Description	Value, Value range
Master ID	Master identifier	1 ... 29, 0: when not yet configured
Pairing Timeout	Timeout for pairing in seconds.	5 ... 60, 0: when not yet configured
Advanced Connectivity	Wireless functionalities	
	Adaptive Hopping Table: Basically this option is an enhancement to Frequency Division Multiple Access (FDMA) technology. If "checked", this option is used.	"checked", "unchecked" (default)
	Reconnect: If "checked", reconnection trials will be performed when connections are lost.	"checked" (default), "unchecked"
WT1 Track Mode ... WT3 Track Mode	Operating mode of wireless track <ul style="list-style-type: none"> Stop: track is inactive, Cyclic: track is in cyclic only mode and can't perform service operations, Service: track is in service mode, meaning, cyclic mode that can perform service operations like scan/pair, Roaming Auto NOTE: Only 1 track can be in Roaming or Service mode.	Stop, Cyclic, Service, Roaming, Auto, Default: Stop

Parameter	Description	Value, Value range
WT1 TXPower... WT3 TXPower	Transmission power The maximum allowable value for the TX Power parameter is selected by the IO-Link Wireless Master.	1 ... 31, Default: 31

Table 21: IO-Link Wireless Master settings - Configuration

- Make settings for the parameters “Master ID”, “Pairing Timeout”, “Advanced Connectivity”, “WT1 Track Mode ... WT3 Track Mode”, and “WT1 TXPower ... WT3 TXPower”.
- Click **Apply**.
- The request appears Applying configuration will restart the device. Are you sure?
- Click **Yes**.
- Wait until reset operation is finished and result is shown:
- The message Master configured successfully appears.

“Master configuration failed” error handling

When the IO-Link Wireless Master went to an error status, a red triangle icon  appears for Master in the left column of the netFIELD Wireless Web Server and the message Master configuration failed. For trouble shooting:

- Delete the Master configuration.
- Perform a device reset.

For further information, refer to *Configuring the IO-Link Wireless Master* [▶ page 73].

8.3.5.3 Scan and pairing

- Select **Master** in the left column of the netFIELD Wireless Web Server.
- Open the **Scan** tab.

The screenshot shows the 'Scan' tab of the netFIELD Wireless Web Server. At the top, there are three tabs: 'Channel Selection', 'Configuration', and 'Scan'. The 'Scan' tab is active. Below the tabs, there is a 'TxPower' dropdown menu with the value '31' selected. Below the dropdown is a 'Scan start' button.

Figure 9: Scan tab

Use the Scan tab, to scan for unconnected devices.

- Select **TxPower**.

The value range of “TxPower” (Transmission power) is “1 ... 31” and the default value “31”.

- Click **Scan start**.

- The system searches for unconnected devices. The scan result is being displayed after a while.

The screenshot shows the 'Scan' tab with the 'Scan start' button clicked. A green banner displays 'Scan finished: 1 device(s) found'. Below the banner is a table with the following data:

Index	Unique ID	Slot Type	Revision ID	Port	Pairing
0	0x03, 0xf3, 0x00, 0x00, 0x01, 0x72, 0xc0, 0x45, 0xcf	Double slot	0x11	Select port	Pair

Figure 10: Scan tab, scan result

Parameter	Description	Value, Value range
Index	Device index	0 ... 20
Unique ID	Identification of the found IO-Link Device as unique ID (UUID, 9 Bytes). Copy/note the unique ID. This value is required for port configuration.	0 ... 0xFF
Slot Type	Slot type of the found device	Single slot, Double slot, Default: Single slot
Revision ID	Revision ID of the found device This parameter is specified by the found device. It indicates software revision running on the found device.	0: No device connected, Others: Software revision running on the found device


Parameter	Description	Value, Value range
Port	ID of wireless IO-Link port to which the IO-Link Device is to be paired. Note: For a device featuring “Double slot” an even port must be assigned. Otherwise the error message appears: “Pairing failed HTTP Error 500:NetProxy returned with an error: C0000124”	WP01 ... WP16
Pairing	A pairing service is provided to pair a found IO-Link Device to a wireless IO-Link port of the IO-Link Wireless Master.	Pair (green), Unpair (red), Default: Pair (green)

Table 22: Scan result, pairing


The scan result includes a textual description: “Scan finished: *[number of found devices]* device(s) found”. For scan errors appears: “Scan failed HTTP Error *[error number]*: *[short description of error]*” plus a further message in the upper part of the scan tab.

Pairing / unpairing

For pairing an IO-Link Device to a wireless IO-Link port of the IO-Link Wireless Master device during device commissioning:

- In the Scan tab in the scan result, select the **Port**.
- Click .
- Pairing is performed and “Pair” (green) switches to “Unpair” (red). The message `Pairing succeeded` appears.

You can change made pairing setting as follows:

- To unpair an IO-Link Device and a paired wireless IO-Link port, click . The message `Unpairing succeeded` appears.

For further information, refer to *Configuring the IO-Link Wireless Master* [► page 73].

8.3.6 Device or port information

In the port specific tabs Information, Status, Settings, ISDU, and Process Data, you can display device or port information individually for each of the wireless IO-Link ports of the IO-Link Wireless Master device. In the Settings tab you also can make port-specific settings, see *Port settings* [▶ page 52].

Access the tabs as follows:

- In the left-hand column, click on the wireless IO-Link port **WP01**, **WP02**, **WP03**, ...
- The Information tab of the corresponding wireless IO-Link port appears.
- To open another tab, click **Status**, **Settings**, **ISDU**, or **Process Data**.

Tab	Description
Information	Displays some "Device information" of the IO-Link Device (Min cycle time, Function ID, Number of profile IDs, Vendor name, Vendor text, Product name, Product ID, Product text, Serial number, Hardware revision, Firmware revision).
Status	Displays port status information (Port state, Port quality, Revision ID, Master cycle time, Input data length, Output data length, Vendor ID, Device ID, Signal quality). This tab shows current settings.
Settings	Display and setting of port parameters (Port mode, Port cycle time, Validation and backup, Vendor ID, Device ID, Low power device, Max PD segment length, Unique ID, Slot number, Track number, Device TX power, Max retry, Slot type, IMA Time), see <i>Port settings</i> [▶ page 52]. This tab shows current settings.
ISDU	Display of the Index Service Data Units: <ul style="list-style-type: none"> • Read/write access to parameters of the connected IO-Link Device. • Read/write access to parameters of the IO-Link Wireless Master device.
Process Data	Display of the process data (input/output)

Table 23: Information, Status, Settings, ISDU, or Process Data

8.3.6.1 Device information

The Information tab displays some “Device information” of the IO-Link Device connected to a wireless IO-Link port. The official IO-Link SMI layer does not provide this information.

- In the left column of the netFIELD Wireless Web Server, select the wireless IO-Link port with the connected IO-Link Device.
- The **Information** tab appears with the device information of the connected device.




Figure 11: Information tab, Device information (example)

Parameters	Description	Value / Value range
Min cycle time	Minimum cycle duration supported by a Device. This is a performance feature of the Device and depends on its technology and implementation.	0 ... ms
Function ID	Function ID of connected device.	
Number of profile IDs	Provides the number of ProfileIDs contained in the ProfileCharacteristic (index 0x000D) of the connected device. The complete list the ProfileIDs has to be read using common OnRequestData Read mechanism.	
Vendor name	Detailed name of vendor of connected device.	Character string (up to 64 characters)
Vendor text	Additional vendor information of the connected device.	Character string (up to 64 characters)
Product name	Detailed product or type name of the connected device.	Character string (up to 64 characters)
Product ID	Product or type identification of connected device.	Character string (up to 64 characters)
Product text	Description of function or characteristic of connected device.	Character string (up to 64 characters)
Serial number	Vendor specific serial number of connected device.	Character string (up to 16 characters)
Hardware revision	Revision of hardware of connected device in a vendor specific format.	Character string (up to 64 characters)
Firmware revision	Revision of firmware in connected device in a vendor specific format.	Character string (up to 64 characters)

Table 24: Information tab, with Device information

8.3.6.2 Port status

- Select the wireless IO-Link port in the left column of the netFIELD Wireless Web Server.
- Open the **Status** tab.
- ⇒ The current values for the status data of the selected wireless IO-Link port appear.




Figure 12: Status tab, Port status (example)

Parameter	Description	Value, Value range
Port state	Current port state of wireless IO-Link port Descriptions of the possible values are listed in table <i>Port state, possible values</i> [▶ page 45].	Pairing success, Pairing timeout, Pairing wrong slot type, Inactive, Port ready, Communication ready, Operate, Communication lost, Revision fault, Compatibility fault, Serial number fault, Process data fault, Cycle time fault
Port quality	Status information of process data Input process data is valid, Input process data is not valid Output process data is valid, Output process data is not valid	PDI valid, PDI invalid, PDO valid, PDO invalid
Revision ID	Revision ID of the connected device This parameter is specified by the connected device. It indicates software revision running on the connected device.	0: No device connected Others: Revision ID of connected device
Master cycle time	Cycle time of communication in Operate mode The Master cycle time is a Master parameter and sets up the actual cycle time of a particular wireless IO-Link port. “Free running”: The Minimum Master cycle time is configured, based on the PD Segmentation length, Slot Type and Max Retry configurations.	“Free running”, 5 ms ... 315 ms
Input data length	Real input data length of connected device in bytes	0 ... 32
Output data length	Real output data length of connected device in bytes	0 ... 32
Vendor ID	Vendor ID of the connected IO-Link Device	0 ... 0xFFFF, Default: 0
Device ID	Device ID of the connected IO-Link Device	0 ... 0xFFFFF, Default: 0
Signal quality	Signal quality gives a relative indication on strength of radio connection between IO-Link Wireless Master device and the connected IO-Link Device. The indicated value does not change during runtime.	0% ... 100%

Table 25: Port status, overview

The Status tab with port status data provides answers to the questions:

- What is the current port state of the wireless IO-Link port?
- Is the process data valid for input or output?

Further port status values are displayed.

The following table contains all possible values for the Port state:

Value	Description
Pairing success	Device is connected to the port via radio and there is wireless communication with the connected device.
Pairing timeout	A timeout has occurred for the connection from this port to the device.
Pairing wrong slot type	A wrong slot type is used for the connection from this port to the device.
Inactive	The port is inactive.
Port ready	The port is ready.
Communication ready	The device is ready for communication.
Operate	The device is in communication.
Communication lost	The communication to the device is broken down.
Revision fault	An error was found during revision check.
Compatibility fault	An error was found during compatibility check.
Serial number fault	An error was found during serial number check.
Process data fault	An error was found during process data check.
Cycle time fault	The configured cycle time does not match the connected device.

Table 26: Port state, possible values

8.3.6.3 Device ISDU

The ISDU tab allows read and write access to the IO-Link Device connected to a wireless IO-Link port by means of `Index` and `Subindex`. The ISDU message format is used for this.

Figure 13: Display of the On Request Data, read/write IO-Link Device parameters



For the meaning of the `Index` and `Subindex` values, refer to the documentation of the connected IO-Link Device. For a description of the ISDU message format, refer to the IO-Link specification.

Required rights

Changes to settings require operator or admin rights. If these are not available, the ISDU tab is grayed out and the displayed values cannot be edited.

Access to IO-Link Device

To access the data of an IO-Link Device connected to the selected wireless IO-Link port via `Index` and `Subindex` (ISDU message format):

- Select the wireless IO-Link port to which the IO-Link Device is connected in the menu on the left.
- Open the **ISDU** tab.
- The ISDU tab is displayed.

Read access to IO-Link Device

To read data from the connected IO-Link Device, proceed as follows:

- Enter the `Index` for ISDU access as a hexadecimal value in the **Index** entry field.
- Enter the `Subindex` for ISDU access as a hexadecimal value in the **Subindex** entry field. The default value here is `00`.
- 🔗 In case of input errors, an error message appears.
- Click on **Read**.
- 🔗 The read access is executed. An entry with a time stamp is written to the history at the bottom of the ISDU tab.

If the execution was successful, the text `Read ok:` and the result is displayed in the history. The entries in the history then have the following structure:

```
Time - Index:Subindex - Read ok: <Result>
```

If the execution was not successful, an error message with error codes of the IO-Link Wireless Master and IO-Link Device is displayed in the history.

In this case, the entries in the history have the following structure:

```
Time - Index:Subindex - Read failed:
IOLMErrorCode(<error code of the IO-Link master>):
IOLDErrorCode(<error code of the IO-Link Device>)
```



Information on the meaning of the error codes of the IO-Link master (IOLMErrorCode) and device (IOLDErrorCode) can be found in the IO-Link specification.

The following applies in both cases:

- The `Time` is displayed in the format `HH:MM:SS`
- `Index` and `Subindex` are displayed in hexadecimal format.

Write access to IO-Link Device

To write data to the connected IO-Link Device, proceed as follows:

- Enter the `Index` of the connected IO-Link Device that you want to access as a hexadecimal value in the **Index** entry field.
- Enter the `Subindex` of the connected IO-Link Device that you want to access as a hexadecimal value in the **Subindex** entry field. The default value here is `00`.
- 🔗 In case of input errors, an error message appears.
- Enter the data to be written (in hexadecimal, without spaces, e.g., `0102030405`) in the **Write data** entry field.
- Click on **Write**.
- 🔗 The write access is performed.

If the execution was successful, the text `Write ok:` and the result is displayed in the history. The entries in the history then have the following structure:

```
Time - Index:Subindex - Write ok: <Result>
```

If the execution was not successful, an error message with error codes of the IO-Link Wireless Master and IO-Link Device is displayed in the history. The entries in the history then have the following structure:

```
Time - Index:Subindex - Write failed:
IOLMErrorCode(<error code of the IO-Link master>):
IOLDErrorCode(<error code of the IO-Link Device>)
```

Delete the history of read and write accesses

To clear the logged history of read and write accesses:

- Click **Clear history**.
- ⇒ The history of read and write accesses is deleted.

8.3.6.4 Master ISDU

The ISDU tab with the option Tigo Master Parameters enabled allows read and write access to the IO-Link Wireless Master device, by means of `PortId` and `ArgBlockId`. The ISDU message format is used for this.

The screenshot shows the 'ISDU' tab in a software interface. At the top, there are five tabs: 'Information', 'Status', 'Settings', 'ISDU' (active), and 'Process Data'. Below the tabs, there is a toggle switch for 'Tigo Master Parameters' which is turned on. Below this, there are three input fields: 'PortId (in hex)' (empty), 'ArgBlockId (in hex)' (containing '00'), and 'ArgBlockData (in hex without spaces)' (empty). Below the input fields are three buttons: 'Read', 'Write', and 'Clear History'. At the bottom, there is a 'History list' section containing two entries:

```
08:57:04 - 1:8090:112233 - VsWrite OK: ArgBlockId(FFF0):ArgBlockData()
08:57:11 - 1:8090 - VsRead OK: ArgBlockId(8090):ArgBlockData(11223300000000000000)
```

Figure 14: Display of the ISDU, read/write IO-Link Wireless Master parameters

Required rights

Changes to settings require operator or admin rights. If these are not available, the ISDU tab is grayed out and the displayed values cannot be edited.

Access to IO-Link Wireless Master device

To access the data of the IO-Link Wireless Master via PortId and ArgBlockId (ISDU message format):

- In the menu on the left, select the wireless IO-Link port of the IO-Link Wireless Master to which an IO-Link Device is connected.
- Open the **ISDU** tab.
- The ISDU tab is displayed.
- Enable **Tigo Master Parameters**.
- The Tigo Master Parameters tab variant is displayed.

Read access to IO-Link Wireless Master device

To read data from the IO-Link Wireless Master device, proceed as follows:

- Enter the `PortId` of the IO-Link Wireless Master device that you want to access as a hexadecimal value in the **PortId** entry field.
- Enter the `ArgBlockId` of the IO-Link Wireless Master that you want to access as a hexadecimal value in the **ArgBlockId** entry field. The default value here is 00.
- In case of input errors, an error message appears.
- Click on **Read**.
- The read access is executed. An entry with a time stamp is written to the history at the bottom of the ISDU tab.

If the execution was successful, the text `Read ok:` and the result is displayed in the history. The entries in the history then have the following structure:

```
Time - PortId:ArgBlockId - Read ok: <Result>
```

If the execution was not successful, an error message with error codes of the IO-Link Wireless Master and IO-Link Device is displayed in the history.

In this case, the entries in the history have the following structure:

```
Time - PortId:ArgBlockId - Read failed:
IOLMErrorCode(<error code of the IO-Link master>):
IOLDErrorCode(<error code of the IO-Link Device>)
```



Information on the meaning of the error codes of the IO-Link master (IOLMErrorCode) and device (IOLDErrorCode) can be found in the IO-Link specification.

The following applies in both cases:

- The `Time` is displayed in the format `HH:MM:SS`
- `PortId` and `ArgBlockId` are displayed in hexadecimal format.

Write access to IO-Link Wireless Master device

To write data to the IO-Link Wireless Master device, proceed as follows:

- Enter the `PortId` of the IO-Link Wireless Master that you want to access as a hexadecimal value in the **PortId** entry field.
- Enter the `ArgBlockId` of the connected IO-Link Device that you want to access as a hexadecimal value in the **ArgBlockId** entry field. The default value here is `00`.
- ⇒ In case of input errors, an error message appears.
- Enter the data to be written (in hexadecimal, without spaces, e.g., `0102030405`) in the **ArgBlockData** entry field.

Write example: `PortId = 01`, `ArgBlockId = B090`, `ArgBlockData = 01020304`

- Click on **Write**.
- ⇒ The write access is performed.

If the execution was successful, the text `Write ok:` and the result is displayed in the history. The entries in the history then have the following structure:

```
Time - PortId:ArgBlockId - Write ok: <Result>
```

If the execution was not successful, an error message with error codes of the IO-Link Wireless Master and IO-Link Device is displayed in the history. The entries in the history then have the following structure:

```
Time - PortId:ArgBlockId:Data - Write failed:  
IOLMErrorCode(<error code of the IO-Link master>):  
IOLDErrorCode(<error code of the IO-Link Device>)
```

Delete the history of read and write accesses

To clear the logged history of read and write accesses:

- Click **Clear history**.
- ⇒ The history of read and write accesses is deleted.

8.3.6.5 Process data

You can display the process data belonging to a specific wireless IO-Link port using the Process data tab.

To display the process data for a port:

- Select the wireless IO-Link port in the left column of the netFIELD Wireless Web Server.
- Open the **Process data** tab.
- ⇒ The current values of process data configured for input or output are displayed in hexadecimal format under input or output.




Figure 15: Display of the Process Data

The Process Data tab shows the process data input and output values from and to a connected IO-Link Device:

Parameter	Description
PD input data	“Process Data” input data to the connected IO-Link Devices
PD input valid	Binary coded Port Qualifier for Input
PD output data	“Process Data” output data from the connected IO-Link Devices
PD output valid	Validation information for process data output. If Output Enable flag is set, data will be valid.

Table 27: Process data, parameters

If no process data has been configured for a data direction (input or output), the corresponding field remains empty.

8.3.7 Device settings

Using the netFIELD Wireless Web Server, you can make the several settings on the device. Open the panes via the left column of the netFIELD Wireless Web Server.

- Select the wireless IO-Link port (**WP01**, **WP02**, **WP03** ...) and open the **Settings** tab to make the port settings (see section *Port settings* [▶ page 52]).
- Select **Settings** in the left column and open the corresponding tab:
 - Device information (with menu on the *IP parameters* [▶ page 57]),
 - *Maintenance information* [▶ page 58],
 - *Firmware update* [▶ page 59],
 - *Factory settings* [▶ page 62],
 - *MQTT configuration* [▶ page 63].
- Select **Sign in** or **User administration** to access to the *Log in or User administration* [▶ page 68].

8.3.7.1 Port settings

Use the Settings tab to view and change the port settings individually.

- Select the desired wireless port (WP01, WP02, WP03, ...) in the left column of the netFIELD Wireless Web Server.
- Open the **Settings** tab with its sub tabs.
- The Port cycle sub tab appears by default.

Settings > Port cycle

Figure 16: Settings tab, Port cycle sub tab (example)

Parameter	Description	Value / Value range
Port mode	Operating mode of IO-Link port <ul style="list-style-type: none"> Deactivated: The port is inactive, Input and Output Process Data is 0. Cyclic Roaming 	Deactivated, Cyclic, Roaming, Default: Deactivated
Port cycle time	Port cycle time expected by the SMI client The expected cycle time of the port is set depending on the selected operating parameters.	See table <i>Calculation of the port cycle time of the IO-Link Wireless Master</i> [► page 53].
	Time base: Used time base for the calculation of the port cycle time.	Free running, 5 ms
	Time multiplier: Used factor for the calculation of the port cycle time.	0 ... 63

Table 28: Settings in port configuration for IO-Link Device, Port cycle sub tab

* Values are in hexadecimal

- Configure port operating mode **Port mode** by selecting the corresponding option.
- Configure the "Port cycle time".

The parameter "Port cycle time" sets up the cycle time of a W-Port of the W-Master. The cycle time is encoded using "Time base" (bits 6+7) and "Multiplier" (bits 0-5) values, as shown in the following table:

Range of values	Time base (Bits 7+6)	Multiplier (Bits 5-0)	Resulting Cycle time
0	00	0	free-running mode
1 ... 64	00	1 ... 63	Note: If the free-running mode is chosen with a time base of 0, the W-Master stack will automatically configure the Master cycle time to be the Minimum Master cycle time based on the PD Segmentation length, Slot Type, and Max Retry configurations.
65 ... 127	01: 5ms	1 ... 63 as multiplier	5 ... 315 ms (Time Base * Multiplier) Note: For W-Devices and W-Bridges the minimum possible transmission time is 5 ms.
128 ... 255	10 ... 11: reserved	1 ... 63	reserved, do not use

Table 29: Calculation of the port cycle time of the IO-Link Wireless Master

- Select the **Time base** and the **Time multiplier** for the “Port cycle time” calculation.
- The result is indicated as value or text in brackets, e.g. Port cycle time (Free running).

Settings > Validation level

- Open the **Validation level** sub tab.

Settings tab, Validation level sub tab (example)

Parameter	Description	Value / Value range
Validation and backup	The table below contains descriptions for the possible values for the inspection level to be performed by the device and the Backup/Restore behavior:	Default: No device check
Vendor ID*	Expected Vendor ID of connected device This information is required to check the device for type compatibility.	0 ... 0xFFFF, Default: 0
Device ID*	Expected Device ID of connected device This information is required to check the device for type compatibility.	1 ... 0xFFFFFFFF, Default: 0xFFFFFFFF

Table 30: Settings in port configuration for IO-Link Device, Validation level sub tab

- * Values are in hexadecimal
- Under **Validation and backup**, configure possible values for the inspection level to be performed by the device and the Backup/Restore behavior.

Value	Description
No device check	There is no device check for validation or backup of connected IO-Link Devices
Type compare*, no Backup/Restore	A device check is performed for validation of connected IO-Link Devices to the specified device type, without backup/restore.
Type compare*, Restore only	A device check is performed for validation or restore of connected IO-Link Devices to the specified device type, without backup. <i>Setting is not supported / reserved for future use.</i>
Type compare*, Backup and Restore	A device check is performed for validation or backup/restore of connected IO-Link Devices to the specified device type. <i>Setting is not supported / reserved for future use.</i>
*Type compare means compare DeviceID and VendorID from the configuration object with the real device values.	

Table 31: Validation and backup, possible values

- If necessary, set the expected port parameters Vendor ID and Device ID.

Settings > Transmission

- Open the **Transmission** sub tab.

Settings tab, Transmission sub tab (example)

Parameter	Description	Value / Value range
Max PD Segment Length	This parameter contains the maximum segment length of the PDO data to the message handler to distribute PDO data within multiple wireless cycles. The maximum value depends by the actual transmission capacity of the used IO-Link Device.	1 ... 32 Byte, Default: 2
Slot number	Wireless slot number to be used for the port	0 ... 7, Default: 0
Track number	Wireless track number to be used for the port	0, 1, 2, Default: 0
Device TX power	This parameter contains the transmit power level of the W-Device	1 ... 31, Default: 31
Max retry	Maximum number of retries for a transmission in OPERATE mode "Unknown" is indicated if there is no value available.	2 ... 31, Default: 8

Table 32: Settings in port configuration for IO-Link Device, Transmission sub tab

* Values are in hexadecimal

- If necessary, set the expected port parameters Max PD Segment Length, Slot number, Track number, Device TX power or Max retry.

Settings > Miscellaneous

- Open the **Miscellaneous** sub tab.

Settings tab, Miscellaneous sub tab (example)

Parameter	Description	Value / Value range
Unique ID*	Unique ID of the IO-Link Device (9 Bytes) Use the Unique ID (UUID) from the scan result.	0 ... 0xFF, Default: 0
Slot type	Slot type of the found device Use the slot type from the scan result. Note: For a device featuring "Double slot" an even number must be assigned as value for the slot.	Single slot, Double slot, Default: Single slot
IMA Time 3 sec (calculated time)	Requested I-Am-Alive time for the OPERATE mode The I-Am-Alive time is calculated by multiplying the "time base" with the "time multiplier".	1.664 ... 10 min (for higher values an error message appears), Default: 3 sec
	Time base: Used time base for the calculation of the I-Am-Alive time.	1.664 ms, 5 ms, 1 sec, 1 min
	Time multiplier: Used factor for the calculation of the I-Am-Alive time.	1 ... 255
Low power device	Is the connected IO-Link Device a low power device or not	No, Yes, Default: No

Table 33: Settings in port configuration for IO-Link Device, Miscellaneous sub tab


* Values are in hexadecimal

- To configure the Unique ID, use the Unique ID (UUID) from the scan result.
- If necessary, set the expected port parameters Slot type or Low power device.
- Configure the "IMA Time" (I-Am-Alive time).

The parameter "I-Am-Alive time" serves for W-Master and W-Device communication control if no other messages are transmitted. The W-Device has to send an "I-Am-Alive" messages to the W-Master before timeout, otherwise an error is reported, e.g. to start failsafe functionalities in the application.

The "I-Am-Alive time" is calculated by multiplying the "Time base" with the "Multiplier".

The Wireless Master verifies the calculated "I-Am-Alive time" with the following limits:

- "Minimum I-Am-Alive time" = W-Sub-cycle duration [ms] * (MaxRetry + 1)
If the calculated "I-Am-Alive time" is less than the "Minimum I-Am-Alive time", the Wireless Master uses the "Minimum I-Am-Alive time" as resulting "I-Am-Alive time".
- Maximum I-Am-Alive time = 10 minutes
If the calculated "I-Am-Alive time" is greater than the "Maximum I-Am-Alive time", the error message `Port configuration failed HTTP Error 500: NetProxy returned with an error: C0000124` appears.
- Select the **Time base** and the **Time multiplier** for the "IMA Time" calculation in order to avoid exceeding the maximum allowed value.
- The result is indicated as value in brackets.
- Click **Apply**.
- ⇒ Your changes now take effect. The message `Port configured successfully` appears and a green hook  appears for the selected port in the left column of the netFIELD Wireless Web Server, indicating that a connection from an IO-Link Device to this wireless IO-Link port has been established, and that the IO-Link Device is in "operate" state.



Note:

The green hook icon disappears if the IO-Link Wireless Master changes to an error state but the device connection is still established and in "connected" state (shown on top left corner of the netFIELD Wireless Web Server). If the device connection drops and the "disconnected" state is shown, the green hook icon is still visible and reflects the latest status obtained from the device.

8.3.7.2 IP parameters

- select **Settings** in the left column of the netFIELD Wireless Web Server.
- The Device configuration tab is displayed.

The screenshot shows the 'Device configuration' tab with the following details:

- Configuration control:** A dropdown menu currently set to 'DHCP'.
- Device IP address:** 192.168.10.94
- Subnet mask:** 255.255.255.0
- Gateway IP address:** 192.168.10.1
- Buttons:** 'Apply (effective after next reboot)' and 'Clear (Undo)'.
- Interface configuration status:** A table displaying the current settings:

Device IP address	192.168.10.94
Subnet mask	255.255.255.0
Gateway IP address	192.168.10.1

Figure 17: Device configuration tab (example)

The **Device configuration** tab allows you

- to define how the module obtains its IP address (via the **Configuration control** selection list, STATIC, BOOTP and DHCP options).

#	Option	Description
0	STATIC	The IP address of the module is configured statically. This is done using the device IP address, subnet mask, and gateway IP address entered in the Device configuration tab.
1	BOOTP	The device obtains its IP address via the BOOTP protocol.
2	DHCP	The device obtains its IP address via the DHCP protocol. This is the default setting.

Table 34: Selection list „Configuration control“

- If static configuration is used, set the IP address and subnet mask manually (the gateway IP address is optional).

Parameter	Settings or Action
Device IP address	IP address for ETHERNET communication if static configuration of IP address is used
Subnet mask	Subnet mask for ETHERNET communication with static configuration of the IP address
Gateway IP address	Gateway IP address for ETHERNET communication with static configuration of the IP address

Table 35: Device configuration tab- Parameter

8.3.7.3 Maintenance information

The Maintenance information tab is used to store maintenance information such as device name, installation location and date, contact information, a description text, or the date of the last and next service on the device.

The screenshot shows the 'Maintenance information' tab selected in a web interface. The tab bar at the top includes 'Device configuration', 'Maintenance information' (active), 'Firmware update', 'Factory reset', and 'MQTT'. The main content area contains several input fields: 'Name', 'Installation location', 'Installation date' (with a calendar icon), 'Contact information', 'Description', 'Last service date' (with a calendar icon), and 'Next service date' (with a calendar icon). At the bottom of the form are 'Apply' and 'Clear' buttons.

Figure 18: Maintenance information tab

Changes to settings require operator or admin rights. If these are not available, the tab is grayed out and cannot be edited.

The maintenance information is in detail:

Name	Data format and length	Description
Name	Printable ASCII string, max. 64 characters	Uniform label (string) in the installation for the function of this device
Installation location	Printable ASCII string, max. 32 characters	Uniform label (string) in the system for the location where the device is mounted.
Installation date	ASCII time specification, max. 32 characters	Date of installation or commissioning of this device, the format may be defined by the fieldbus organization.
Contact information	Printable ASCII string, max. 32 characters	Textual identification of a contact person for this managed node of the installation, together with information on how to contact this person.
Description	Printable ASCII string, max. 64 characters	Readable comment field (in plain text) to store any individual status information and remarks.
Last service date	ASCII time specification, max. 32 characters	Date/time of the last service, e.g. firmware update
Next service date	ASCII time specification, max. 32 characters	Date/time of the next service, e.g. firmware

Table 36: Maintenance information

To make changes to the maintenance information:


- Click on the **Settings** in the left column of the netFIELD Wireless Web Server.
- The Device configuration tab appears.

- Select the **Maintenance information** tab.
- Change the relevant fields there.
- Click **Apply**.
- ⇒ Your changes take effect.

8.3.7.4 Firmware update

The netFIELD Wireless Web Server provides a way to update all firmware required for the IO-Link Wireless Master NFD-3090-EIS-IOLM\W device via the Firmware update tab.

- Select **Settings** in the left column of the netFIELD Wireless Web Server.
- Open the **Firmware update** tab.



The screenshot shows the 'Firmware update' tab selected in a navigation bar. Below the navigation bar, there is a 'File' section with a 'Choose File' button and a text field containing 'NFDW_Update_... .zip'. Below this is a 'Details of new Firmware' section with an 'Official description' field containing 'Full Update Package V... (COM V1.1.8.0, WEB V1.0.0.4, IOLWM V40.01.1000)' and an 'Update' button. At the bottom is a 'Details of current active firmware' section with a table of device information.

Details of current active firmware	
Hardware name	NFD-3090-...-IOLM\W
Firmware version	V2.1.0.4
Kernel version	V1.1.7.1
Webpage version	V1.0.0.4
IO-Link Wireless Master main revision	V40.01.1000
IO-Link Wireless Master stack version	V8.3.1000
Radio module revision	V2.3.32

Note
Do not switch off device while updating firmware !

Figure 19: Firmware update tab (example)

NOTICE**Bring the system into safe operating condition**

Never carry out a firmware update during operation of the system in which the NFD-3090-EIS-IOLMW device is installed. Before each firmware update, the system must first be shut down properly, or must be brought into a safe operating state.

NOTICE**Invalid firmware**

Loading invalid firmware files could render your device unusable. Only load firmware files to the device that are valid for this device. Otherwise, you might be forced to send in your device for repair.

**Important:**

If you update the firmware of the NFD-3090-EIS-IOLMW device and you did not make a backup of the firmware and configuration data, you cannot restore the state of your device prior to the update, including the previously used firmware.

Changes to settings require operator or admin rights. If these are not available, the Firmware update tab is grayed out and cannot be edited.

To update the firmware, you need the file `NFDW_Update_[protocol name]_V[version].zip` containing all firmware required for the NFD-3090-EIS-IOLMW device. You can download this from the website of the device manufacturer or provider.

**Note:**

Do not change the name of the `NFDW_Update_[protocol name]_V[version].zip` file.

- In the Firmware update tab, click on **Choose File**.
- ⇒ A file selection dialog appears.
- Select the file `NFDW_Update_[protocol name]_V[version].zip` in this dialog.
- Click **Update**.
- ⇒ The firmware update is performed. This takes a short while.

The screenshot displays a web-based configuration interface with a top navigation bar containing five tabs: 'Device configuration', 'Maintenance Information', 'Firmware update' (which is active), 'Factory reset', and 'MQTT'. Below the tabs, the 'Firmware update' section is titled 'File' and includes a 'Choose File' button and a text field showing 'NFDW_Update_... .zip'. A section titled 'Details of new Firmware' shows the 'Official description:' as 'Full Update Package V... (COM V1.1.8.0, WEB V1.0.0.4, IOLWM V40.01.1000)'. Below this is an 'Update' button. A large red progress bar indicates the update is at 69% completion, with the word 'Loading' positioned below it. Further down, a section titled 'Details of current active firmware' states 'New firmware is prepared...'. At the bottom, a 'Note' section contains the warning: 'Do not switch off device while updating firmware !'.

Figure 20: Firmware update is performed (example)

- ⇒ A message appears indicating that the firmware update was finished, and the device will be restarted after pressing OK, and has a new (possibly different) IP address.
- Click **OK**.
- Then you must perform the port configuration once again.

8.3.7.5 Factory settings

In some cases, it is helpful to reset the device to the factory settings. This is possible for various selectable classes of settings via the Factory reset tab in the Settings menu.




Figure 21: Factory reset tab

Changes to settings require operator or admin rights. If these are not available, the tab is grayed out and cannot be edited.

Various settings made can be deleted depending on your selection:

Option	Delete stored configuration
Delete stored device information	Device information (e. g. maintenance information, system time settings, and IO-Link master settings within OPC UA)
Delete stored network adapter settings	Network adapter settings (communication settings, IP address configuration, Name of Station)
Delete stored application parameters	Application-specific data (port configuration and parameters, remanent parameters)
Delete all stored settings	All settings

Table 37: Options to delete settings

To reset the device to the factory settings, proceed as follows:

- Click on the **Settings** in the left column of the netFIELD Wireless Web Server.
- The Device configuration tab appears.
- Select the **Factory reset** tab.
- Select which settings should be reset to the factory defaults.
- Click on **Delete settings**.
- ⇒ The selected settings are deleted.
- ⇒ Click on **Restart**.
- ⇒ The device is restarted with the factory settings.

8.3.7.6 MQTT configuration

Use the MQTT tab to view and change the MQTT client and connection configuration.

- Select **Settings** in the left column of the netFIELD Wireless Web Server.
- Open the **MQTT** tab with its sub tabs.
- The Client Status appears, and by default the Client Configuration sub tab.

MQTT > Client Status, and Client Configuration

Client Status

State **CONNECTION_ACCEPTED**
 Broker Address **192.168.10.5**
 Active Connection **Connection 1**
 Last Error Code **0**

Client Configuration | Connection1 | Connection2 | Connection3

Client mode
 ACTIVE

Active connection
 Connection 1

Apply Clear (Undo)

Figure 22: MQTT tab, Client Status, Client Configuration sub tab (example)

Parameter	Description	Value / Value range
State	States 1, 2: "CONNECTING" State 3: "CONNECTION_ACCEPTED" States 0,4,5,6: "CLIENT_INACTIV" Connection state code 0: Ready: initialization value, connection not established. 1: Connecting: TCP connection establishment in progress. 2: TCP Connected: TCP connection established. MQTT connection in progress. 3: MQTT Connected: MQTT connection established. 4: Disconnecting: MQTT connection shutdown in progress. 5: Disconnected: TCP connection terminated. 6: Wait Reconnect: Waiting for reconnection to be allowed again. See "Connect Timeout" parameter.	CONNECTING (red), CONNECION_ACCEPTED (green), CLIENT_INACTIVE (red)
Broker Address	Current value for "Broker Address"	Example: 192.168.10.5
Active connection	Current value for "Active connection", respectively active connection configured.	Example: Connection 1
Last Error Code	Last error code, related to this connection.	Example: 0

Table 38: MQTT in port configuration for IO-Link Device, Client Status

Parameter	Description	Value / Value range
Client mode	"ACTIVE" means MQTT client application is enabled and "INACTIVE" means disabled.	INACTIVE (default), ACTIVE
Active connection	Active connection configured.	Connection 1 (default), Connection 2, Connection 3

Table 39: MQTT in port configuration for IO-Link Device, Client Configuration

- For MQTT Client Configuration make the following settings and configuration steps:
 - Client mode
 - Active connection

MQTT > Connection1 > IP settings

- Open the **Connection1** sub tab.
- The IP settings sub sub tab appears by default.

The screenshot shows a web-based configuration interface for MQTT. At the top, there are four tabs: 'Client Configuration', 'Connection1' (selected), 'Connection2', and 'Connection3'. Below 'Connection1', there are four sub-tabs: 'IP settings' (selected), 'Session settings', 'Will settings', and 'Advanced settings'. The 'IP settings' sub-tab contains two input fields: 'Broker Address' with the value '192.168.10.5' and 'Broker Port' with the value '1883'.

Figure 23: MQTT tab, Connection1 > IP settings sub sub tab (example)

Parameter	Description	Value / Value range
Broker Address	IP address of the broker.	Valid IP address, Default: [BrokerAddress],
Broker Port	MQTT broker IP port number.	Typically: 1883

Table 40: MQTT in port configuration for IO-Link Device, Connection1 > IP settings

- For MQTT Connection Configuration make the following settings and configuration steps:
 - Broker Address
 - Broker Port

MQTT > Connection1 > Session settings

➤ Open the **Session settings** sub sub tab.

The screenshot shows a web-based configuration interface for MQTT. At the top, there are four tabs: 'Client Configuration', 'Connection1' (selected), 'Connection2', and 'Connection3'. Below these, there are four sub-tabs: 'IP settings', 'Session settings' (selected), 'Will settings', and 'Advanced settings'. The 'Session settings' sub-tab contains three configuration fields: 'Topic Prefix' with a text input containing 'Device5', 'Clean Session' with a dropdown menu set to 'Enabled', and 'MQTT Keep Alive Time [Seconds]' with a text input containing '60'.

Figure 24: MQTT tab, Connection1 > Session settings sub sub tab (example)

Parameter	Description	Value / Value range
Topic Prefix	Text that is prefixed to each topic, e. g. 'StationA'. For each single topic can be configured if this prefix is to be preceded or not. If left empty the firmware will try to use the MAC address.	Text of uppercase and lowercase letters and underscore, Default: [not specified]
Clean Session	Setting whether all topics are to be transferred to the broker after establishing a connection or not. Enabled (default): After a connection to the broker has been established, all topics of the type 'publish' are transmitted from the MQTT client to the broker . Disabled: Only those topic are transmitted to the broker, which have changed since the last connection. Note that if you use this setting, the broker must support the 'preserve context' function.	Enabled (default), Disabled
MQTT Keep Alive Time [Seconds]	Interval in which the MQTT client sends a sign of life to the broker. The set value for the MQTT client must be less than the monitoring time set in the broker. Enabling this timeout is suitable if the connection is used for at least one subscription so a permanent connection to the broker is required. Not allowed to be enabled together with the Connection Idle Timeout.	Specified in s. 0 = send no sign of life to the broker. Default: 0

Table 41: MQTT in port configuration for IO-Link Device, Connection1 > Session settings

➤ For MQTT Connection Configuration make the following settings and configuration steps:

- Topic Prefix
- Clean Session
- MQTT Keep Alive Time

MQTT > Connection1 > Will settings

- Open the **Will settings** sub sub tab.

The screenshot displays the MQTT configuration interface for Connection1, specifically the Will settings sub-tab. The interface includes a top navigation bar with 'Client Configuration', 'Connection1', 'Connection2', and 'Connection3'. Below this, a secondary navigation bar shows 'IP settings', 'Session settings', 'Will settings' (which is highlighted), and 'Advanced settings'. The main content area for 'Will settings' contains four configuration items: 'Will Enabled' with a dropdown menu set to 'Enabled'; 'Will Topic' with a text input field containing 'EXIT'; 'Will Message' with a text input field containing '{\"Publisher\": \"Offline\"}'; and 'Will Retain' with a dropdown menu set to 'Enabled'.

Figure 25: MQTT tab, Connection1 > Will settings sub sub tab (example)

Parameter	Description	Value / Value range
Will Enabled	Enable this option if you want to use the "will" feature of MQTT.	Enabled (default), Disabled
Will topic	Unique name for the topic, editable. If left empty the firmware will use the string constant "will" prefixed by the Prefix Will if enabled.	Max. 128 characters of text from uppercase and lowercase letters and underscore; Default: [not specified]
Will Message	Payload forwarded by the broker to other clients subscribed to the will topic in case of abnormal disconnection (when an MQTT Disconnect packet was not sent to the broker). If left empty, the string "Disconnected" is sent.	Text of uppercase and lowercase letters and underscore; Default: [not specified]
Will QoS	Quality of Service Level for the Will Message. 0: "Only once": fire and forget 1: "At least once": acknowledged delivery 2: "Exactly once": assured delivery	Only once (default), At least once, Exactly once
Will Retain	Setting whether the broker shall store the history of a data value or not.	Enabled (default), Disabled

Table 42: MQTT in port configuration for IO-Link Device, Connection1 > Will settings

- For MQTT Connection Configuration make the following settings and configuration steps:
- Will Enabled
 - Will Topic
 - Will Message
 - Will Retain

MQTT > Connection1 > Advanced settings

➤ Open the **Advanced settings** sub sub tab.

Figure 26: MQTT tab, Connection1 > Advanced settings sub sub tab (example)

Parameter	Description	Value / Value range
Will QoS	Quality of Service Level for the Will Message. 0: "Only once": fire and forget 1: "At least once": acknowledged delivery 2: "Exactly once": assured delivery	Only once (default), At least once, Exactly once
Will Prefix	Text that is prefixed to each Will topic. For each single topic can be configured if this prefix is to be preceded or not.	Text of uppercase and lowercase letters and underscore, Default: [not specified]
Connection Timeout	Time for trying to establish a connection (MQTT Connect) to the broker. If the connection could not be established, then the MQTT client waits for the duration of 'Connection Timeout' until a new connection is established to the broker.	Specified in s. = 0 MQTT client constantly tries to establish a connection to the broker. Default: 0
Client identifier	Unique name of the MQTT client in UTF-8 format used at connection establishment time. All devices that are connected to a broker, must have a unique name. The name may only consist of lowercase letters, uppercase letters and numbers. If the field is empty, then the broker assigns a name.	max. 23 Bytes for max. 23 characters, Default: [Client ID] Example: "ClientId1"

Table 43: MQTT in port configuration for IO-Link Device, Connection1 > Advanced settings

➤ For MQTT Connection Configuration make the following settings and configuration steps:

- Will QoS
- Will Prefix
- Connection Timeout
- Client Identifier

8.3.7.7 Log in or User administration

Log in user

**Note:**

A log in is only possible when device connection state is “connected” (top left corner of the netFIELD Wireless Web Server).

To log in as a user

- Select **Sign in** in the left column of the netFIELD Wireless Web Server.
- ⇒ The input mask for user name and password appears:

The screenshot shows a web interface for logging in. It has two text input fields, one labeled 'Username' and one labeled 'Password'. Below the 'Password' field is a button labeled 'Sign in'.

Figure 27: Menu item SignIn - Input mask for user name and password

- Enter your user name and password correctly in the corresponding input fields of the screen mask.
- Click **Sign in**.
- ⇒ If you have entered a known user name correctly, you now can work with the netFIELD Wireless Web Server with the defined rights of this user. The user role (Operator, Maintenance, Admin) used for sign in is displayed in the upper left corner. The previous menu entry **Sign in** changes and is now called **Sign out**.

Logging off users

To log off a user:

- Click on the **Sign out** menu item in the main menu of the netFIELD Wireless Web Server (left side).
- ⇒ From now on, you can no longer work with the netFIELD Wireless Web Server with the previous rights. The user role `guest` appears in the upper left corner. The previous menu entry **Sign out** changes and is now called **Sign in** again.

Guest user access

By default, the netFIELD Wireless Web Server knows a user `guest` without password, which has been set up to realize a first-time or guest access.

First-time login as administrator

In the delivery state or after resetting to the factory settings, the netFIELD Wireless Web Server can be accessed via the user name “root” and the password “password”. This combination also has administrator rights.



Important:

Change the administrator password immediately after commissioning. The factory default setting is generally known and does not provide sufficient protection.

User Administration

- Select **User administration** in the left column of the netFIELD Wireless Web Server.

The Administration pane provides a role-based user administration. You can use it to create and delete users and assign roles to them on which their rights depend. Users can be divided into three roles:

- Maintenance
- Operator
- Administrator

Creating a new user

When opening the user administration the following picture appears:




Account list		Actions
User name	Role	
root	Admin	

New account			Actions
<input type="text" value="username"/>	<input type="text" value="password"/>	Maintenance ▾	

Figure 28: User Administration screen mask (initial state)

Another user can be defined in the second line. Proceed as follows:

- In the Username input field (left side), enter the user name that is to be used for the user. User names that have already been used are not permitted here.
- In the Password input field (middle), enter the password for this user name.
- Use the combo box on the right to select the role for the new user to be created (the roles Maintenance, Operator or Administrator are available).
- Finally, click on the green field.
- The new user is created and assigned to the selected role.

Account list		Actions
User name	Role	
root	Admin	
user1	Maintenance	
operator1	Operator	


New account			Actions
<input type="text" value="username"/>	<input type="text"/>	<input type="text" value="Operator"/>	

Figure 29: User Administration screen mask

Remove user

To remove an existing user from the device user management, proceed as follows:

- Click the red square with a white cross to the right of the user to be removed.
- ⇒ The user will be deleted.

The “root” user cannot be deleted, so the red delete button is grayed out.

9 Commissioning

For commissioning the NFD-3090-EIS-IOLMW device using the netFIELD Wireless Web Server proceed as described in the sections hereafter.

9.1 Getting an IP address from a DHCP server

The device needs an IP address so that it can be addressed via the Ethernet network. In the state of delivery, the device does not have an IP address, and, once started, the device sends requests to a DHCP server in order to get an IP address.

If a DHCP server is already available in the network, ask your network administrator for the IP address assigned to the device and use its MAC address for identification.

If necessary, a static IP address can be set via the netFIELD Web Server. For details, see section *IP parameters* [► page 57].

Using a DHCP server on your PC

If no DHCP server exists in the network or if you wish to use a DHCP server in the local network for test purposes, you can use e.g. the Open DHCP server.

Observe the following notes:

- Never connect your PC to a global network, if a DHCP server is installed on your PC. Since larger networks usually have a DHCP server, collisions might occur causing a collapse of the network.
- Use a DHCP server on your PC only if no DHCP server is available in the network.

Installing and using the Open DHCP server

You can install the Open DHCP server on your PC. For configuring the DHCP server you need the IP address of the network connection of your PC. To display the IP address(es) of your PC, you can use the command `ipconfig` in the Windows command prompt.

Proceed as follows

- Download the Open DHCP server from <http://dhcpserver.sourceforge.net/>
- Install the Open DHCP server.
- Use a text editor to open file `OpenDHCPServer.ini` in the installation directory of the Open DHCP server.
- Under `[LISTEN_ON]`, enter the IP address of the PC network board on which the DHCP server is to work.
- Save file `OpenDHCPServer.ini`.
- Under `[RANGE_SET]`, enter the IP address range the DHCP server is allowed to assign.
- Thereafter, start file `RunStandAlone.bat`.
- ⇒ The DHCP server is ready for operation now.

In the output window the Open DHCP server displays the requests and the assigned IP address.

9.2 Configuration with netFIELD Wireless Web Server

Requirements

To allow the commissioning or configuration using the netFIELD Wireless Web Server, the following requirements must be fulfilled:

- The device must be mounted, wired, and supplied with power.
- A browser is required, to connect to the netFIELD Wireless Web Server.
- A login as admin.

9.2.1 Configuring the IO-Link Wireless Master

- Select **Master** in the left column of the netFIELD Wireless Web Server.
- On the **Channel selection** tab select the WLAN channels required (for example, WLAN channels 01 to 04).
- Then open the **Configuration** tab.

Figure 30: Master > Configuration tab

- Use the following IO-Link Wireless Master settings as possible values for commissioning. They will allow you to put the NFD-3090-EIS-IOLM \W device into operation.

Parameter	Possible value for commissioning	Note
Master ID	1	Enter the Master ID this way: "1"
Pairing Timeout	5	seconds
Advanced Connectivity	Adaptive Hopping Table: unchecked , Reconnect: checked	
WT1 Track Mode	Cyclic	
WT2 Track Mode	Cyclic	
WT3 Track Mode	Cyclic	
WT1 TXPower	31	"31" = max. transmission power
WT2 TXPower	31	
WT3 TXPower	31	

Table 44: Configuration, possible values for IO-Link Wireless Master (example)



Important:

For proper device operation all three tracks must be activated.

- Click **Apply**.
- The request appears Applying configuration will restart the device. Are you sure?.

- Click **Yes**.
- Wait until reset operation is finished and result is shown:
- The message `Master configured successfully` appears.
- The set IO-Link Wireless Master settings are used now.

Scan

- Select **Master** in the left column of the netFIELD Wireless Web Server.
- Open the **Scan** tab.

Figure 31: Scan tab

- Enter **TXPower** as decimal value: 31 (= maximum transmission power of the device)
- Click **Scan start**.
- The scan result is displayed. The connected device is found.
- The following scan result values are displayed:

Parameter	Scan result (example)	Note
Index	0	
Unique ID	0x03,0xf3,0x00,0x00,0x01,0x72,0xc0,0x45,0xcf	Copy/note the unique ID. This value is required for port configuration.
Slot Type	Double slot	
Revision ID	0x11	
Port	"Select port"	Note: For a device featuring "Double slot" an even port must be assigned.
Pairing	Pair (green)	

Table 45: Scan result

Index	Unique ID	Slot Type	Revision ID	Port	Pairing
0	0x03, 0xf3, 0x00, 0x00, 0x01, 0x72, 0xc0, 0x45, 0xcf	Double slot	0x11	Select port	Pair

Figure 32: Scan tab with result

9.2.2 Port settings

- Select the desired wireless port (WP01, WP02, WP03, ...) in the left column of the netFIELD Wireless Web Server.
- Open the **Settings** tab with its sub tabs.
- The Port cycle sub tab appears by default.



Note:

The values for the port settings given below are example values for commissioning of your NFD-3090-EIS-IOLM\W device.

“Port cycle” sub tab

The Port cycle sub tab includes the parameters Port mode and Port cycle time.

Figure 33: Settings tab > Port cycle sub tab (example)

Parameter	Example value for commissioning		Note
Port mode	Cyclic		
Port cycle time	Time base	Time multiplier	
Example 1	Free running	(any selectable value)	„Free running“
Example 2	5 ms	1	Port cycle time = 5 ms

Table 46: Settings > Port cycle (example values)

“Validation level” sub tab

- Click **Validation level**.
- The Validation level sub tab with the parameters Validation and backup, Vendor ID and Device ID appears.

The screenshot shows a software interface with a top navigation bar containing 'Information', 'Status', 'Settings' (active), 'ISDU', and 'Process Data'. Below this is a sub-tab bar with 'Port cycle', 'Validation level' (active), 'Transmission', and 'Miscellaneous'. The 'Validation level' sub-tab contains a 'Validation and backup' dropdown menu currently showing 'No Device check'. Below this are two text input fields: 'Vendor ID' containing '0x136' and 'Device ID' containing '0x174'. At the bottom of the sub-tab are two buttons: 'Apply' and 'Clear (Undo)'.

Figure 34: Settings tab > Validation level sub tab (example)

Parameter	Example value for commissioning	Note
Validation and backup	Default: No device check	
Vendor ID	0x0136	Example device
Device ID	0x0174	Example device

Table 47: Settings > Validation level (example values)

- Enter the **Vendor ID** and **Device ID** of the wireless connected IO-Link Device.

The Vendor ID and Device ID can be taken from the IODD or the device description of the manufacturer.

“Transmission” sub tab

- Click **Transmission**.
- The Transmission sub tab with the parameters Max PD Segment Length, Slot number, Track number, Device TX power and Max retry appears.

The screenshot shows the 'Settings' tab with the 'Transmission' sub-tab selected. The sub-tab contains five dropdown menus: 'Max PD Segment Length' (value 2), 'Slot number' (value 0), 'Track number' (value WT1), 'Device TX power' (value 31), and 'Max retry' (value 2). At the bottom of the sub-tab are two buttons: 'Apply' and 'Clear (Undo)'.

Figure 35: Settings tab > Transmission sub tab (example)

Parameter	Example value for commissioning	Note
Maximum PD Segment Length	2	Max. process data transmissible via IO-Link, as in the example device used If this maximum value of the used device is not available, enter “32”.
Slot number	0	
Track number	0 (=WT1)	
Device TX power	31	31 = max. transmission power
Maximum retry	2	Example value

Table 48: Settings > Transmission (example values)

“Miscellaneous” sub tab

- Click **Miscellaneous**.
- The Transmission sub tab with the parameters Unique I, Slot type, IMA Time 3 sec and Low power device appears.

Figure 36: Settings tab > Miscellaneous sub tab (example)

Parameter	Example value for commissioning	Note
Unique ID	0x03,0xf3,0x00,0x00,0x01,0x72,0xc0,0x45,0xcf	The Unique ID consists of 9 numbers. Use the Unique ID from the scan result.
Slot type	Single slot	Use the slot type from the scan result. Note: For a device featuring “Double slot” an even number must be assigned as value for the slot.
IMA Time 3 sec	Time base: 1 sec Time multiplier: 3	Default value is used
Low power device	No	

Table 49: Settings > Miscellaneous (example values)

- Enter the Unique ID numbers without space. Use the Unique ID from the scan result (see *Configuring the IO-Link Wireless Master* [▶ page 73]).
- Click **Apply**.

A description of the parameters on the sub tabs shown can be found under *Port settings* [▶ page 52]. For details on track and port, see *Wireless* [▶ page 84]. For the corresponding process data as result from the configuration made, see *Testing* [▶ page 79].

9.3 Testing

Process data

- Select the desired wireless port (WP01, WP02, WP03, ...) in the left column of the netFIELD Wireless Web Server.
- Open the **Process Data** tab.
- ⇒ The following process data are the result of the represented commissioning example with a laser distance sensor.




Figure 37: Tab and table "Port process data" (example PD input valid = OK)



Note:

Displayed values coming from a real sensor, can change if sensor conditions change.

Status

- Select the desired wireless port (WP01, WP02, WP03, ...) in the left column of the netFIELD Wireless Web Server.
- Open the **Status** tab.
- ⇒ The following port status data are the values displayed after configuration steps for the IO-Link Wireless Master and the port configuration are completed.




Figure 38: Status tab, Port status

The displayed values are real values from the device.

Parameter	Displayed values	Parameter	Displayed values
Port state	Operate	Output data length	0 Bytes
Port quality	PDI invalid, PDO invalid	Vendor ID	0x136
Revision ID	0x11	Device ID	0x174
Master cycle time	15 ms	Signal quality	15 %
Input data length	2 Bytes		

Table 50: Status tab, Port status, displayed values

Information

- Select the desired wireless port (WP01, WP02, WP03, ...) in the left column of the netFIELD Wireless Web Server.
- Open the **Information** tab.
- ⇒ The following device information data are example values displayed after configuration steps for the IO-Link Wireless Master and the port configuration are completed.

Information	Status	Settings	ISDU	Process Data
Device information				
Min cycle time	5 ms			
Function ID	0			
Number of profile IDs	4			
Vendor name	ifm electronic gmbh			
Vendor text	www.ifm.com			
Product name	E30391_AB			
Product ID	E30391			
Product text	IO-Link mini HMI			
Serial number	000129163805			
Hardware revision	AC			
Firmware revision	V0.25			

Figure 39: Information tab, Device information

9.4 Master reset

To perform a reset of the IO-Link Wireless Master NFD-3090-EIS-IOLM\W device, proceed as follows.

1. Safety

NOTICE

Bring the system into safe operating condition

Never carry out a firmware update during operation of the system in which the NFD-3090-EIS-IOLM\W device is installed. Before each firmware update, the system must first be shut down properly, or must be brought into a safe operating state.

NOTICE

Invalid firmware

Loading invalid firmware files could render your device unusable. Only load firmware files to the device that are valid for this device. Otherwise, you might be forced to send in your device for repair.



Important:

If you update the firmware of the NFD-3090-EIS-IOLM\W device and you did not make a backup of the firmware and configuration data, you cannot restore the state of your device prior to the update, including the previously used firmware.

2. Firmware update

- Select **Settings** in the left column of the netFIELD Wireless Web Server.
- Open the **Firmware update** tab.
- First click **Delete all settings**.
- Then click **Reset**.
- The device reset is complete. The message `Device reset successfully` appears.

For detailed descriptions on the firmware update page, see *Firmware update* [▶ page 59].

9.5 Indexed Service Data Units

Read/write IO-Link Device parameters

The function of the ISDU tab is to read from or write to one IO-Link object of the connected IO-Link Device.

- Select **Master** in the left column of the netFIELD Wireless Web Server.
- Open the **ISDU** tab.
- ⇒ For example, you can read an IO-Link object from an IO-Link Device, e. g. to know the device manufacturer.

Figure 40: ISDU tab, read/write IO-Link Device parameters

- To read data from the IO-Link Device click **Read**.
- ⇒ The time stamp and the corresponding data are displayed in ASCII format below.

For detailed descriptions on the ISDU tab, see *Device ISDU* [► page 46].

Read/write IO-Link Wireless Master parameters

The function of the ISDU tab with option Tigo Master Parameters enabled is to read from or write to one IO-Link object from the IO-Link Wireless Master.

- Select **Master** in the left column of the netFIELD Wireless Web Server.
- Open the **ISDU** tab.
- Enable **Tigo Master Parameters**.

Example

Write example

- PortId: 1
- ArgBlockId: B090
- ArgBlockData: 112233

Read example

- PortId: 1
- ArgBlockId: B090

Information Status Settings **ISDU** Process Data

☒ Tigo Master Parameters

PortId (in hex)

ArgBlockId (in hex)

00

ArgBlockData (in hex without spaces)

Read Write Clear History

History list

```
08:57:04 - 1:B090:112233 - VsWrite OK: ArgBlockId(FFF0):ArgBlockData()
08:57:11 - 1:B090 - VsRead OK: ArgBlockId(B090):ArgBlockData(11223300000000000000)
```

Figure 41: ISDU tab, read/write IO-Link Wireless Master parameters

- To read data from the IO-Link Wireless Master device click **Read**.
- ⇒ The time stamp and the corresponding data are displayed in ASCII format below.

For detailed descriptions on the ISDU tab with option Tigo Master Parameters enabled, see *Master ISDU* [▶ page 48].

9.6 Wireless

For each track up to 8 IO-Link Devices can be connected via a wireless connection.

The tracks and slots for the IO-Link Devices, configured with the wireless IO-Link port configuration, must be unique! For each connected IO-Link Device, 1 wireless track must be configured and 1 slot must be configured.

The presented commissioning example includes 1 connected IO-Link Device. The chosen values were:

- Track: 0x00
- Slot: 0x00

Any further slots must be configured to free slots.



Note:

If slot type = "Double slot", then the value for slot must be an even number.

The following table shows an example for track and slot configuration for a connected IO-Link Device if the slot type "Double slot" is configured.

Track	Slot 0	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6	Slot 7
0	W-device with double slot	free	free	free	free	free	free	free
1	free	free	free	free	free	free	free	free

Table 51: Track and Slot – example 1 wireless device with slot type "double slot"

9.7 Setting date and time

The device has a built-in timing unit. To get the date and time from an NTP server using Network Time Protocol (NTP), the device needs the IP address of the NTP server. An OPC UA client is required to set the IP address of the NTP server.

Chapter *NTP Client configuration* [► page 104] describes the nodes of the OPC UA server for configuring the NTP client.

Chapter *Setting date and time of the device via OPC UA* [► page 87] describes how to set the IP address of the NTP server via an OPC UA client.

9.8 Using OPC UA Client

The device has an integrated OPC UA server. You can communicate with the device using an OPC UA client.

For test purposes, you can use e.g. the UaExpert from Unified Automation GmbH:

<http://www.unifiedautomation.com>

The authentication "anonymous" allows an OPC UA client read access to the device.

The authentication "User name and password" allows an OPC UA client read access and write access to the device if the user used has the permission to write.

9.8.1 Connecting with device

Requirements

- You have an OPC UA client.
- For write access to the device: You know the user name and password, and you have the permission to write.
- You know the IP address of the device.

Without user name and password, you can access the device "anonymously" and read data.

Step-by-step instructions

Establish a connection to the device:

- Start UaExpert.
- Use **File > New** to create a new project.
- Use **Server > Add** to add a new server.
- The tab **Discovery** displays the dialog **Add Server**.

Tab **Discovery** (default)

Tab **Advanced**




Table 52: Dialog Add Server - tabs **Discovery** and **Advanced**

- In the field **Configuration name**, enter a name for your configuration, e. g. **Test**.
- Select the tab **Advanced**.
- In the area **Server Information** of the tab **Advanced**, enter the following text in the data field **Endpoint Url**:
`opc.tcp://<IP address>:4840`
 For <IP address> enter the IP address of your device.
- In the area **Authentication Settings**, select the option **Username/Password** if you want to execute a write access to the device or select **Anonymous** if a read access is sufficient.
- If you have selected the option **Username/Password**, enter your user name and, if necessary, your password.
- Click **Ok**.
- In the project window, under **Project > Servers**, the UaExpert enters the server, e. g. **Test**.
- Open the context menu of the server (**Test**) and select **Connect**.
- ⇒ The connection will be established.

9.8.2 Setting date and time of the device via OPC UA

Requirements

- You have an OPC UA client.
- You know the username and password, and you have the permission to write.
- You know the IP address of an NTP server.
- You have converted the IP address of the NTP server into a decimal number, as described below.
- You have already established a connection to the device.

Example of an NTP server

NTP server `ptbtime1.ptb.de` of the German Federal Institute of the Physikalisch-Technische Bundesanstalt in Braunschweig with the IP address `192.53.103.108`

Substitute NTP server (optional) of the NTP server `ptbtime2.ptb.de` of the Physikalisch-Technische Bundesanstalt in Braunschweig with the IP address `192.53.103.104`

Converting an IP address into a decimal number

To convert the IP address to a decimal number, use the following formula. Starting from an IP address in the format A.B.C.D:

$$((A * 256 + B) * 256 + C) * 256 + D = \text{IP address as a decimal number}$$

Example of IP address `192.53.103.108`

$$((192 * 256 + 53) * 256 + 103) * 256 + 108 = 3224725356$$

Step-by-step instructions

- In the window **Address Space**, open the context menu:
 Root> Objects> DeviceSet> [Device name] >
 Configuration> NtpClient>
 NtpClientUpdateConfiguration.




Figure 42: Node `NtpClientUpdateConfiguration` (1)

- In the context menu select **Call**.




Figure 43: Node NtpClientUpdateConfiguration (2)

- ⇒ The dialog **Call NtpClientUpdateConfiguration on NtpClient** will be displayed:

Input Arguments			
Name	Value	DataType	Description
ServerIpAddress	3224725356	UInt32	
ServerIpAddressFallback	3224725352	UInt32	

Output Arguments			
Name	Value	DataType	Description
Status		Int32	

Result

Call Close

Figure 44: Dialog for configuring the NTP client

- In the area **Input Arguments**, in the input field **ServerIpAddress**, enter the value 3224725356 for the IP address of the NTP server.
- In the area **Input Arguments**, in the input field **ServerIpAddressFallback**, enter 3224725352 for the IP address of the substitute NTP server.
- Click **Call**.
- ⇒ If the function call was successful, the output field to the right of Status in the area **Output Arguments** displays 0. A green bar with the text "succeeded" appears in the area **Result**. The two variables ServerIpAddress and ServerIpAddressFallback are now set. Via NTP the device gets the current date and time of the time server and synchronizes its internal timing unit.

Input Arguments			
Name	Value	DataType	Description
ServerIpAddress	3224725356	UInt32	
ServerIpAddressFallback	3224725352	UInt32	

Output Arguments			
Name	Value	DataType	Description
Status	0	Int32	

Result

Succeeded

Call Close

Figure 45: Dialog for configuring the NTP client (successful)

10 Communication

10.1 Process data

This section describes the process data for the netFIELD IO-Link Wireless Master EtherNet/IP Adapter NFD-3090-EIS-IOLM\W

- Connection 1 (Exclusive Owner - 8 ports x 32 bytes)
- Connection 2 (Exclusive Owner - 8 ports x 32 bytes w/o Config)
- Connection 3 (Listen Only - 8 ports x 32 bytes)
- Connection 4 (Input Only - 8 ports x 32 bytes)
- Connection 5 (Exclusive Owner - 16 ports x 16 bytes w/o Config)
- Connection 6 (Listen Only - 16 ports x 16 bytes)
- Connection 7 (Input Only - 16 ports x 16 bytes)
- Connection 8 (Exclusive Owner - 16 ports x 4 bytes w/o Config)
- Connection 9 (Listen Only - 16 ports x 4 bytes)
- Connection 10 (Input Only - 16 ports x 4 bytes)

The process data input and the process data output

- for connection 1, connection 2, connection 3 and connection 4 have a fixed size of 276 Byte,
- for connection 5, connection 6 and connection 7 have a fixed size of 292 Byte,
- for connection 8, connection 9 and connection 10 have a fixed size of 100 Byte.

10.1.1 Connections 1 to 4

Input process data

The following table gives a description of the process data structure of the input process data and is valid for connection 1, connection 2, connection 3 and connection 4.

Byte	Number of bytes	Input process data	Description
1	1 byte	DI status	Reserved
2	1 byte	Padding byte	Do not use
3 ... 4	2 byte	DI data	Reserved
5	1 byte	WP01 data status	See section <i>Input process data status</i> [► page 101].
6	1 byte	Padding byte	Do not use
7 ... 38	32 byte	WP01 process input data	IO-Link input data of the IO-Link Device wireless connected to WP01. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
39	1 byte	WP02 data status	See section <i>Input process data status</i> [► page 101].
40	1 byte	Padding byte	Do not use
41 ... 72	32 byte	WP02 process input data	IO-Link input data of the IO-Link Device wireless connected to WP02. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
73	1 byte	WP03 data status	See section <i>Input process data status</i> [► page 101].
74	1 byte	Padding byte	Do not use
75 ... 106	32 byte	WP03 process input data	IO-Link input data of the IO-Link Device wireless connected to WP03. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
107	1 byte	WP04 data status	See section <i>Input process data status</i> [► page 101].
108	1 byte	Padding byte	Do not use
109 ... 140	32 byte	WP04 process input data	IO-Link input data of the IO-Link Device wireless connected to WP04. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
141	1 byte	WP05 data status	See section <i>Input process data status</i> [► page 101].
142	1 byte	Padding byte	Do not use
143 ... 174	32 byte	WP05 process input data	IO-Link input data of the IO-Link Device wireless connected to WP05. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
175	1 byte	WP06 data status	See section <i>Input process data status</i> [► page 101].
176	1 byte	Padding byte	Do not use
177 ... 208	32 byte	WP06 process input data	IO-Link input data of the IO-Link Device wireless connected to WP06. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
209	1 byte	WP07 data status	See section <i>Input process data status</i> [► page 101].
210	1 byte	Padding byte	Do not use
211 ... 242	32 byte	WP07 process input data	IO-Link input data of the IO-Link Device wireless connected to WP07. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
243	1 byte	WP08 data status	See section <i>Input process data status</i> [► page 101].
244	1 byte	Padding byte	Do not use

Byte	Number of bytes	Input process data	Description
245 ... 276	32 byte	WP08 process input data	IO-Link input data of the IO-Link Device wireless connected to WP08. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Table 53: Input process data, connection 1 to connection 4

Output process data

The following table gives a description of the process data structure of the output process data and is valid for connection 1 and connection 2.

Byte	Number of bytes	Output process data	Description
1	1 byte	DO status	Reserved
2	1 byte	Padding byte	Do not use
3 ... 4	2 byte	DO data	Reserved
5	1 byte	WP01 Output enable	0: WP01 output data not valid. 1-255: WP01 output data valid.
6	1 byte	Padding byte	Do not use
7 ... 38	32 byte	WP01 process output data	IO-Link output data of the IO-Link Device wireless connected to WP01. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
39	1 byte	WP02 Output enable	0: WP02 output data not valid. 1-255: WP02 output data valid.
40	1 byte	Padding byte	Do not use
41 ... 72	32 byte	WP02 process output data	IO-Link output data of the IO-Link Device wireless connected to WP02. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
73	1 byte	WP03 Output enable	0: WP03 output data not valid. 1-255: WP03 output data valid.
74	1 byte	Padding byte	Do not use
75 ... 106	32 byte	WP03 process output data	IO-Link output data of the IO-Link Device wireless connected to WP03. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
107	1 byte	WP04 Output enable	0: WP04 output data not valid. 1-255: WP04 output data valid.
108	1 byte	Padding byte	Do not use
109 ... 140	32 byte	WP04 process output data	IO-Link output data of the IO-Link Device wireless connected to WP04. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
141	1 byte	WP05 Output enable	0: WP05 output data not valid. 1-255: WP05 output data valid.
142	1 byte	Padding byte	Do not use
143 ... 174	32 byte	WP05 process output data	IO-Link output data of the IO-Link Device wireless connected to WP05. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
175	1 byte	WP06 Output enable	0: WP06 output data not valid. 1-255: WP06 output data valid.
176	1 byte	Padding byte	Do not use
177 ... 208	32 byte	WP06 process output data	IO-Link output data of the IO-Link Device wireless connected to WP06. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
209	1 byte	WP07 Output enable	0: WP07 output data not valid. 1-255: WP07 output data valid.
210	1 byte	Padding byte	Do not use

Byte	Number of bytes	Output process data	Description
211 ... 242	32 byte	WP07 process output data	IO-Link output data of the IO-Link Device wireless connected to WP07. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
243	1 byte	WP08 Output enable	0: WP08 output data not valid. 1-255: WP08 output data valid.
244	1 byte	Padding byte	Do not use
245 ... 276	32 byte	WP08 process output data	IO-Link output data of the IO-Link Device wireless connected to WP08. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Table 54: Output process data, connection 1 and connection 2

10.1.2 Connections 5 to 7

Input process data

The following table gives a description of the process data structure of the input process data and is valid for connection 5, connection 6 and connection 7.

Byte	Number of bytes	Input process data	Description
1	1 byte	DI status	Reserved
2	1 byte	Padding byte	Do not use
3 ... 4	2 byte	DI data	Reserved
5	1 byte	WP01 data status	See section <i>Input process data status</i> [► page 101].
6	1 byte	Padding byte	Do not use
7 ... 22	16 byte	WP01 process input data	IO-Link input data of the IO-Link Device wireless connected to WP01. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
23	1 byte	WP02 data status	See section <i>Input process data status</i> [► page 101].
24	1 byte	Padding byte	Do not use
25 ... 40	16 byte	WP02 process input data	IO-Link input data of the IO-Link Device wireless connected to WP02. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
41	1 byte	WP03 data status	See section <i>Input process data status</i> [► page 101].
41	1 byte	Padding byte	Do not use
43 ... 58	16 byte	WP03 process input data	IO-Link input data of the IO-Link Device wireless connected to WP03. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
59	1 byte	WP04 data status	See section <i>Input process data status</i> [► page 101].
60	1 byte	Padding byte	Do not use
61 ... 76	16 byte	WP04 process input data	IO-Link input data of the IO-Link Device wireless connected to WP04. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
77	1 byte	WP05 data status	See section <i>Input process data status</i> [► page 101].
78	1 byte	Padding byte	Do not use
79 ... 94	16 byte	WP05 process input data	IO-Link input data of the IO-Link Device wireless connected to WP05. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
94	1 byte	WP06 data status	See section <i>Input process data status</i> [► page 101].
96	1 byte	Padding byte	Do not use
97 ... 112	16 byte	WP06 process input data	IO-Link input data of the IO-Link Device wireless connected to WP06. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
113	1 byte	WP07 data status	See section <i>Input process data status</i> [► page 101].
114	1 byte	Padding byte	Do not use
115 ... 130	16 byte	WP07 process input data	IO-Link input data of the IO-Link Device wireless connected to WP07. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
131	1 byte	WP08 data status	See section <i>Input process data status</i> [► page 101].
132	1 byte	Padding byte	Do not use

Byte	Number of bytes	Input process data	Description
133 ... 148	16 byte	WP08 process input data	IO-Link input data of the IO-Link Device wireless connected to WP08. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
149	1 byte	WP09 data status	See section <i>Input process data status</i> [► page 101].
150	1 byte	Padding byte	Do not use
151 ... 166	16 byte	WP09 process input data	IO-Link input data of the IO-Link Device wireless connected to WP09. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
167	1 byte	WP10 data status	See section <i>Input process data status</i> [► page 101].
168	1 byte	Padding byte	Do not use
169 ... 184	16 byte	WP10 process input data	IO-Link input data of the IO-Link Device wireless connected to WP10. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
185	1 byte	WP11 data status	See section <i>Input process data status</i> [► page 101].
186	1 byte	Padding byte	Do not use
187 ... 202	16 byte	WP11 process input data	IO-Link input data of the IO-Link Device wireless connected to WP11. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
203	1 byte	WP12 data status	See section <i>Input process data status</i> [► page 101].
204	1 byte	Padding byte	Do not use
205 ... 220	16 byte	WP12 process input data	IO-Link input data of the IO-Link Device wireless connected to WP12. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
221	1 byte	WP13 data status	See section <i>Input process data status</i> [► page 101].
222	1 byte	Padding byte	Do not use
223 ... 238	16 byte	WP13 process input data	IO-Link input data of the IO-Link Device wireless connected to WP13. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
239	1 byte	WP14 data status	See section <i>Input process data status</i> [► page 101].
240	1 byte	Padding byte	Do not use
241 ... 256	16 byte	WP14 process input data	IO-Link input data of the IO-Link Device wireless connected to WP14. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
257	1 byte	WP15 data status	See section <i>Input process data status</i> [► page 101].
258	1 byte	Padding byte	Do not use
259 ... 274	16 byte	WP15 process input data	IO-Link input data of the IO-Link Device wireless connected to WP15. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
275	1 byte	WP16 data status	See section <i>Input process data status</i> [► page 101].
276	1 byte	Padding byte	Do not use
277 ... 292	16 byte	WP16 process input data	IO-Link input data of the IO-Link Device wireless connected to WP16. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Table 55: Input process data, connection 5 to connection 7

Output process data

The following table gives a description of the process data structure of the output process data and is valid for connection 5.

Byte	Number of bytes	Output process data	Description
1	1 byte	DO status	Reserved
2	1 byte	Padding byte	Do not use
3 ... 4	2 byte	DO data	Reserved
5	1 byte	WP01 Output enable	0: WP01 output data not valid. 1-255: WP01 output data valid.
6	1 byte	Padding byte	Do not use
7 ... 22	16 byte	WP01 process output data	IO-Link output data of the IO-Link Device wireless connected to WP01. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
23	1 byte	WP02 Output enable	0: WP02 output data not valid. 1-255: WP02 output data valid.
24	1 byte	Padding byte	Do not use
25 ... 40	16 byte	WP02 process output data	IO-Link output data of the IO-Link Device wireless connected to WP02. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
41	1 byte	WP03 Output enable	0: WP03 output data not valid. 1-255: WP03 output data valid.
41	1 byte	Padding byte	Do not use
43 ... 58	16 byte	WP03 process output data	IO-Link output data of the IO-Link Device wireless connected to WP03. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
59	1 byte	WP04 Output enable	0: WP04 output data not valid. 1-255: WP04 output data valid.
60	1 byte	Padding byte	Do not use
61 ... 76	16 byte	WP04 process output data	IO-Link output data of the IO-Link Device wireless connected to WP04. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
77	1 byte	WP05 Output enable	0: WP05 output data not valid. 1-255: WP05 output data valid.
78	1 byte	Padding byte	Do not use
79 ... 94	16 byte	WP05 process output data	IO-Link output data of the IO-Link Device wireless connected to WP05. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
94	1 byte	WP06 Output enable	0: WP06 output data not valid. 1-255: WP06 output data valid.
96	1 byte	Padding byte	Do not use
97 ... 112	16 byte	WP06 process output data	IO-Link output data of the IO-Link Device wireless connected to WP06. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
113	1 byte	WP07 Output enable	0: WP07 output data not valid. 1-255: WP07 output data valid.
114	1 byte	Padding byte	Do not use
115 ... 130	16 byte	WP07 process output data	IO-Link output data of the IO-Link Device wireless connected to WP07. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
131	1 byte	WP08 Output enable	0: WP08 output data not valid. 1-255: WP08 output data valid.
132	1 byte	Padding byte	Do not use
133 ... 148	16 byte	WP08 process output data	IO-Link output data of the IO-Link Device wireless connected to WP08. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Byte	Number of bytes	Output process data	Description
149	1 byte	WP09 Output enable	0: WP09 output data not valid. 1-255: WP09 output data valid.
150	1 byte	Padding byte	Do not use
151 ... 166	16 byte	WP09 process output data	IO-Link output data of the IO-Link Device wireless connected to WP09. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
167	1 byte	WP10 Output enable	0: WP10 output data not valid. 1-255: WP10 output data valid.
168	1 byte	Padding byte	Do not use
169 ... 184	16 byte	WP10 process output data	IO-Link output data of the IO-Link Device wireless connected to WP10. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
185	1 byte	WP11 Output enable	0: WP11 output data not valid. 1-255: WP11 output data valid.
186	1 byte	Padding byte	Do not use
187 ... 202	16 byte	WP11 process output data	IO-Link output data of the IO-Link Device wireless connected to WP11. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
203	1 byte	WP12 Output enable	0: WP12 output data not valid. 1-255: WP12 output data valid.
204	1 byte	Padding byte	Do not use
205 ... 220	16 byte	WP12 process output data	IO-Link output data of the IO-Link Device wireless connected to WP12. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
221	1 byte	WP13 Output enable	0: WP13 output data not valid. 1-255: WP13 output data valid.
222	1 byte	Padding byte	Do not use
223 ... 238	16 byte	WP13 process output data	IO-Link output data of the IO-Link Device wireless connected to WP13. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
239	1 byte	WP14 Output enable	0: WP14 output data not valid. 1-255: WP14 output data valid.
240	1 byte	Padding byte	Do not use
241 ... 256	16 byte	WP14 process output data	IO-Link output data of the IO-Link Device wireless connected to WP14. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
257	1 byte	WP15 Output enable	0: WP15 output data not valid. 1-255: WP15 output data valid.
258	1 byte	Padding byte	Do not use
259 ... 274	16 byte	WP15 process output data	IO-Link output data of the IO-Link Device wireless connected to WP15. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
275	1 byte	WP16 Output enable	0: WP16 output data not valid. 1-255: WP16 output data valid.
276	1 byte	Padding byte	Do not use
277 ... 292	16 byte	WP16 process output data	IO-Link output data of the IO-Link Device wireless connected to WP16. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Table 56: Output process data, connection 5

10.1.3 Connections 8 to 10

Input process data

The following table gives a description of the process data structure of the input process data and is valid for connection 8, connection 9 and connection 10.

Byte	Number of bytes	Input process data	Description
1	1 byte	DI status	Reserved
2	1 byte	Padding byte	Do not use
3 ... 4	2 byte	DI data	Reserved
5	1 byte	WP01 data status	See section <i>Input process data status</i> [► page 101].
6	1 byte	Padding byte	Do not use
7 ... 10	4 byte	WP01 process input data	IO-Link input data of the IO-Link Device wireless connected to WP01. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
11	1 byte	WP02 data status	See section <i>Input process data status</i> [► page 101].
12	1 byte	Padding byte	Do not use
13 ... 16	4 byte	WP02 process input data	IO-Link input data of the IO-Link Device wireless connected to WP02. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
17	1 byte	WP03 data status	See section <i>Input process data status</i> [► page 101].
18	1 byte	Padding byte	Do not use
19 ... 22	4 byte	WP03 process input data	IO-Link input data of the IO-Link Device wireless connected to WP03. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
23	1 byte	WP04 data status	See section <i>Input process data status</i> [► page 101].
24	1 byte	Padding byte	Do not use
25 ... 28	4 byte	WP04 process input data	IO-Link input data of the IO-Link Device wireless connected to WP04. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
29	1 byte	WP05 data status	See section <i>Input process data status</i> [► page 101].
30	1 byte	Padding byte	Do not use
31 ... 34	4 byte	WP05 process input data	IO-Link input data of the IO-Link Device wireless connected to WP05. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
35	1 byte	WP06 data status	See section <i>Input process data status</i> [► page 101].
36	1 byte	Padding byte	Do not use
37 ... 40	4 byte	WP06 process input data	IO-Link input data of the IO-Link Device wireless connected to WP06. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
38	1 byte	WP07 data status	See section <i>Input process data status</i> [► page 101].
39	1 byte	Padding byte	Do not use
40 ... 46	4 byte	WP07 process input data	IO-Link input data of the IO-Link Device wireless connected to WP07. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
47	1 byte	WP08 data status	See section <i>Input process data status</i> [► page 101].
48	1 byte	Padding byte	Do not use

Byte	Number of bytes	Input process data	Description
49 ... 52	4 byte	WP08 process input data	IO-Link input data of the IO-Link Device wireless connected to WP08. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
53	1 byte	WP09 data status	See section <i>Input process data status</i> [► page 101].
54	1 byte	Padding byte	Do not use
55 ... 58	4 byte	WP09 process input data	IO-Link input data of the IO-Link Device wireless connected to WP09. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
59	1 byte	WP10 data status	See section <i>Input process data status</i> [► page 101].
60	1 byte	Padding byte	Do not use
61 ... 64	4 byte	WP10 process input data	IO-Link input data of the IO-Link Device wireless connected to WP10. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
65	1 byte	WP11 data status	See section <i>Input process data status</i> [► page 101].
66	1 byte	Padding byte	Do not use
67 ... 70	4 byte	WP11 process input data	IO-Link input data of the IO-Link Device wireless connected to WP11. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
71	1 byte	WP12 data status	See section <i>Input process data status</i> [► page 101].
72	1 byte	Padding byte	Do not use
73 ... 76	4 byte	WP12 process input data	IO-Link input data of the IO-Link Device wireless connected to WP12. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
77	1 byte	WP13 data status	See section <i>Input process data status</i> [► page 101].
78	1 byte	Padding byte	Do not use
79 ... 82	4 byte	WP13 process input data	IO-Link input data of the IO-Link Device wireless connected to WP13. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
83	1 byte	WP14 data status	See section <i>Input process data status</i> [► page 101].
84	1 byte	Padding byte	Do not use
85 ... 88	4 byte	WP14 process input data	IO-Link input data of the IO-Link Device wireless connected to WP14. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
89	1 byte	WP15 data status	See section <i>Input process data status</i> [► page 101].
90	1 byte	Padding byte	Do not use
91 ... 94	4 byte	WP15 process input data	IO-Link input data of the IO-Link Device wireless connected to WP15. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
95	1 byte	WP16 data status	See section <i>Input process data status</i> [► page 101].
96	1 byte	Padding byte	Do not use
97 ... 100	4 byte	WP16 process input data	IO-Link input data of the IO-Link Device wireless connected to WP16. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Table 57: Input process data, connection 8 to connection 10

Output process data

The following table gives a description of the process data structure of the output process data and is valid for connection 8.

Byte	Number of bytes	Output process data	Description
1	1 byte	DO status	Reserved
2	1 byte	Padding byte	Do not use
3 ... 4	2 byte	DO data	Reserved
5	1 byte	WP01 Output enable	0: WP01 output data not valid. 1-255: WP01 output data valid.
6	1 byte	Padding byte	Do not use
7 ... 10	4 byte	WP01 process output data	IO-Link output data of the IO-Link Device wireless connected to WP01. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
11	1 byte	WP02 Output enable	0: WP02 output data not valid. 1-255: WP02 output data valid.
12	1 byte	Padding byte	Do not use
13 ... 16	4 byte	WP02 process output data	IO-Link output data of the IO-Link Device wireless connected to WP02. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
17	1 byte	WP03 Output enable	0: WP03 output data not valid. 1-255: WP03 output data valid.
18	1 byte	Padding byte	Do not use
19 ... 22	4 byte	WP03 process output data	IO-Link output data of the IO-Link Device wireless connected to WP03. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
23	1 byte	WP04 Output enable	0: WP04 output data not valid. 1-255: WP04 output data valid.
24	1 byte	Padding byte	Do not use
25 ... 28	4 byte	WP04 process output data	IO-Link output data of the IO-Link Device wireless connected to WP04. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
29	1 byte	WP05 Output enable	0: WP05 output data not valid. 1-255: WP05 output data valid.
30	1 byte	Padding byte	Do not use
31 ... 34	4 byte	WP05 process output data	IO-Link output data of the IO-Link Device wireless connected to WP05. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
35	1 byte	WP06 Output enable	0: WP06 output data not valid. 1-255: WP06 output data valid.
36	1 byte	Padding byte	Do not use
37 ... 40	4 byte	WP06 process output data	IO-Link output data of the IO-Link Device wireless connected to WP06. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
38	1 byte	WP07 Output enable	0: WP07 output data not valid. 1-255: WP07 output data valid.
39	1 byte	Padding byte	Do not use
40 ... 46	4 byte	WP07 process output data	IO-Link output data of the IO-Link Device wireless connected to WP07. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
47	1 byte	WP08 Output enable	0: WP08 output data not valid. 1-255: WP08 output data valid.
48	1 byte	Padding byte	Do not use
49 ... 52	4 byte	WP08 process output data	IO-Link output data of the IO-Link Device wireless connected to WP08. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Byte	Number of bytes	Output process data	Description
53	1 byte	WP09 Output enable	0: WP09 output data not valid. 1-255: WP09 output data valid.
54	1 byte	Padding byte	Do not use
55 ... 58	4 byte	WP09 process output data	IO-Link output data of the IO-Link Device wireless connected to WP09. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
59	1 byte	WP10 Output enable	0: WP10 output data not valid. 1-255: WP10 output data valid.
60	1 byte	Padding byte	Do not use
61 ... 64	4 byte	WP10 process output data	IO-Link output data of the IO-Link Device wireless connected to WP10. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
65	1 byte	WP11 Output enable	0: WP11 output data not valid. 1-255: WP11 output data valid.
66	1 byte	Padding byte	Do not use
67 ... 70	4 byte	WP11 process output data	IO-Link output data of the IO-Link Device wireless connected to WP11. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
71	1 byte	WP12 Output enable	0: WP12 output data not valid. 1-255: WP12 output data valid.
72	1 byte	Padding byte	Do not use
73 ... 76	4 byte	WP12 process output data	IO-Link output data of the IO-Link Device wireless connected to WP12. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
77	1 byte	WP13 Output enable	0: WP13 output data not valid. 1-255: WP13 output data valid.
78	1 byte	Padding byte	Do not use
79 ... 82	4 byte	WP13 process output data	IO-Link output data of the IO-Link Device wireless connected to WP13. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
83	1 byte	WP14 Output enable	0: WP14 output data not valid. 1-255: WP14 output data valid.
84	1 byte	Padding byte	Do not use
85 ... 88	4 byte	WP14 process output data	IO-Link output data of the IO-Link Device wireless connected to WP14. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
89	1 byte	WP15 Output enable	0: WP15 output data not valid. 1-255: WP15 output data valid.
90	1 byte	Padding byte	Do not use
91 ... 94	4 byte	WP15 process output data	IO-Link output data of the IO-Link Device wireless connected to WP15. For a description of the data, see manual of the manufacturer of the used IO-Link Device.
95	1 byte	WP16 Output enable	0: WP16 output data not valid. 1-255: WP16 output data valid.
96	1 byte	Padding byte	Do not use
97 ... 100	4 byte	WP16 process output data	IO-Link output data of the IO-Link Device wireless connected to WP16. For a description of the data, see manual of the manufacturer of the used IO-Link Device.

Table 58: Output process data, connection 8

10.1.4 Input process data status

Bit	Description
0 ... 2	Reserved
3	IO-Link event available This bit has the same value as attribute 20 of the instance of the Event Log Object 65 (0x41). 0: No IO-Link event is available. 1: IO-Link event is available in the instance for the port of the Event Log Object.
4	Reserved
5	Device communication (DevCom) 0: The connected device is not in PreOperate or Operate state. 1: The connected device is in PreOperate or Operate state.
6	Device error (DevErr) 0: No error, no warning. 1: Error or a warning occurred assigned to either device or port.
7	Port qualifier (PQ) 0: Input process data is not valid. 1: Input process data is valid.

Table 59: Input data status

10.2 OPC UA

The device contains an OPC UA server. An OPC UA client can establish a connection to the device and access the following parameters:

- device identification,
- identification of the IO-Link Devices
- etc.

The OPC UA client establishes a connection via the following URL:

```
opc.tcp://IP address:4840
```

For IP address, use the IP address of the device.

The client can access device parameters anonymously (read only) or with user name/password (read and write). The user name and password are set with the netFIELD Wireless Web Server.

The following figure shows a section of the information model of the device.




Figure 46: OPC UA: Information model of the device

10.2.1 Device identification

The device provides nodes for device identification. For example, the OPC UA client can read the version of the device firmware used in the `SoftwareRevision` node. The path to these nodes is

Root > Object > DeviceSet > [Device name]

Node name	Node class	Access	Description
Manufacturer	Variable	read	Device manufacturer
ManufacturerUri	Variable	read	URL of the device manufacturer
Model	Variable	read	Model name of the device
ProductCode	Variable	read	Product code of the device
RevisionCounter	Variable	read	Hardware revision of the device
SerialNumber	Variable	read	Serial number of the device
SoftwareRevision	Variable	read	Revision/version of the device firmware

Table 60: Device identification

10.2.2 Identification of connected IO-Link Devices

The device provides nodes for the identification of connected IO-Link Devices. For example, the OPC UA client can read the version of the device firmware used in the `SoftwareRevision` node. The path to these nodes is

Root > Object > DeviceSet > [Device name] >
IOLinkWirelessMaster > PortXX > Device

Node name	Node class	Access	Description
Manufacturer	Variable	read	Device manufacturer
MinCycleTime	Variable	read	Minimal cycle time
Model	Variable	read	Model name
RevisionID	Variable	read	Hardware revision
SerialNumber	Variable	read	Serial number
SoftwareRevision	Variable	read	Revision/version of the firmware
VendorID	Variable	read	Vendor identification

Table 61: Identification of the connected IO-Link Devices

10.2.3 NTP Client configuration

The OPC UA server provides nodes for configuring the NTP client.

Path to these nodes:

```
Root > Object > DeviceSet > [Device Name] >
Configuration > NtpClient > Configuration >
CurrentConfiguration
```

Node name	Node class	Access	Default	Description
NtpClientServerIpAddress	Variable	read / write	0	IP address of the NTP server The NTP client uses the set IP address to get the date and time from an NTP server. The IP address must be converted into a decimal number. The calculation is explained below the table. The value 0 disables the function.
NtpClientServerIpAddressFallback	Variable	read / write	0	IP address of the NTP server (fallback) Optional additional IP address if the NTP server cannot be reached via the IP address in the NtpClientServerIpAddress node. The IP address must be converted into a decimal number. The calculation is explained below the table. The value 0 disables the function.
NtpClientUpdateConfiguration	Method	write	-	Method for writing the nodes NtpClientServerIpAddress and NtpClientServerIpAddressFallback.

Table 62: NTP client configuration

Explanation of the calculation

To convert the IP address to a decimal number, use the following formula.
Starting from an IP address in the format A.B.C.D:

$$((A * 256 + B) * 256 + C) * 256 + D = \text{IP address as a decimal number}$$

Example of IP address 192.53.103.108

$$((192 * 256 + 53) * 256 + 103) * 256 + 108 = 3224725356$$

10.3 MQTT topics

10.3.1 General parts of a topic

The description of a topic contains parts that will be substituted.

Topic part	Description
{prefix}	Prefix of each topic. The prefix is a text used to identify a device. Configurable in the netFIELD Wireless Web Server.
[MASTER_NUMBER]	Number for each master in the gateway. Typically, the gateway has one master and MASTER_NUMBER is 1.
[PORT_NUMBER]	Number for each port of a master. If the master has 8 ports for example, PORT_NUMBER is 1 ... 8.
[DEVICE_ALIAS]	String to identify a device connected to a port of a master: masterXportY. Example: master1port3.

Table 63: General parts of a topic

10.3.2 Gateway topics

Topic	Description
{prefix}/iolink/v1/gateway/identification	Identification of the gateway: MAC address, serial number, product ID, vendor name, product name, hardware revision, firmware revision, product instance URI For an example, see Gateway Identification.
{prefix}/iolink/v1/gateway/capabilities	Capabilities of the gateway: IODD supported, MQTT supported For an example, see Gateway Capabilities.
{prefix}/iolink/v1/gateway/configuration	Network configuration of the gateway: IP configuration, IP address, subnet mask, standard gateway For an example, see Gateway Configuration.

Table 64: Gateway topics

You find examples and details about the transferred JSON objects below.

Gateway Identification

Example for the gateway identification JSON object:

```
{
  "macAddress": "01:02:03:04:05:06",
  "serialNumber": "12345678",
  "productID": "TMP34Z",
  "vendorName": "SensorCompany",
  "productName": "FlowSensor34",
  "hardwareRevision": "V2.34",
  "firmwareRevision": "V1.23",
  "productInstanceUri": "sensor.tmp.23.com"
}
```

Gateway Capabilities

JSON key	Description
ioddSupported	"iooddSupported": true: IODD is available "iooddSupported": false: IODD is not available
mqttSupported	"mqttSupported": true: MQTT is available "mqttSupported": false: MQTT is not available

Table 65: Gateway Capabilities, "JSON key"

Example for the gateway capabilities JSON object:

```
{
  "iooddSupported": true,
  "mqttSupported": false
}
```

Gateway Configuration

JSON key	Description
"ipConfiguration"	Possible values for "ipConfiguration": <ul style="list-style-type: none">• "MANUAL": Assignment of the IP address by other device specific means.• "DHCP": RFC 2131 defines the "Dynamic Host Configuration Protocol", allowing automatic assignment of IP addresses.• "DCP": PROFINET defines the "Discovery and Configuration Protocol", a link-layer protocol that allows the manual assignment of IP addresses.

Table 66: Gateway Configuration, "JSON key"

Example for the gateway configuration JSON object:

```
{
  "ethIpv4":
  [
    {
      "ipConfiguration": "MANUAL",
      "ipAddress": "192.168.1.13",
      "subnetMask": "255.255.255.0",
      "standardGateway": "192.168.1.1"
    }
  ]
}
```

10.3.3 Master topics

Topic	Description
{prefix}/iolink/v1/masters	Available master number keys and identification information: Master number, serial number, location tag For an example, see Master List.
{prefix}/iolink/v1/masters/[MASTER_NUMBER]/capabilities	Capabilities of the master: Number of ports, max. power supply (of the device) Example: {prefix}/iolink/v1/masters/1/capabilities For an example, see Master Capabilities.
{prefix}/iolink/v1/masters/[MASTER_NUMBER]/identification	Identification of the master: Vendor name, vendor ID, master ID, master type, serial number, product ID, product name, hardware revision, firmware revision, vendor URL, manual URL, application specific tag, location tag, function tag Example: {prefix}/iolink/v1/masters/1/identification For an example, see Identification.
{prefix}/iolink/v1/masters/[MASTER_NUMBER]/ports	Available port number keys: Port number, status info, device alias Example: {prefix}/iolink/v1/masters/1/ports For an example, see Port List.
{prefix}/iolink/v1/masters/[MASTER_NUMBER]/ports/[PORT_NUMBER]/capabilities	Read capability information of the port: Max power supply (of the port), port type Example: {prefix}/iolink/v1/masters/1/ports/4/capabilities For an example, see Port Capabilities.
{prefix}/iolink/v1/masters/[MASTER_NUMBER]/ports/[PORT_NUMBER]/status	Read current status of the port: Status Info, IO-Link revision, master cycle time Example: {prefix}/iolink/v1/masters/1/ports/4/status For an example, see Port Status.
{prefix}/iolink/v1/masters/[MASTER_NUMBER]/ports/[PORT_NUMBER]/configuration	Read configuration of the port: Mode, validation and backup, cycle time, vendor ID, device ID, slot number, track number, device TX power, max retry, IMA time (I-am-alive time), slot type, device low power, max PD segment length, unique ID, device alias Example: {prefix}/iolink/v1/masters/1/ports/4/configuration For an example, see Port Configuration.
{prefix}/iolink/v1/masters/[MASTER_NUMBER]/ports/[PORT_NUMBER]/datastorage	Read data storage content of the port: Vendor ID, device ID, IO-Link revision Example: {prefix}/iolink/v1/masters/1/ports/4/datastorage For an example, see Port Data Storage.

Table 67: Master topics

You find examples and details about the transferred JSON objects below.

Master List

Example for the master list JSON object:

```
[
  {
    "masterNumber": 1,
    "serialNumber": "A0A1A2A3A4",
    "locationTag": "slot 2"
  },
  {
    "masterNumber": 2,
    "serialNumber": "B0B1B2B3B4",
    "locationTag": "slot 3"
  }
]
```

Master Capabilities

Example for the master capabilities JSON object:

```
{
  "numberOfPorts": 8,
  "maxPowerSupply": {
    "value": 0.3,
    "unit": "A"
  }
}
```

Master Identification

Example for the master identification JSON object:

```
{
  "vendorName": "Vendor GmbH",
  "vendorId": 26,
  "masterId": 42,
  "masterType": "Master acc. V1.0",
  "serialNumber": "IOLM123456",
  "productId": "PROD-123456",
  "productName": "IO-Link Master",
  "hardwareRevision": "3.2.1.444R",
  "firmwareRevision": "3.2.1.888R",
  "vendorUrl": "http://www.io-link.com/io-link-master",
  "manualUrl": "http://www.io-link.com/io-link-master/manual.pdf",
  "applicationSpecificTag": "Fallback reader",
  "locationTag": "Down under",
  "functionTag": "Code reading"
}
```

Port list

JSON key	Description
statusInfo	Activated: "statusInfo": "DEVICE_ONLINE" Deactivated: "statusInfo": "DEACTIVATED"
deviceAlias	Possible values for "deviceAlias": <ul style="list-style-type: none">• "Distance_sensor"• "Pressure_sensor"• "Switching_sensor"• "Empty_port"

Table 68: Port List, "JSON key"

Example for the port list JSON object:

```
[
  {
    "portNumber": 1,
    "statusInfo": "DEVICE_ONLINE",
    "deviceAlias": "Distance_sensor"
  },
  {
    "portNumber": 2,
    "statusInfo": "DEVICE_ONLINE",
    "deviceAlias": "Pressure_sensor"
  },
  {
    "portNumber": 3,
    "statusInfo": "DEVICE_ONLINE",
    "deviceAlias": "Switching_sensor"
  },
  {
    "portNumber": 4,
    "statusInfo": "DEACTIVATED",
    "deviceAlias": "Empty_port"
  }
]
```

Port Capabilities

JSON key	Description
portType	Value for "portType" for IO-Link Wireless Master: "WIRELESS_MASTER"

Table 69: Port Capabilities, "JSON key"

Example for the port capabilities JSON object:

```
{
  "maxPowerSupply": {
    "value" : 0.3,
    "unit" : "A"
  },
  "portType" : "CLASS_A"
}
```

Port Status

JSON key	Description
statusInfo	Activated: "statusInfo": "DEVICE_ONLINE" Deactivated: "statusInfo": "Deactivated"

Table 70: Port Status, "JSON key"

Example for the IO-Link wireless port status JSON object:

```
{
  "statusInfo": "DEVICE_ONLINE",
  "iolinkRevision" : "1.1",
  "masterCycleTime" : {
    "value" : "5.0",
    "unit" : "ms"
  }
}
```

Port Configuration

JSON key	Values
mode	<ul style="list-style-type: none"> "DEACTIVATED" "IOLINK_CYCLIC" "IOLINK_ROAMING"
validationAndBackup	<ul style="list-style-type: none"> "NO_DEVICE_CHECK" "TYPE_COMPATIBLE" "TYPE_COMPATIBLE_RESTORE_ONLY" "TYPE_COMPATIBLE_BACKUP_AND_RESTORE"
slotNumber	0 ... 7
trackNumber	0 ... 2
deviceTxPower	1 ... 31
maxRetry	2 ... 31
imaTime	<ul style="list-style-type: none"> "SINGLE_SLOT" "DOUBLE_SLOT"
maxPdSegmentLength	1 ... 32

Table 71: Port Configuration, configuration values

Example for the IO-Link wireless configuration JSON object:

```
{
  "mode": "IOLINK_MANUAL",
  "validationAndBackup" : "TYPE_COMPATIBLE",
  "cycleTime" : {
    "value" : "5.0",
    "unit" : "ms"
  },
  "vendorId" : 26,
  "deviceId" : 333,
  "slotNumber" : 0,
  "trackNumber" : 1,
  "deviceTxPower" : 31,
  "maxRetry" : 2,
  "imaTime" : 771,
  "slotType" : "SINGLE_SLOT",
  "deviceLowPower" : false,
  "maxPdSegmentLength" : 2,
  "uniqueId" : [11, 12, 13, 14, 15, 16, 17, 18],
  "deviceAlias" : "Distance_sensor_1"
}
```

Example for the cycle time object JSON object:

```
{
  "value" : "5.0",
  "unit" : "ms"
}
```

Port Data Storage

Example for the port data storage JSON object:

```
{
  "header": {
    "vendorId" : 15,
    "deviceId" : 65253,
    "iolinkRevision" : "1.1"
  },
  "content": "YmFzZTY0IGVuY3J5cHRlZCBjb250ZW50"
}
```

10.3.4 Device topics

Topic	Description
{prefix}/iolink/v1/devices	Address all devices of all masters: Device alias, master number, port number For an example, see Device List.
{prefix}/iolink/v1/devices/[DEVICE_ALIAS]/capabilities	Read capability information of the device: Minimum cycle time, supported profiles Example: {prefix}/iolink/v1/devices/master1port4/capabilities For an example, see Device Capabilities.
{prefix}/iolink/v1/devices/[DEVICE_ALIAS]/identification	Read identification information of the device: Vendor ID, device ID, IO-Link revision, vendor name, vendor text, product name, product ID, product text, serial number, serial number, hardware revision, firmware revision, application specific tag, location tag, function tag Example: {prefix}/iolink/v1/devices/master1port4/identification For an example, see Device Identification.
{prefix}/iolink/v1/devices/[DEVICE_ALIAS]/processdata/value	Read process data value from the device: Get data (IO-Link, IQ value), set data (IO-Link, IQ value) Example: {prefix}/iolink/v1/devices/master1port4/processdata/value For an example, see Device Process Data.
{prefix}/iolink/v1/devices/[DEVICE_ALIAS]/processdata/getdata/value	Read process data input value from the device: Get Data (IO-Link, IQ value) Example: {prefix}/iolink/v1/devices/master1port4/processdata/getdata/value For an example, see Device Process Data Input.
{prefix}/iolink/v1/devices/[DEVICE_ALIAS]/processdata/setdata/value	Read process data output value from the device: Set Data (IO-Link, IQ value) Example: {prefix}/iolink/v1/devices/master1port4/processdata/setdata/value For an example, see Device Process Data Output.
iolink/v1/devices/[DEVICE_ALIAS]/events	Read event log from the device: Time, severity, origin, message Example: {prefix}/iolink/v1/devices/master1port4/events For an example, see Device Events.
{prefix}/iolink/v1/devices/[DEVICE_ALIAS]/parameters/[INDEX]/subindices/[SUBINDEX]/value	Read IO-Link device parameter (request, elements): Direction, index (IO-Link parameter index number), subindex (O-Link parameter subindex number), object reference (reference to NPX object holding operation result)
{prefix}/iolink/v1/devices/[DEVICE_ALIAS]/parameters/[INDEX]/value	Read IO-Link device parameter: This resource is also reachable via following URL with [SUBINDEX] set to zero. {prefix}/iolink/v1/devices/[DEVICE_ALIAS]/parameters/[INDEX]/subindices/[SUBINDEX]/value

Table 72: Device topics

You find examples and details about the transferred JSON objects below.

Device List

Example for the device list JSON object:

```
[
  {
    "deviceAlias" : "DT35",
    "masterNumber" : 1,
    "portNumber" : 1,
  },
  {
    "deviceAlias" : "DT36",
    "masterNumber" : 1,
    "portNumber" : 2,
  },
  {
    "deviceAlias" : "DT37",
    "masterNumber" : 1,
    "portNumber" : 3,
  },
  {
    "deviceAlias" : "DT38",
    "masterNumber" : 1,
    "portNumber" : 4,
  },
]
```

Device Capabilities

Example for the device capabilities JSON object:

```
{
  "minimumCycleTime" : {
    "value" : 2.3,
    "unit" : "ms"
  },
  "supportedProfiles" : [10,32770]
}
```

Device Identification

Example for the Device identification JSON object:

```
{
  "vendorId" : 26,
  "deviceId" : 42,
  "iolinkRevision" : "1.1",
  "vendorName" : "Vendor GmbH",
  "vendorText" : "IO-Link",
  "productName" : "Sensor Intelligence",
  "productId" : "PROD-123456",
  "productText" : "Light switch",
  "serialNumber" : "IOLM123456",
  "hardwareRevision" : "3.2.1.444R",
  "firmwareRevision" : "3.2.1.888R",
  "applicationSpecificTag" : "Fallback light switch at the end of the belt",
  "locationTag" : "Down under",
  "functionTag" : "Check end of belt"
}
```

Device Process Data

Example for the device process data JSON object

For an IO-Link device:

```
{
  "getData" : {
    "iolink" : {
      "valid" : true,
      "value" : [12,22,216]
    },
    "iqValue" : false
  },
  "setData" : {
    "iolink" : {
      "valid" : true,
      "value" : [128,221,134]
    },
    "iqValue" : false
  }
}
```

Device Process Data Input

Example for the device process data input JSON object

For an IO-Link device:

```
{
  "getData" : {
    "iolink" : {
      "valid" : true,
      "value" : [12,22,216]
    },
    "iqValue" : false
  }
}
```

Device Process Data Output

Example for the device process data output JSON object

For an IO-Link device:

```
{
  "getData" : {},
  "setData" : {
    "iolink" : {
      "valid" : true,
      "value" : [128,221,134]
    },
    "iqValue" : false
  }
}
```

Device Events

Example for the device events JSON object

```
[
  {
    "time" : "2018-05-18T07:31:54.123z",
    "severity" : "WARNING",
    "origin" : {
      "master" : 1,
      "port" : 1,
      "device" : "Temp sensor 1",
    },
    "message" : {
      "code" : 16912,
      "mode" : "APPEARS",
      "text" : "Device temperature over-run - Clear source of
heat"
    }
  }
]
```

10.3.5 MQTT topics

Topic	Description
{prefix}/iolink/v1/mqtt/configuration	Read configuration of MQTT client: Client mode, server address, user name, user name, password, last will, keep alive time For an example, see MQTT Configuration.
{prefix}/iolink/v1/mqtt/connectionstatus	Configuration of MQTT client: Connection status, server address, up time For an example, see MQTT Connection Status.

Table 73: MQTT topics

You find examples and details about the transferred JSON objects below.

MQTT Configuration

JSON key	Description
clientMode	Activated: "clientMode": "ACTIVE" Deactivated: "clientMode": "INACTIVE"

Table 74: MQTT Configuration, "JSON key"

Example for the MQTT configuration JSON object:

```
{
  "clientMode" : "ACTIVE",
  "serverAddress" : "192.168.2.1./mqttserver",
  "username" : "iolink_json",
  "password" : "123456",
  "lastWill" : {
    "topic" : "my temperature sensor",
    "message" : "Process data transfer stopped",
    "qoS" : "0_ONLY_ONCE",
    "retain" : true
  },
  "keepAliveTime" : 0
}
```

MQTT Connection Status

JSON key	Description
connectionStatus	Possible values for "connectionStatus": <ul style="list-style-type: none"> • CONNECTING • CONNECION_ACCEPTED • CLIENT_INACTIVE

Table 75: MQTT Connection Status, "JSON key"

Example for the MQTT connection status JSON object:

```
{
  "connectionStatus" : "CONNECTION_ACCEPTED",
  "serverAddress" : "192.168.2.1./mqttserver",
  "upTime" : 123
}
```

11 Diagnosis

11.1 Diagnosis via LEDs

11.1.1 System LED

The system status LED **SYS** can assume the states described below.











LED	Color	State	Description
SYS	Duo-LED: yellow RDY / green RUN		
	 (green)	On	The firmware is running.
	 (green)	Blinking	During the formatting of the file system
	 (yellow)	On	A system error has occurred.
	 (yellow)/  (green)	Blinking, 3x yellow, 3x green	Firmware crash, unrecoverable (an internal exception occurred that cannot be handled)
	 (yellow)/  (green)	Blinking, 1 Hz	Firmware update mode active: The firmware is idle and waiting for the update file.
	 (yellow)/  (green)	Blinking, 4 Hz	Firmware update mode active: A firmware update is being installed.
	 (gray)	Off	<ul style="list-style-type: none"> No supply voltage: No supply voltage for the device or hardware defect. During a firmware reset

Table 76: States of the SYS-LED

LED state	Definition
Blinking	The LED turns on and off in phases.
Blinking, 3x yellow, 3x green	The LED turns on and off, with a frequency of approx. 1 Hz: <ul style="list-style-type: none"> 3x yellow "On" for 500 ms and "Off" for 500 ms and 3x green "On" for 500 ms and "Off" for 500 ms.
Blinking, yellow/green, 1 Hz, 4 Hz	The LED turns on in phases yellow or green, with a frequency of approx.: <ul style="list-style-type: none"> 1 Hz: 1 x yellow "On" for 500 ms and 1 x green "On" for 500 ms, 4 Hz: 1 x yellow "On" for 125 ms and 1 x green "On" for 125 ms.

Table 77: Definitions of the states of the SYS LED

11.1.2 APL LED

The application LED **APL** indicates the internal communication status as described below.






LED	Color	State	Description
APL	Duo LED red/green/yellow (yellow = red and green simultaneously)		
	 (green)	On	IO-Link Wireless Master configured
	 (green)	Blinking	IO-Link Wireless Master communication established
	 (yellow)	On	Initialization of IO-Link Wireless Master components done
	 (red)	Blinking	IO-Link Wireless Master communication error
	 (gray)	Off	IO-Link Wireless Master components not initialized

Table 78: APL LED states

11.1.3 Supply voltage status

The supply voltage status LEDs **1L** and **2L** indicate the states described below.





LED	Color	State	Description
1L	Duo LED red/green		
	 (green)	On	1L supply voltage ok
	 (gray)	Off	No 1L supply voltage
2L	Duo LED red/green		
	 (green)	On	2L supply voltage ok
	 (gray)	Off	No 2L supply voltage

Table 79: Supply voltage status 1L and 2L

11.1.4 EtherNet/IP Adapter status

The **MS** and **NS** LEDs indicate the status of the EtherNet/IP Adapter. The **LINK** and **ACT** LEDs indicate the status of the Ethernet.

Communication status EtherNet/IP Adapter

The following table describes the LED states of the EtherNet/IP Adapter communication status.















LED	Color	State	Description
MS (module status) Position in the device overview: (7)	Duo LED red/green		
	 (green)	On	Device operational: The device is operating correctly.
	 (green)	Flashing (1 Hz)	Standby: The device has not been configured.
	 (green/red/green)	Flashing fast green/red/green	Self-test: The device performs a self-test after power-on. The following sequence is displayed during the self-test: <ul style="list-style-type: none"> • NS LED off. • MS LED turns green for approximately 250 ms, turns red for approximately 250 ms, and again turns green (and holds that state until the power-up test has completed). • NS LED turns green for approximately 250 ms, turns red for approximately 250 ms, and then turns off (and holds that state until the power-up test has completed).
	 (red/green/off)	Flashing sequence red/green/off	Flashing sequence: The flashing sequence is used to visually identify the device. The scanner can start the flashing sequence in Identity object 1 of the device. The MS LED and NS LED perform the flashing sequence simultaneously.
	 (red)	Flashing (1 Hz)	Major recoverable fault: The device has detected a major recoverable fault. E.g., an incorrect or inconsistent configuration can be considered a major recoverable fault.
	 (red)	On	Major unrecoverable fault: The device has detected a major unrecoverable fault.
	 (off)	Off	No power: The device is powered off.
NS (Network status) Position in the device overview: (8)	Duo LED red/green		
	 (green)	On	Connected: An IP address is configured, at least one CIP connection (any transport class) is established, and an Exclusive Owner connection has not timed out.
	 (green)	Flashing (1 Hz)	No connections: An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out.
	 (green/red/green)	Flashing fast green/red/green	Self-test: The device performs a self-test after power-on. Refer to the description of the MS LED in the self-test status.
	 (red/green/off)	Flashing sequence red/green/off	Flashing sequence: The flashing sequence is used to visually identify the device. The scanner can start the flashing sequence in Identity object 1 of the device. The MS LED and NS LED perform the flashing sequence simultaneously.
	 (red)	Flashing (1 Hz)	Connection timeout: An IP address is configured, and an Exclusive Owner connection for which this device is the target has timed out. The NS LED returns to steady green only when all timed out Exclusive Owner connections are reestablished.
	 (red)	On	Duplicate IP: The device has detected that its IP address is already in use.
	 (off)	(Off)	Not powered, no IP address: The device does not have an IP address (or is powered off).

Table 80: Communication status EtherNet/IP Adapter

LED state	Definition
Flashing (1 Hz)	The LED turns on and off with a frequency of 1 Hz: "on" for 500 ms, followed by "off" for 500 ms.
Flashing fast green/red/green	The MS LED or NS LED turns on green "On" for 250 ms, then red "On" for 250 ms, then green "On" (until the test is completed).
Flashing sequence red/green/off	The MS LED and NS LED each turn red "On" for 500 ms, then green "On" for 500 ms, then "Off" for 500 ms. This flashing sequence is repeated at least 6 times.

Table 81: Definition LED states communication status

Ethernet status EtherNet/IP Adapter

The following table describes the LED states of the EtherNet/IP Adapter Ethernet status.

LED	Color	State	Description
LINK Ch0: (30) , Ch1: (29)	LED green		
	● (green)	On	The device is linked to the Ethernet.
	● (off)	Off	The device has no link to the Ethernet.
ACT Ch0: (31) , Ch1: (28)	LED yellow		
	● (yellow)	Flickering (load dependent)	The device sends/receives Ethernet frames.
	● (off)	Off	The device does not send/receive Ethernet frames.

Table 82: Ethernet status EtherNet/IP Adapter

LED state	Definition
Flickering (load dependent)	The LED turns on and off with a frequency of approximately 10 Hz to indicate high Ethernet activity: "On" for approximately 50 ms, followed by "Off" for 50 ms. The LED turns on and off in irregular intervals to indicate low Ethernet activity.

Table 83: Definition LED states Ethernet status

11.1.5 Wireless track status

The wireless track status LEDs **WT1 ... WT3** indicate the states for the wireless tracks 1, 2, and 3, as described below.





LED	Color	State	Description
WT1 ... WT3	Duo LED red/green/yellow (yellow = red and green simultaneously)		
	 (green)	On	Track operational mode and track service mode
	 (yellow)	On	Track inactive
	 (red)	Blinking	Track error
	 (gray)	Off	Track off

Table 84: Wireless track status WT1 ... WT3

11.1.6 Wireless port status

The wireless port status LEDs **WP01 ... WP16** indicate the states for the wireless ports 1 ... 16 as described below.








LED	Color	State	Description
WP01 ... WP16	Duo LED red/green/yellow (yellow = red and green simultaneously)		
	 (green)	On	Port operational
	 (green)	Blinking	Communication ready
	 (yellow)	On	Pairing success
	 (yellow)	Blinking	Port ready
	 (red)	Blinking	Port communication lost, pairing timeout
	 (red)	On	Port errors: Pairing wrong slot-type, revision fault, compatibility fault, serial number fault, process data fault, or cycle time fault.
	 (gray)	Off	Port inactive

Table 85: Wireless track status WP01 ... WP16

11.2 Diagnosis via EtherNet/IP

The IO-Link Wireless Master device NFD-3090-EIS-IOLMW contains the Event Log object with information about IO-Link events. The PLC can read attributes of the Event Log object, in order to get the „Event Qualifier“ and „Event Code“ of an IO-Link Event. Each IO-Link port has an assigned CIP instance.

Section *Event Log Object 65 (0x41)* [► page 122] describes the attributes of the object.

11.2.1 Event Log Object 65 (0x41)

The Event Log Object contains information on IO-Link events.

Instance 0 (class attributes)

Attribute	Name	NV	Access	Data type	Description	Default
1 (0x01)	Revision	NV	Get	UINT	Revision of this object	1
2 (0x02)	Max. instance	NV	Get	UINT	Number of IO-Link ports	Number of available IO-Link ports
32 (0x20)	Time Format	NV	Get	USINT	Data type identifier of the time format Only THE STIME data type is supported.	204 (0xCC) = STIME
33 (0x21)	Present Time	NV	Get	STIME	Default for time value Applies to all instances.	0

Table 86: Class attributes event log object 65 (0x41)

Instances 100, 101, ... (instance attributes)

The following table shows the mapping of CIP instances to the IO-Link ports.

IO-Link port	CIP instance
1	100
2	101
3	102
...	...

Table 87: Mapping CIP instances to IO-Link ports

The following table describes the attributes of the instances 100, 101, ...

Attribute	Name	NV	Access	Data type	Description	Default
2 (0x02)	State	V	Get	USINT	State of this instance 0: Does not exist 1: Stopped 2: Empty 3: Available 4: Full/Override 5: Full/Stopped 6 – 255: Reserved	-

Attribute	Name	NV	Access	Data type	Description	Default
9 (0x09)	Logged Data Configuration	NV	Get / Set	BYTE	Configures which data is stored in the event log. Bit 0 = 0: Enter event without time value Bit 0 = 1: Enter event with time value Bits 1 – 7: Reserved (always 0).	0
10 (0x0A)	Log Full Action	NV	Get / Set	USINT	Configures what to do when a new event is detected and the log is full. 0: Stop 1: Scroll 2 – 255: Reserved	1
11 (0x0B)	Duplicate Event Action	NV	Get / Set	USINT	Configures what to do when a double event is detected. 0: Ignore 1: Add 2 – 255: Reserved	1
12 (0x0C)	Event/Data Log Maximum Size	V	Get	UDINT	Max. Number of allowed entries in the event log.	8
13 (0x0D)	Event/Data Log Size	V	Get	UDINT	The current number of entries in the event log. Values: 0 to maximum (= value of the attribute 12).	0
14 (0x0E)	Event/Data Log	V	Get Get Member Remove Member	ARRAY of STRUCT	List of all registered events. An entry contains the IO-Link Event Qualifier (USINT) and the IO-Link Event Code (UINT). Attribute 9 specifies whether a time stamp (STIME) is also entered. The structure of an entry is described below.	0
19 (0x13)	Log Full	V	Get	BOOL	Log full? Incorrect: Log not full True: Log full	Wrong
20 (0x14)	Log Contains Entries	V	Get	BOOL	Log contains entries? False: Log is empty. True—Log contains events.	Wrong
21 (0x15)	Log Overrun	V	Get	BOOL	Log Overflow? False: No Log Overflow True - Log Overflow	Wrong
22 (0x16)	Sequential Event/Data Access	V	Get	STRUCT	Easy read access to event entries. If there are one or more entries in the event log, get_attribute_Single reads the first entry, which is then removed from the event log. If there is no entry in the event log, get_attribute_Single does not return any data.	-
24 (0x18)	Event Identifier Format	NV	Get / Set	USINT	Format of a log entry 0 – 3: Reserved 4: 24 bits in the format USINT + UINT 5 – 255: Reserved	4

Table 88: Instance attributes event log object 65 (0x41)

Attribute 14: Structure of a log entry

The value of attribute 9 determines the structure of a log entry.

Structure of a log entry	Description
USINT	IO-Link Event Qualifier, always available.
UINT	IO-Link Event Code, always available.

Structure of a log entry	Description
STIME	System time The system time is available only if attribute 9 bit 0 = 1.

Table 89: Structure of a log entry

Services

Service code	Service name	Class level	Instance level	Description
5 (0x05)	Reset	-	Yes	Reset
14 (0x0E)	Get Attribute Single	Yes	Yes	Read an attribute
16 (0x10)	Set Attribute Single	-	Yes	Write an attribute value
24 (0x18)	Get Member	-	Yes	Read the entry
27 (0x1B)	Remove Member	-	Yes	Delete entry

Table 90: Services Event Log Object 65 (0x41)

11.2.2 CIP status

CIP status	Description
0 (0x00)	Success The addressed object has successfully performed the service.
1 (0x01)	Connection failure A connection-related service failed. The error may have occurred anywhere along the connection path.
2 (0x02)	Resource not available Some resources the object needs to perform the service are not available.
3 (0x03)	Invalid parameter value See CIP status 32 (0x20).
4 (0x04)	Path segment error A path segment error has occurred. The path information could not be evaluated.
5 (0x05)	Path destination unknown The addressed CIP class or CIP instance is unknown.
6 (0x06)	Partial transfer Only a part of the data could be transferred.
7 (0x07)	Connection lost The connection for messaging has been lost.
8 (0x08)	Service not supported The required service has not been defined or implemented for this object class or instance.
9 (0x09)	Invalid attribute value Detection of invalid attribute data.
10 (0x0A)	Attribute list error An attribute in the response "Get_Attribute_List" or "Set_Attribute_List" has a status not equal to 0.
11 (0x0B)	Already in requested mode/state The object is already in the mode or state requested by the service.
12 (0x0C)	Object state conflict The object is not able to perform the requested service in the current mode or state.
13 (0x0D)	Object exists already It has been tried to create an instance of an existing object.

CIP status	Description
14 (0x0E)	Attribute not settable It has been tried to change a non-modifiable attribute.
15 (0x0F)	Violation of rights The check of authorizations or rights failed.
16 (0x10)	Device state conflict The current mode or state of the device prevents the execution of the requested service.
17 (0x11)	Reply data too large The data to be transmitted requires more space than the allocated response buffer has.
18 (0x12)	Fragmentation of a primitive value The service specifies a function to fragment a primitive data value (e.g. to halve a REAL data type) and can thus not be executed.
19 (0x13)	Not enough data The service did not supply all required data to perform the specified operation.
20 (0x14)	Attribute not supported An unsupported attribute has been specified in the request.
21 (0x15)	Too much data The service supplied more data than expected.
22 (0x16)	Object does not exist The specified object does not exist in the device.
23 (0x17)	Service fragmentation sequence not in progress The fragmentation sequence for this service is currently not active for this data.
24 (0x18)	No stored attribute data The attribute data for this object has not been saved before requesting the service.
25 (0x19)	Saving attempt failed The attribute data of the object could not be saved because an error occurred during the attempt to save the data.
26 (0x1A)	Routing failure, request packet too large The routing device had to abort the service because the request packet of this service was too large for the transmission in the network on the path to the destination.
27 (0x1B)	Routing failure, response packet too large The routing device had to abort the service because the response packet of this service was too large for the transmission in the network on the path from the destination.
28 (0x1C)	Missing entry data in attribute list The service could not supply an attribute of an attribute list that it needs to perform the requested behavior.
29 (0x1D)	Invalid attribute value list The service returns a list of attributes containing the status information "invalid attributes".
30 (0x1E)	Embedded service error If the embedded service is an IO-Link service: The IO-Link-specific error codes within the CIP data provide further information of the IO-Link master or IO-Link-Device.
31 (0x1F)	Vendor-specific error A Vendor-specific error has occurred. This Vendor-specific error occurs if none of the general error codes can be used.

CIP status	Description
32 (0x20)	Invalid parameter A parameter of the request is invalid because it does not meet the requirements of the CIP specification and/or the requirements defined in the specification of an application object.
33 (0x21)	Write-once value or medium already written An attempt was made to modify the values of a medium that have already been written and cannot be written a second time.
34 (0x22)	Invalid reply received An invalid reply has been received because, e.g., a reply service code does not match the request service code or because the reply is shorter than the expected minimum size.
35 (0x23) – 36 (0x24)	Reserved Reserved for future extensions of the CIP standard.
37 (0x25)	Error in the key segment The key segment (the first segment in the path) does not match the destination module. More information about which part of the key check failed, see object status.
38 (0x26)	Path size invalid The path to an object cannot be routed due to lacking information or too much routing data.
39 (0x27)	Unexpected attribute in list The attempt has been made to set an attribute that must not be set in the current situation.
40 (0x28)	Invalid member ID The member ID specified in the request is not available in the class/ instance or attribute.
41 (0x29)	Member cannot be modified A request has occurred to modify a member that cannot be modified.
42 (0x2A)	General error in "Group 2 only server" This DeviceNet-specific error cannot occur in EtherNet/IP.
43 (0x2B) – 207 (0xCF)	Reserved Reserved for future extensions of the CIP standard.
208 (0xD0) – 255 (0xFF)	Reserved for object class and service errors An object-class-specific error has occurred.

Table 91: Error codes (CIP status)

11.3 Diagnosis over IO-Link

11.3.1 Event Qualifier

The Event Qualifier is a bit-coded information about the event.




Figure 47: Event Qualifier

Bit	Name	Description
Bit 6–7	Mode	0: reserved 1: Event single shot 2: Event disappears 3: Event appears
Bit 4–5	Type	0: reserved 1: Notification 2: Warning 3: Error
Bit 3	Source	0: Device (remote) 1: Master/Port
Bit 0–2	Instance	0: unknown 1–3: reserved 4: Application 5–7: reserved

Table 92: Event Qualifier

11.3.2 IO-Link Wireless Master Event Codes

Event code	Description	Type	Remedy
0x0000	No malfunction	Notification	No action required
0xFF21	Communication to Wireless Device (IO-Link Device is connected to Bridge)	Event	No action required
0xFF22	Communication loss to IO-Link Device (IO-Link Device is disconnected from Bridge)	Error	Check connection from IO-Link Device to the Bridge
0xFFB1	Max Retry error, indicating a packet loss The W-Master cannot send a message to W-Device after MaxRetry attempts. This error indicates that one packet failed to be transmitted successfully. This can be for example the result of a noisy environment (RF-wise). It affects the PER (Packet Error Ratio) of the system.	Error	An excessive PER requires a check of the system configuration (ranges, operating channels, etc.).
0xFFB2	IMA timeout The W-Master did not receive a message from the connected W-Device within the IMA timeout. This error indicates that the IOLW connection failed. Possibly this leads to "Communication loss" 0xFF22.	Error	Check connection from IO-Link Device to the Bridge

Table 93: IO-Link Wireless Master Event Codes

11.3.3 IO-Link Device Event Codes (common)

The following table lists standard IO-Link Device Event Codes. For device-specific Event Codes or remedy, use the manual of the used IO-Link Device.

Event code	Description	Type	Remedy (common)
0x0000	No malfunction	Notification	No action required
0x1000	General malfunction (unknown error)	Error	See manual of the used IO-Link Device
0x1800 – 0x18FF	Vendor-specific	-	See manual of the used IO-Link Device
0x4000	Temperature fault – overload	Error	Check temperature, find source for overload
0x4210	Device temperature overrun	Warning	Clear source of heat
0x4220	Device temperature underrun	Warning	Insulate IO-Link Device
0x5000	Device hardware fault	Error	Exchange IO-Link Device
0x5010	Component malfunction	Error	Repair or exchange
0x5011	Non-volatile memory loss	Error	Check batteries
0x5012	Batteries low	Warning	Exchange batteries
0x5013	HMI button pressed	Notification	-
0x5100	General power supply fault	Error	Check availability of power supply
0x5101	Fuse blown/open	Error	Exchange fuse
0x5110	Primary supply voltage overrun	Warning	Check tolerance of 1L+ voltage
0x5111	Primary supply voltage underrun	Warning	Check tolerance of 1L+ voltage
0x5112	Secondary supply voltage fault (Port Class B)	Warning	Check tolerance of 2L+ voltage
0x6000	Device software fault	Error	Check firmware revision
0x6320	Parameter error	Error	Check data sheet and values
0x6321	Parameter missing	Error	Check data sheet
0x6350	Parameter changed	Error	Check configuration
0x7700	Wire break of a subordinate device	Error	Check installation
0x7701 – 0x770F	Wire break of subordinate device 1 ... device 15	Error	Check installation
0x7710	Short circuit	Error	Check installation
0x7711	Ground fault	Error	Check installation
0x8C00	Technology-specific application fault	Error	Reset Device
0x8C01	Simulation active	Warning	Check operational mode
0x8C10	Process variable range overrun – Process Data uncertain	Warning	Check configuration of device
0x8C20	Measurement range exceeded	Error	Check application
0x8C30	Process variable range underrun – Process Data uncertain	Warning	Check configuration of device
0x8C40	Maintenance required	Warning	Clean
0x8C41	Maintenance required	Warning	Refill
0x8C42	Maintenance required	Warning	Exchange wear and tear parts
0x8CA0 – 0x8DFF	Vendor-specific	-	See manual of the used IO-Link Device
0xB000 – 0xB0FF	Safety extensions	-	See manual of the used IO-Link Device
0xB100 – 0xBFFF	Profile-specific	-	See manual of the used IO-Link Device
0xFF91	Internal Data Storage upload request	Notification (single shot)	See manual of the used IO-Link Device

Event code	Description	Type	Remedy (common)
0xFFB9	Retry error	Error	See manual of the used IO-Link Device
Any other code	Reserved	-	See manual of the used IO-Link Device

Table 94: IO-Link Device Event Codes (common)

12 Technical data

12.1 Technical data device

Category	Parameter	Value		
Product	Part number	1912.122		
	Model	NFD-3090-EIS-IOLMW		
	Description	netFIELD IO-Link Wireless Master EtherNet/IP Adapter		
	Function	IO-Link Master Wireless for EtherNet/IP with 2 tracks for up to 16 channels		
Communication controller	Type	netX 90		
Integrated memory	RAM	16 MB SDRAM		
	FLASH	8 MB		
Ethernet communication	Real-Time Ethernet	EtherNet/IP Adapter		
Ethernet interface	Interface type	100BASE-TX, 10BASE-T, isolated		
	Auto-negotiation, Auto crossover	yes		
	Connectors	X31: Ethernet interface, M12, D-coded, EtherNet/IP port 1 X32: Ethernet interface, M12, D-coded, EtherNet/IP port 2		
LEDs	System and application	SYS	System status	green/ yellow
		APL	Application status	red/green
	Power supply	1L (X21)	1L power supply (DC 24 V)	red/green
		2L (X21)	2L power supply (DC 24 V)	red/green
	EtherNet/IP communication	MS	Module status	red/green
		NS	Network status	red/green
	Ethernet	LINK (X31)	Link status, connector X31	green
		ACT (X31)	Activity status, connector X31	yellow
		LINK (X32)	Link status, connector X32	green
		ACT (X32)	Activity status, connector X32	yellow
	Wireless tracks	WT01 ... WT03	IO-Link wireless track status, antenna X1 ... X3	red/yellow/ green
	Wireless ports	WP01 ... WP08	Port status, wireless IO-Link ports 1 to 8	red/yellow/ green
		WP09 ... WP16	Port status, wireless IO-Link ports 9 to P16	red/yellow/ green
Power supply 1L, 2L	Voltage supply	24V DC, -25%/+30% (18 V DC ... 31.2 V DC)		
	Power consumption	1L: 0.2 A (at 24 V DC), 2L: 0.1 A (at 24 V DC)		
	Connectors	X21: Power supply input (Power In), M12, L-coded X22: Power supply output (Power Out), M12, L-coded		
	Power consumption (power connectors)	Max. 16 A, Max. current of the device including pass through must not exceed 16 A for 1L and 2L. Observe derating for the maximum current depending on the ambient temperature.		
	Revers polarity protection	Yes		

Category	Parameter	Value
Ambient conditions	Ambient temperature (operation), Air flow, during measurement	-25 °C ... +70 °C, $V \leq 0,5 \text{ m/s}$
	Ambient temperature (storage)	-40 °C ... +85 °C
	Max. temperature change	3 K / min
	Humidity	5 ... 95% relative humidity, no condensation permitted
	Operating height	0 ... 2000 m
	Over voltage category	II (EN 60664-1)
Device	Dimensions (L x W x H)	200 x 30 x 20 mm
	Housing	Plastics
	Weight	212 g, with 3 antennas: 227 g
	Mounting/installation	Screw mounting, with 2x M4 screws to the 2 mounting holes. The upper screw makes contact to FE (functional earth).
	Tightening torque	1.2 Nm
	Protection class	IP67
Conformity	RoHS	EN IEC 63000:2018 / BS EN IEC 63000:2018
Compliance with EMC	CE sign	yes
	UKCA sign	yes
Approvals	FCC	FCC ID: 2ANEG002
	ISED	IC ID: 24152-0002
	RED	Certificate: In preparation
Firmware download	Web pages	netFIELD Wireless Web Server
Configuration	Software	EtherNet/IP Scanner, netFIELD Wireless Web Server, IO-Link E.T.

Table 95: Technical data NFD-3090-EIS-IOLMW

Category	Parameter	Value
Product data	Name	Wifi Antenna 2.4G rubber antenna
	Model	TLW2.5A-SMA-Male
	Type	Monopole whip antenna
	Manufacturer	Silram Technologies Ltd., Kfar Saba, Israel
Electrical specifications	Frequency Range	2400-2500 MHz
	Gain	1.6 dBi
	Polarization	Vertical
	Radiation	Omni
Mechanical specifications	Connector	Regular SMA-Male
	Height	25.6 mm

Table 96: Technical data SMA antenna

12.2 Technical data IO-Link Wireless Master

Parameter	Value
Tracks and IO-Link Devices	2 wireless tracks for up to 16 IO-Link Devices
Radio frequencies	RFch (RF channel center frequency): 2403 ... 2478 MHz (wireless channels 3 – 78, configurable). The IO-Link Wireless Master uses the frequencies (wireless channels) 2401 (1), 2402 (2), 2479 (79), 2480 (80) for network configurations purposes and cannot be configured for communication purposes.
Range of the wireless function	Max. 10 m distance
Masters per cell	Max. 3 masters within a circle of 20 m diameter
Antennas	3 SMA antennas

Table 97: Technical data IO-Link Wireless Master

12.3 Technical data protocol

Parameter	Value
Connection 1 "Exclusive Owner – 8 ports x 32 bytes	Input data: 276 bytes, Output data: 276 bytes
Connection 2 "Exclusive Owner – 8 ports x 32 bytes w/o Config	
Connection 3 "Listen Only – 8 ports x 32 bytes	Input data: 276 bytes, output data: 0 bytes
Connection 4 "Input Only – 8 ports x 32 bytes	
Connection 5 "Exclusive Owner - 16 ports x 16 bytes w/o Config	Input data: 292 bytes, Output data: 292 bytes
Connection 6 "Listen Only - 16 ports x 16 bytes	
Connection 7 "Input Only - 16 ports x 16 bytes	Input data: 292 bytes, output data: 0 bytes
Connection 8 "Exclusive Owner - 16 ports x 4 bytes w/o Config	
Connection 9 "Listen Only - 16 ports x 4 bytes	Input data: 100 bytes, Output data: 100 bytes
Connection 10 "Input Only - 16 ports x 4 bytes	
I/O connection types (implicit)	Exclusive ownerOwner Input Only Listen Only
I/O connection trigger type	Cyclic
Maximum number of I/O connections (class 1)	3
Maximum number of message connections (class 3)	6
Predefined standard objects	Identity Object (0x01) Message Router Object (0x02) Assembly Object (0x04) Connection Manager (0x06) Event Log Object (0x41) DLR Object (0x47) QoS Object (0x48) TCP/IP Interface Object (0xF5) Ethernet Link Object (0xF6)
DHCP	Supported (factory setting)
BOOTP	Supported
Fixed IP address	Supported
Duplex mode	Half duplex, full duplex, auto-negotiation
MDI mode	MDI, MDI-X, Auto-MDIX
ACD (Address Conflict Detection)	Supported
Integrated switch	Supported
Reset services	CIP reset services: Identity Object, Reset Services Type 0 and 1
Data transport layer	Ethernet II, IEEE 802.3
Interface type	10BASE-T, 100BASE-TX, isolated

Table 98: Technical data EtherNet/IP Adapter

12.4 Technical data netFIELD Wireless Web Server

Parameter	Value
HTTP	HTTP/1.1
Port	80
Connections	Max. 8 simultaneous connections One connection is being processed.
JavaScript	Required
HTTPS	Not supported

Table 99: Technical Data Web Server

12.5 OPC UA Server

Parameter	Description
OPC UA Server	According to "IO-Link Companion Specification": http://opcfoundation.org/UA/IOLink/ Vendor-specific information model: http://www.hilscher.com/UA/IOLink/Wireless
Server profile	Micro Embedded Device
Protocol	OPC UA TCP
User access	Anonymous (Read access only) User name / password (Read and write access)
Number of sessions	2
Number subscriptions per session	2
Number „Monitored Items“ per session	20
Data coding	UA binary

Table 100: OPC UA Server

12.6 MQTT Client

Parameter	Description
MQTT	Client
Client services	Publish
Protocols	MQTT over TCP
Topic size	Max. 256 bytes individually per MQTT publication and up to 256 bytes of common topic prefix of the associated MQTT connection
Topics	Topic: Printable UTF-8 string, NUL-terminated, multi-byte encoding (MBCS) Payload: JSON
Will Topic	Max. 256 bytes
Quality of Service	QoS 0, QoS 1, and QoS 2
IP standard	IPv4
Port	1883 (default), MQTT unencrypted
MQTT standard	V3.1.1
Restriction	The Subscribe service is not supported.

Table 101: Technical data MQTT Client

14 Approvals

14.1 FCC/ISED

CAUTION: Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

The FCC Wants You to Know

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

FCC Warning

Hilscher Gesellschaft für Systemautomation mbH has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment.

ISED Warning

Hilscher Gesellschaft für Systemautomation mbH n'approuve aucune modification apportée à l'appareil par l'utilisateur, quelle qu'en soit la nature. Tout changement ou modification peuvent annuler le droit d'utilisation de l'appareil par l'utilisateur.

Interference statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Wireless notice

This device complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Le présent appareil est conforme à l'exposition aux radiations FCC / ISED définies pour un environnement non contrôlé et répond aux directives d'exposition de la fréquence de la FCC radiofréquence (RF) et RSS-102 de la fréquence radio (RF) ISED règles d'exposition. L'émetteur ne doit pas être colocalisé ni fonctionner conjointement avec à autre antenne ou autre émetteur.

15 Appendix

15.1 References

IO-Link Wireless

IO-Link Community, IO-Link Wireless System Extensions, Specification, Version 1.1, March 2018, Order No: 10.112

IO-Link

IO-Link Community, JSON Integration for IO-Link, Specification, Version 1.0.0, March 2020, Order No: 10.222

Safety standards

American National Standards Institute, Inc.: American National Standard, Product Safety Information in Product Manuals, Instructions, and Other Collateral Materials, ANSI Z535.6-2016, English, 2016.

DIN Deutsches Institut für Normung e. v. and VDE Verband der Elektrotechnik Elektronik Informationstechnik e. V.: German standard, Equipment for audio/video, information and communication technology - Part 1: Safety requirements, (IEC 62368-1:2014, modified + Cor.:2015); English version EN 62368-1:2014 + AC:2015, English, 2016-05.

15.2 Conventions in this document

Instructions

1. Operation purpose
2. Operation purpose
 - Instruction

Results

- ↗ Intermediate result
- ⇒ Final result

Signs




Sign	Note
	General note
	Important note that must be followed to prevent malfunctions.
	Reference to further information

Table 102: Signs

Signal words





Signal word	Description
	Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
	Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
	Indicates a hazardous situation, which if not avoided, may result in minor or moderate Injury.
	Indicates a property damage message.

Table 103: Signal words

15.3 Directives and standards

The following table lists the directives and standards applicable to the netFIELD IO-Link Wireless Master EtherNet/IP Adapter NFD-3090-EIS-IOLM/W device.

	European Union	United Kingdom
Directives/ statutory instrument	2014/53/EU RED Directive, 2014/30/EU EMC Directive, 2011/65/EU RoHS Directive changed by directive 2015/863/EU amending annex II	Electromagnetic Compatibility Regulations 2016, Radio Equipment Regulation 2017, Electrical Equipment (Safety) Regulation 2016, The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic, Equipment Regulations 2012
Emission	EN IEC 61000-6-3	BS EN IEC 61000-6-3
Electromagnetic compatibility of multimedia equipment	EN 55032:2015	BS EN 55032:2015
ElectroMagnetic Compatibility (EMC) standard for radio equipment and services	ETSI EN 301489-1 V2.2.3	ETSI EN 301489-1 V2.2.3
Part 17: Specific conditions for Broadband Data Transmission Systems	ETSI EN 301489-17 V3.2.4	ETSI EN 301489-17 V3.2.4
Immunity	EN 61000-6-2:2019-11	BS EN 61000-6-2:2019-11
Electrostatic discharge (ESD) (air and contact discharge method)	EN 61000-4-2	BS EN 61000-4-2
Radiated immunity	EN 61000-4-3	BS EN 61000-4-3
Fast transient interferences (Burst)	EN 61000-4-4	BS EN 61000-4-4
Surge immunity	EN 61000-4-5	BS EN 61000-4-5
Conducted immunity	EN 61000-4-6	BS EN 61000-4-6
Wideband transmission systems	ETSI EN 300328 V2.2.2	ETSI EN 300328 V2.2.2
Human exposure restrictions for electromagnetic fields	EN IEC 62311:2020, EN 62479:2010 (German Version)	BS EN IEC 62311:2020, BS EN 62479:2010
Audio/video, information and communication technology equipment - Part 1: Safety requirements	EN 62368-1: 2020+A11:2020	BS EN 62368-1: 2020+A11:2020

Table 104: Directives and standards netFIELD IO-Link Wireless Master device

15.4 Legal notes

Copyright

© Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying materials (in the form of a user's manual, operator's manual, Statement of Work document and all other document types, support texts, documentation, etc.) are protected by German and international copyright and by international trade and protective provisions. Without the prior written consent, you do not have permission to duplicate them either in full or in part using technical or mechanical methods (print, photocopy or any other method), to edit them using electronic systems or to transfer them. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. Illustrations are provided without taking the patent situation into account. Any company names and product designations provided in this document may be brands or trademarks by the corresponding owner and may be protected under trademark, brand or patent law. Any form of further use shall require the express consent from the relevant owner of the rights.

Important notes

Utmost care was/is given in the preparation of the documentation at hand consisting of a user's manual, operating manual and any other document type and accompanying texts. However, errors cannot be ruled out. Therefore, we cannot assume any guarantee or legal responsibility for erroneous information or liability of any kind. You are hereby made aware that descriptions found in the user's manual, the accompanying texts and the documentation neither represent a guarantee nor any indication on proper use as stipulated in the agreement or a promised attribute. It cannot be ruled out that the user's manual, the accompanying texts and the documentation do not completely match the described attributes, standards or any other data for the delivered product. A warranty or guarantee with respect to the correctness or accuracy of the information is not assumed.

We reserve the right to modify our products and the specifications for such as well as the corresponding documentation in the form of a user's manual, operating manual and/or any other document types and accompanying texts at any time and without notice without being required to notify of said modification. Changes shall be taken into account in future manuals and do not represent an obligation of any kind, in particular there shall be no right to have delivered documents revised. The manual delivered with the product shall apply.

Under no circumstances shall Hilscher Gesellschaft für Systemautomation mbH be liable for direct, indirect, ancillary or subsequent damage, or for any loss of income, which may arise after use of the information contained herein.

Liability disclaimer

The hardware and/or software was created and tested by Hilscher Gesellschaft für Systemautomation mbH with utmost care and is made available as is. No warranty can be assumed for the performance or flawlessness of the hardware and/or software under all application conditions and scenarios and the work results achieved by the user when using the hardware and/or software. Liability for any damage that may have occurred as a result of using the hardware and/or software or the corresponding documents shall be limited to an event involving willful intent or a grossly negligent violation of a fundamental contractual obligation. However, the right to assert damages due to a violation of a fundamental contractual obligation shall be limited to contract-typical foreseeable damage.

It is hereby expressly agreed upon in particular that any use or utilization of the hardware and/or software in connection with

- Flight control systems in aviation and aerospace;
- Nuclear fission processes in nuclear power plants;
- Medical devices used for life support and
- Vehicle control systems used in passenger transport

shall be excluded. Use of the hardware and/or software in any of the following areas is strictly prohibited:

- For military purposes or in weaponry;
- For designing, engineering, maintaining or operating nuclear systems;
- In flight safety systems, aviation and flight telecommunications systems;
- In life-support systems;
- In systems in which any malfunction in the hardware and/or software may result in physical injuries or fatalities.

You are hereby made aware that the hardware and/or software was not created for use in hazardous environments, which require fail-safe control mechanisms. Use of the hardware and/or software in this kind of environment shall be at your own risk; any liability for damage or loss due to impermissible use shall be excluded.

Warranty

Hilscher Gesellschaft für Systemautomation mbH hereby guarantees that the software shall run without errors in accordance with the requirements listed in the specifications and that there were no defects on the date of acceptance. The warranty period shall be 12 months commencing as of the date of acceptance or purchase (with express declaration or implied, by customer's conclusive behavior, e.g. putting into operation permanently).

The warranty obligation for equipment (hardware) we produce is 36 months, calculated as of the date of delivery ex works. The aforementioned provisions shall not apply if longer warranty periods are mandatory by law pursuant to Section 438 (1.2) BGB, Section 479 (1) BGB and Section 634a (1) BGB [Bürgerliches Gesetzbuch; German Civil Code] If, despite of all due care taken, the delivered product should have a defect, which already existed at the time of the transfer of risk, it shall be at our discretion to either repair the product or to deliver a replacement product, subject to timely notification of defect.

The warranty obligation shall not apply if the notification of defect is not asserted promptly, if the purchaser or third party has tampered with the products, if the defect is the result of natural wear, was caused by unfavorable operating conditions or is due to violations against our operating regulations or against rules of good electrical engineering practice, or if our request to return the defective object is not promptly complied with.

Costs of support, maintenance, customization and product care

Please be advised that any subsequent improvement shall only be free of charge if a defect is found. Any form of technical support, maintenance and customization is not a warranty service, but instead shall be charged extra.

Additional guarantees

Although the hardware and software was developed and tested in-depth with greatest care, Hilscher Gesellschaft für Systemautomation mbH shall not assume any guarantee for the suitability thereof for any purpose that was not confirmed in writing. No guarantee can be granted whereby the hardware and software satisfies your requirements, or the use of the hardware and/or software is uninterrupted or the hardware and/or software is fault-free.

It cannot be guaranteed that patents and/or ownership privileges have not been infringed upon or violated or that the products are free from third-party influence. No additional guarantees or promises shall be made as to whether the product is market current, free from deficiency in title, or can be integrated or is usable for specific purposes, unless such guarantees or promises are required under existing law and cannot be restricted.

Confidentiality

The customer hereby expressly acknowledges that this document contains trade secrets, information protected by copyright and other patent and ownership privileges as well as any related rights of Hilscher Gesellschaft für Systemautomation mbH. The customer agrees to treat as confidential all of the information made available to customer by Hilscher Gesellschaft für Systemautomation mbH and rights, which were disclosed by Hilscher Gesellschaft für Systemautomation mbH and that were made accessible as well as the terms and conditions of this agreement itself.

The parties hereby agree to one another that the information that each party receives from the other party respectively is and shall remain the intellectual property of said other party, unless provided for otherwise in a contractual agreement.

The customer must not allow any third party to become knowledgeable of this expertise and shall only provide knowledge thereof to authorized users as appropriate and necessary. Companies associated with the customer shall not be deemed third parties. The customer must obligate authorized users to confidentiality. The customer should only use the confidential information in connection with the performances specified in this agreement.

The customer must not use this confidential information to his own advantage or for his own purposes or rather to the advantage or for the purpose of a third party, nor must it be used for commercial purposes and this confidential information must only be used to the extent provided for in this agreement or otherwise to the extent as expressly authorized by the disclosing party in written form. The customer has the right, subject to the obligation to confidentiality, to disclose the terms and conditions of this agreement directly to his legal and financial consultants as would be required for the customer's normal business operation.

Export provisions

The delivered product (including technical data) is subject to the legal export and/or import laws as well as any associated regulations of various countries, especially such laws applicable in Germany and in the United States. The products / hardware / software must not be exported into such countries for which export is prohibited under US American export control laws and its supplementary provisions. You hereby agree to strictly follow the regulations and to yourself be responsible for observing them. You are hereby made aware that you may be required to obtain governmental approval to export, reexport or import the product.

15.5 Registered trademarks

EtherNet/IP™ is a trademark of the ODVA (Open DeviceNet Vendor Association, Inc.).

IO-Link™ and IO-Link wireless™ are trade names of the “IO-Link Community”.

All other brands mentioned are property of their respective owner of the rights. Any company names and product designations provided in this document may be brands (company names or trademarks) of the corresponding owner and may be protected under trademark or patent law.

List of figures

Figure 1:	Device overview, NFD-3090-EIS-IOLMW	7
Figure 2:	QR code (example)	10
Figure 3:	Derating netFIELD IO-Link Wireless Master device	12
Figure 4:	Connection example with W-Bridge	22
Figure 5:	Dashboard page (example)	33
Figure 6:	Channel selection tab	35
Figure 7:	Channel selection tab, Expert settings (example)	37
Figure 8:	Master > Configuration tab	38
Figure 9:	Scan tab	40
Figure 10:	Scan tab, scan result	40
Figure 11:	Information tab, Device information (example)	43
Figure 12:	Status tab, Port status (example)	44
Figure 13:	Display of the On Request Data, read/write IO-Link Device parameters	46
Figure 14:	Display of the ISDU, read/write IO-Link Wireless Master parameters	48
Figure 15:	Display of the Process Data	51
Figure 16:	Settings tab, Port cycle sub tab (example)	52
Figure 17:	Device configuration tab (example)	57
Figure 18:	Maintenance information tab	58
Figure 19:	Firmware update tab (example)	59
Figure 20:	Firmware update is performed (example)	61
Figure 21:	Factory reset tab	62
Figure 22:	MQTT tab, Client Status, Client Configuration sub tab (example)	63
Figure 23:	MQTT tab, Connection1 > IP settings sub sub tab (example)	64
Figure 24:	MQTT tab, Connection1 > Session settings sub sub tab (example)	65
Figure 25:	MQTT tab, Connection1 > Will settings sub sub tab (example)	66
Figure 26:	MQTT tab, Connection1 > Advanced settings sub sub tab (example)	67
Figure 27:	Menu item SignIn - Input mask for user name and password	68
Figure 28:	User Administration screen mask (initial state)	69
Figure 29:	User Administration screen mask	70
Figure 30:	Master > Configuration tab	73
Figure 31:	Scan tab	74
Figure 32:	Scan tab with result	74
Figure 33:	Settings tab > Port cycle sub tab (example)	75
Figure 34:	Settings tab > Validation level sub tab (example)	76
Figure 35:	Settings tab > Transmission sub tab (example)	77
Figure 36:	Settings tab > Miscellaneous sub tab (example)	78
Figure 37:	Tab and table "Port process data" (example PD input valid = OK)	79
Figure 38:	Status tab, Port status	79
Figure 39:	Information tab, Device information	80
Figure 40:	ISDU tab, read/write IO-Link Device parameters	82

Figure 41:	ISDU tab, read/write IO-Link Wireless Master parameters.....	83
Figure 42:	Node NtpClientUpdateConfiguration (1).....	87
Figure 43:	Node NtpClientUpdateConfiguration (2).....	88
Figure 44:	Dialog for configuring the NTP client.....	88
Figure 45:	Dialog for configuring the NTP client (successful).....	88
Figure 46:	OPC UA: Information model of the device.....	102
Figure 47:	Event Qualifier	127
Figure 48:	Dimensions NFD-3090-EIS-IOLM\W device	135

List of tables

Table 1:	List of revisions	5
Table 2:	Legend to the device overview, NFD-3090-EIS-IOLMW	8
Table 3:	Hardware	9
Table 4:	Software.....	9
Table 5:	Firmware	9
Table 6:	IO-Link Wireless Master	9
Table 7:	Supply voltage	11
Table 8:	Ethernet	11
Table 9:	SMA antenna type	12
Table 10:	Overview for installation and commissioning.....	15
Table 11:	Overview Tool chains 1 and 2	25
Table 12:	Connections	27
Table 13:	Parameters 10 to 85	28
Table 14:	Parameters 410 to 566	29
Table 15:	Calculation of the port cycle time of the IO-Link Wireless Master	29
Table 16:	Time base of I-Am-Alive time.....	30
Table 17:	Calculation of I-Am-Alive time.....	30
Table 18:	Functional overview of the netFIELD Wireless Web Server for IO-Link Devices ...	31
Table 19:	Data on "Dashboard" page	33
Table 20:	IO-Link Wireless Master settings - Channel selection	35
Table 21:	IO-Link Wireless Master settings - Configuration	38
Table 22:	Scan result, pairing	40
Table 23:	Information, Status, Settings, ISDU, or Process Data	42
Table 24:	Information tab, with Device information.....	43
Table 25:	Port status, overview	44
Table 26:	Port state, possible values.....	45
Table 27:	Process data, parameters.....	51
Table 28:	Settings in port configuration for IO-Link Device, Port cycle sub tab.....	52
Table 29:	Calculation of the port cycle time of the IO-Link Wireless Master	53
Table 30:	Settings in port configuration for IO-Link Device, Validation level sub tab	53
Table 31:	Validation and backup, possible values.....	54
Table 32:	Settings in port configuration for IO-Link Device, Transmission sub tab	54
Table 33:	Settings in port configuration for IO-Link Device, Miscellaneous sub tab.....	55
Table 34:	Selection list „Configuration control“	57
Table 35:	Device configuration tab- Parameter	57
Table 36:	Maintenance information	58
Table 37:	Options to delete settings	62
Table 38:	MQTT in port configuration for IO-Link Device, Client Status.....	63
Table 39:	MQTT in port configuration for IO-Link Device, Client Configuration.....	64
Table 40:	MQTT in port configuration for IO-Link Device, Connection1 > IP settings	64

Table 41:	MQTT in port configuration for IO-Link Device, Connection1 > Session settings...	65
Table 42:	MQTT in port configuration for IO-Link Device, Connection1 > Will settings.....	66
Table 43:	MQTT in port configuration for IO-Link Device, Connection1 > Advanced settings	67
Table 44:	Configuration, possible values for IO-Link Wireless Master (example)	73
Table 45:	Scan result.....	74
Table 46:	Settings > Port cycle (example values).....	75
Table 47:	Settings > Validation level (example values)	76
Table 48:	Settings > Transmission (example values)	77
Table 49:	Settings > Miscellaneous (example values).....	78
Table 50:	Status tab, Port status, displayed values	79
Table 51:	Track and Slot – example 1 wireless device with slot type “double slot”	84
Table 52:	Dialog Add Server - tabs Discovery and Advanced	85
Table 53:	Input process data, connection 1 to connection 4	90
Table 54:	Output process data, connection 1 and connection 2.....	91
Table 55:	Input process data, connection 5 to connection 7	93
Table 56:	Output process data, connection 5	95
Table 57:	Input process data, connection 8 to connection 10	97
Table 58:	Output process data, connection 8	99
Table 59:	Input data status	101
Table 60:	Device identification	103
Table 61:	Identification of the connected IO-Link Devices.....	103
Table 62:	NTP client configuration.....	104
Table 63:	General parts of a topic	105
Table 64:	Gateway topics	105
Table 65:	Gateway Capabilities, "JSON key"	106
Table 66:	Gateway Configuration, "JSON key"	106
Table 67:	Master topics	107
Table 68:	Port List, "JSON key"	109
Table 69:	Port Capabilities, "JSON key"	109
Table 70:	Port Status, "JSON key"	110
Table 71:	Port Configuration, configuration values.....	110
Table 72:	Device topics	112
Table 73:	MQTT topics	116
Table 74:	MQTT Configuration, "JSON key"	116
Table 75:	MQTT Connection Status, "JSON key"	116
Table 76:	States of the SYS-LED	117
Table 77:	Definitions of the states of the SYS LED	117
Table 78:	APL LED states	118
Table 79:	Supply voltage status 1L and 2L.....	118
Table 80:	Communication status EtherNet/IP Adapter	119
Table 81:	Definition LED states communication status	120

Table 82:	Ethernet status EtherNet/IP Adapter	120
Table 83:	Definition LED states Ethernet status	120
Table 84:	Wireless track status WT1 ... WT3	121
Table 85:	Wireless track status WP01 ... WP16	121
Table 86:	Class attributes event log object 65 (0x41).....	122
Table 87:	Mapping CIP instances to IO-Link ports	122
Table 88:	Instance attributes event log object 65 (0x41)	122
Table 89:	Structure of a log entry	123
Table 90:	Services Event Log Object 65 (0x41)	124
Table 91:	Error codes (CIP status)	124
Table 92:	Event Qualifier	127
Table 93:	IO-Link Wireless Master Event Codes	127
Table 94:	IO-Link Device Event Codes (common)	128
Table 95:	Technical data NFD-3090-EIS-IOLM\W	130
Table 96:	Technical data SMA antenna.....	131
Table 97:	Technical data IO-Link Wireless Master	132
Table 98:	Technical data EtherNet/IP Adapter	133
Table 99:	Technical Data Web Server	134
Table 100:	OPC UA Server	134
Table 101:	Technical data MQTT Client	134
Table 102:	Signs	139
Table 103:	Signal words	139
Table 104:	Directives and standards netFIELD IO-Link Wireless Master device	140

Glossary

CIP	Common Industrial Protocol: communication protocol for industrial automation applications, which is supported by the ODVA (Open DeviceNet Vendors Association). The peer to peer object oriented protocol provides connections between industrial devices (sensors, actuators) and higher-level devices (controllers) and is physical media and data link layer independent.
DCP	Discovery and basic configuration protocol: Protocol for identifying and configuring devices, which is defined within the PROFINET specification
DHCP	Dynamic host configuration protocol: protocol simplifying the configuration of IP networks by automatically assigning IP addresses
DHCP server	Provides the assignment of IP address via DHCP protocol as a service to other network participants and facilitates the IP address assignment essentially
EDS	Electronic Data Sheet: external ASCII text file that provides information necessary to access and alter the configurable parameters of a device. The file contains information about the configurable attributes of the device, including object addresses of each parameter. The application objects in a device represent the destination addresses for the configuration data. These addresses are encoded in the EDS.
EtherNet/IP	Communication system for industrial Ethernet designed and developed by Rockwell that uses the CIP (common industrial protocol)
EtherNet/IP Adapter	Exchanges real-time I/O data with a Scanner Class product and does not initiate connections on its own
EtherNet/IP Scanner	Exchanges real-time I/O data with adapters and scanners, can respond to connection requests and also initiate connections on its own
IODD	IO Device Description: Describes sensors and actuators with an IO-Link communication interface
IO-Link	Communication system to connect intelligent sensors and actuators to an automation system standardized in the IEC 61131-9 under the name Single-drop digital communication interface for small sensors and actuators (SDCI).
IO-Link wireless	Extension of the IO-Link base technology for IO-Link wireless communication according to the IO-Link Wireless System Specification
IP	Internet Protocol: Belongs to the TCP/IP family of protocols and is defined in RFC791 (available on http://www.ietf.org/rfc/rfc791.txt). It is based on layer 3 of the ISO/OSI 7 layer model of networking and is a connectionless protocol, i. e. you do not need to open a connection to a computer before sending an IP data packet to it. Therefore, IP is not able to guarantee that the IP data packets really arrive at the

recipient. On IP level, neither the correctness of data nor the consistence and completeness are checked. IP defines special addressing mechanisms; see IP address.

IP adresse	Identifies a device or a computer within an IP-based network and is defined in the Internet Protocol Version 4 (IPv4) as a 32-bit number. For ease of notation the address is usually divided into four 8-bit numbers represented in decimal notation and separated by points: a.b.c.d. Each letter stands for an integer value between 0 and 255, e.g. 192.168.30.16. However, not all combinations are allowed, some are reserved for special purposes. The IP address 0.0.0.0 is defined as invalid.
ISDU	Indexed Service Data Unit: Used for acyclic transmission of parameters (IO-Link wireless communication)
MAC-ID	Media Access Control-ID: unique (physical) Ethernet address of the device on delivery, defined as 48 bit number; for ease of notation it is divided into six 8 bit numbers which are represented in hexadecimal notation and separated by "minus"-signs (-): A-B-C-D-E-F (A-B-C-D-E-F each are integer values between 0 and 0XFF=255), Example:00-02-A2-20-91-18
MQTT	Message Queue Telemetry Transport: publish-subscribe based "light weight" M2M (machine to machine) messaging protocol for use on top of the TCP/IP protocol and for telemetry data transmission with a very low footprint. As protocol of the Internet of Things (IoT) it is standardized by OASIS (Organization for the Advancement of Structured Information Standards) since 2013. Additional features: ease of use, efficient use of resources, security mechanisms, support of several cloud-systems, session-aware, data-agnostic (i.e. flexible structures allow to transmit multiple types of information
netFIELD	Technology platform for the industry 4.0 integration of field devices and sensors developed by Hilscher Gesellschaft für Systemautomation mbH
OPC UA	Open Platform Communications Unified Architecture; is a platform-independent standard through which various kinds of systems and devices can communicate by sending Messages between Clients and Servers over various types of networks. It supports robust, secure communication that assures the identity of Clients and Servers and resists attacks.
OPC UA Server for netPROXY	Task-based firmware component integrating the OPC Foundation C stack, as well as an additional server layer from Hilscher for the connection to netPROXY. This component is available as a LOM (Linkable Object Module = library, the respective C-language headers and a WAF script).
PELV	Protective Extra Low Voltage with safe disconnection
PER	Packet Error Ratio
PLC	Programmable Logic Controller: Industrial digital computer for the control of manufacturing processes

QR code	Quick response code according ISO/IEC 18004 standard. A type of two-dimensional barcode that can use up to 4000 alphanumeric characters, often used with smartphone camera.
SELV	Safety Extra Low Voltage
SMI	Standard Master Interface
UUID	Universally Unique Identifier

Contacts

HEADQUARTERS

Germany

Hilscher Gesellschaft für
Systemautomation mbH
Rheinstrasse 15
65795 Hattersheim
Phone: +49 (0) 6190 9907-0
Fax: +49 (0) 6190 9907-50
E-mail: info@hilscher.com

Support

Phone: +49 (0) 6190 9907-99
E-mail: de.support@hilscher.com

SUBSIDIARIES

China

Hilscher Systemautomation (Shanghai) Co. Ltd.
200010 Shanghai
Phone: +86 (0) 21-6355-5161
E-mail: info@hilscher.cn

Support

Phone: +86 (0) 21-6355-5161
E-mail: cn.support@hilscher.com

France

Hilscher France S.a.r.l.
69800 Saint Priest
Phone: +33 (0) 4 72 37 98 40
E-mail: info@hilscher.fr

Support

Phone: +33 (0) 4 72 37 98 40
E-mail: fr.support@hilscher.com

India

Hilscher India Pvt. Ltd.
Pune, Delhi, Mumbai
Phone: +91 8888 750 777
E-mail: info@hilscher.in

Italy

Hilscher Italia S.r.l.
20090 Vimodrone (MI)
Phone: +39 02 25007068
E-mail: info@hilscher.it

Support

Phone: +39 02 25007068
E-mail: it.support@hilscher.com

Japan

Hilscher Japan KK
Tokyo, 160-0022
Phone: +81 (0) 3-5362-0521
E-mail: info@hilscher.jp

Support

Phone: +81 (0) 3-5362-0521
E-mail: jp.support@hilscher.com

Korea

Hilscher Korea Inc.
Seongnam, Gyeonggi, 463-400
Phone: +82 (0) 31-789-3715
E-mail: info@hilscher.kr

Switzerland

Hilscher Swiss GmbH
4500 Solothurn
Phone: +41 (0) 32 623 6633
E-mail: info@hilscher.ch

Support

Phone: +49 (0) 6190 9907-99
E-mail: ch.support@hilscher.com

USA

Hilscher North America, Inc.
Lisle, IL 60532
Phone: +1 630-505-5301
E-mail: info@hilscher.us

Support

Phone: +1 630-505-5301
E-mail: us.support@hilscher.com